

Working Instruction english


Revision	A
Datum	16.05.2007
Ersteller	NH
T 1 · · · ·	

This operating instruction is not subject to the updating

Parking Station

1-95813-9-00034-AAAA-Z03







This parking station is a quality product, in which special attention has been paid to high functionality, ease of operation, safety and reliability. As an item of technical equipment this parking station is intended for use in the commercial, industrial area and for operators, who have been trained by specialists in the handling of technical systems / tools.

Customer care:

As part of our individual customer care we will be happy to assist you in questions relating to use and operation and on any problems encountered.

Service and maintenance:

In order to maintain the high technical performance capability and reliability of your parking station over many years, we recommend regular inspection and maintenance.

We can thereby offer you optimum support by our Customer Service department and the conclusion of a service and maintenance contract. Please ask for a quotation.

> Carl Kurt Walther GmbH & Co. KG PO Box 42 04 44 42781 Haan Westfalenstraße 2

Tel.: +49 (0) 2129 567-0 Fax: +49 (0) 2129 567 450

E-Mail: info@walther-praezision.de Internet: www.walther-praezision.de

Contact:

Application technology and service Holger R. Figge Telephone: (02129) 567-591 Telefax: (02129) 567-590 Handy: (0162) 2090100 e-mail: hfigge@walther-praezision.de

Further addresses and telephone numbers of contacts can be found on the Internet on our homepage under <u>www.walther-praezision.de</u> "Service / Customer service".



List of Contents

1 List of Contents

1	Ll	IST OF CONTENTS	
2	G	ENERAL	4
3	SA	AFETY INSTRUCTIONS	5
4	w	ARRANTY	6
5	G	ENERAL DESCRIPTION OF TOOL PARKING STATION	7
6	TI	ECHNICAL DATA	7
7	D	ESCRIPTION OF EQUIPMENT	
	7.1	STAND	8
	7.2	LEVEL ADJUSTMENT	
	7.3	Support	
	7.4	PROTECTION COVER	
	7.5	INSTALLATION PACKAGE ELECTRO	
	7.6	INSTALLATION PACKAGE PNEUMATIC	
8	AS	SSEMBLY AND INSTALLATION	9
	8.1	GENERAL SAFETY INSTRUCTIONS	9
	8.2	Erection	9
	8.3	PNEUMATIC INSTALLATION	
	8.4	ELECTRICAL INSTALLATION	
9	C	OMMENTS TO APPLICATION PREPARATION	11
1()	COMMISSSIONING, WORKING AND MAINTENANCE	12
	10.1	General safety instructions	12
	10.1	PREVENTIVE CHECKS	
	10.3	MAINTENANCE	
11	1	WORKS ON MALFUNCTIONS AND DAMAGES	
	11.1	GENERAL SAFETY INSTRUCTIONS	13
	11.1	MALFUNCTIONS AND ASSESSMENT OF DAMAGE	
	11.2	REPAIR	
12		DRAWINGS AND PARTS LISTS	
	12.1	1-95813-9-00034-AAAA-Z03 parking station	
	12.1	1-95813-9-00003-AAA-Z03 SUPPORT FOR WELDING GUNS	
	12.2	1-95813-B-00008-AAAA-Z03 SUPPORT FOR WELDING GUNS	
	12.3	1-95813-E-00008-AAAA-Z03 ELECTRICAL EQUIPMENT	
	12.4	1-95813-P-00007-AAA-Z03 INSTALLATIONSPAKET PNEUMATIK	
	12.6	1-95813-B-00005-AAAA-Z03 Tool Identification	
	12.7	1-95813-B-00006-AAAA-Z03 SECURITY MODULE (PARKING STATION)	
	12.8	1-95813-B-00016-AAAA-Z03 INSCRIPTION	
13	3	INDEX	



General

2 <u>General</u>

This manual contains all regulations for operation, commissioning and maintenance of the parking station 95813.

All information and notes in this operating manual were collated while taking into consideration the valid regulations, the current engineering related status of development as well as our many years of experience and acquired knowledge.

Translations of this operating manual were also produced according to the best of knowledge. However, we cannot assume liability for any translation errors. The German version provided for this operating manual is considered the authoritative version.

The actual scope of delivery can deviate from the explanations and graphic representations described herein under certain circumstances, e.g. in the case of special designs, utilization of additional order options or because of state-of-the-art technical alterations. If you have any questions, please contact the manufacturer.

This operating manual must be read carefully before starting work on or with the equipment, in particular before commissioning!

The manufacturer assumes no liability for damage or faults arising from non-compliance with the instructions in this operating manual.

The operating manual must be kept directly with the equipment and be accessible to all persons who work on or with the equipment.

It is not permitted for the operating manual to be passed to third parties and if applicable this will incur damage compensation. All other rights reserved.

Before commissioning the device must be checked for being not defective and its technically perfect function.

The German version is the original.

We reserve the right to make technical alterations to the product within the context of improving the usage properties and further development.

The operating manual remains our property.

Any reproduction, use by or communication to third parties incurs a penalty and will be pursued by court action (copyright law against unfair competition, BGB [German Civil Code]). All rights reserved in the case of a patent award (Paragraph 7, Section. 1 of the patent law - PG) or entry as a patented design (Paragraph 5, Section 4 of the patented design law - GMG).



Safety Instructions

3 Safety Instructions

The usage of this coupling requires from the operator to observe all relevant industrial safety regulations. It is up to the duty of care of the user of the coupling to plan protective measures which guarantee an orderly operation and to control their realization.

Danger references

In case of wrong product selection, inappropriate use and non-effected maintenance, there is a danger that damage can be caused to persons and objects. This may result from

- dangerous spreading of medium or individual particles / coupling parts.

In particular, the operator must guarantee that

- coupling is always used according to specification.
- coupling is always used in an orderly, functionable way.
- operating instruction is always available to the operators in a complete and readable form.
- operating personnel is sufficiently informed about the operating and safety instructions of the coupling.
- for repair, couplings are returned to our factory.
- during operation of the coupling, no safety devices are removed and/or set out of function.
- coupling is not pressurized before mounting/dismounting of the coupling.

The following items have to be observed after assembly and installation as well as before the first use of the coupling:

Check again whether all screw-type connections are firmly fixed.

Before the first use of the coupling, a functional test must be made (see "Maintenance and functional test").



Warranty

4 <u>Warranty</u>

The warranty conforms to:

the "General Conditions for Delivery and Capacity" of C.K. Walther GmbH & Co. KG of the state which was valid at the date of the purchase contract and

the regulations agreed in the purchase contract.

Wearing parts are generally excluded from the warranty. Typical wearing parts of products from company C.K. Walther GmbH & Co. KG are for example:

- seals
- springs
- electric plug contacts
- electric cables and hoses which are exposed to a regular alternating bending load or torsional stress

Also components which normally do not wear under the estimated conditions (ambient and operational conditions) can transform into wearing parts if the described product is not operated to the agreed conditions or if technical demands of the operating instructions are disregarded.

Thus, for example electric cables are not part of this warranty if the coating is damaged by an extreme occurrence of flying welding sparks. Furthermore, the wear of other components which results from exceptional ambient conditions and which are not expressly agreed with C.K. Walther GmbH & Co. KG does not belong to this warranty such as high temperatures, abrasive acting dust, high humidity or corrosive acting steam and gases.

Regarding maintenance works, the demands dependent on cycles, time or load applications for the exchange of certain components of the described product are no warranty relevant statements of durability but recommendations for preventing maintenance for minimisation of standstill periods in production.



General description of tool parking station Technical data

5 General description of tool parking station

The tool parking station is used to pick up welding tools (welding guns) at robot working places with tool change systems.

The tool parking station can be modified for different requirements by the designed modular system and is adaptable to the tool geometry within limitations (see item 12).

The parking of the welding tools is done by vertical movement towards the parking position by the robot and disconnection of the tool changer.

The tools are parked in such a way, that tool side of the tool changer with parking segments which are provided with 2 bolts each is plunged in 2 sword guidances of the tool parking station. An additional support device (roll support) is not necessary for most of the applications.

According to scope of delivery and equipment the tool parking station consists of the following components:

- stand
- level adjustment
- support
- protection cover (hinged cover)
- installation package electro
- installation package pneumatic
- tool identification
- safety module

The stand and/or level adjustment are to be anchored in the floor of the hall and/or welded on a base plate by means of 4 screws M 16.

6 Technical data

Main dimensions according to drawing (see item 12).

Support distance = 200 mm.

Tool clearance between the parking arms = 130 mm.

Interference dimension in parking direction = $0 \dots 35$ mm.

Maximum load = 6.000 N.



Description of equipment

7 Description of equipment

7.1 <u>Stand</u>

The stand consists of the welded bracket and the fastening elements.

Construction dimensions

- Height of parking station
- (clearance floor/tool changer tool side assembly side)
- Misalignment parking station/tool changer
- Drill picture base plate (attachment level adjustment Construction dimensions according to drawing (see item 12)

7.2 Level adjustment

The level adjustment is used to level the parking tool station (adjustment during installation).

Plate size = 400 mm x 500 mm Drill pictureanchorage = 350 mm x 450 mm

7.3 <u>Support</u>

This component group takes up the torque caused by the tool load whereat two bolts of the tool changer each support themselves in horizontally and vertically displaced sword guidances which are arranged in a support distance of 200 mm.

With type 95813-Z01 a floated position with a radial balance of 1 mm is obtained. Type 95813-Z02 is rigid piped.

7.4 Protection cover

Protection cover is used to avoid contaminations of tool changer parts being in the parking tool station, especially for protection against weld chips.

It is a pneumatic clamping unit with warm and cover and integrated position monitors.

- Air pressure connection $p_{min} = 5$ bar.
- Apperture angle of protection cover $= 90^{\circ}$.
- Proximity switch 1SE1R/2SE1R = "protection cover off".
- Proximity switch 1SE1V/2SE1V = "protection cover on".

If the cover is designed as flexible plastic plate (hardly flammable) the endangering is reduced by mobile parts to a large extent.

<u>Weight:</u> = kg (without valve and hoses)

7.5 Installation package electro

Depending on required scope of delivery:

- with Interbus module inclusive connector cable to sensors and valves.
- with Aktor sensor box inclusive connection cable to sensors and valves.

7.6 Installation package pneumatic

Depending on the required scope of delivery:

- with ISO pneumatic valve size 1 inclusive piping (without valve plug).



Assembly and Installation

8 Assembly and installation

8.1 **General safety instructions**

ATTENTION!

The tool parking station must not be used before the tool parking station is anchored in the floor of the hall, <u>tipping danger</u>!

ATTENTION!

Before connection to the air pressure system close cover!

Please observe safety distance to the moving parts during adjustment and operation!

8.2 <u>Erection</u>

The tool parking station must be erected and adjusted in such a way that tool changer plate lies on horizontally. Maximum difference in height of support points = 1 mm.

Fastening is carried out in the floor of the hall with 4 anchor bolts M 16 or by welding on at an anchored steel base plate.

If delivery is carried out with level adjustment adjusting is essentially simplified:

- anchorage of the base plate in the floor of the hall.
- unscrew the 4 fillister head screws M 16 and groove nuts M 32x1.5.
- level the tool parking station by adjusting the 4 adjusting screws with wrench SW 36.
- fix the adjusting screws with the 4 groove nuts with sickle spanner DIN 1810-A45-50 (safety via Schnorr tooth lock washers).
- drive in the 4 fillister head screws M 16 with
- a hexagon screw driver SW 14. Torque = 195 Nm.

8.3 **Pneumatic installation**

Version with protection cover only

 a) Scope of delivery with installation package pneumatic: Pneumatic installation is complete; the protection cover movement is adjusted. Air pressure connection is carried out according to pneumatic schedule (see 12) at the connecting plate of the ISO directional control valve.

Please observe safety instructions to item 7.1!

- b) Scope of delivery without installation pneumatic:
 - mount the directional control valve at the rear side of the parking station bracket.
 - screw in swivel connections with one-way restrictor into the pneumatic cylinder and complete closing of the chokes by clockwise turning of the adjusting screw.
 - Installation of hose connections between cylinder and directional control valve.
 - screw in sound absorbers.
 - air pressure connection see A.
 - adjust protection cover movement by careful unscrewing of the adjusting screws of the chokes (tipp operation for valve circuit).



Assembly and Installation

ATTENTION!

Avoid hard final position stress!

ATTENTION!

Do not operate pneumatic cylinder of the protection cover without choke!

ATTENTION!

Opening of the protection cover is done due to pressure build-up with a delay of 1 ... 2 s !

8.4 <u>Electrical installation</u>

- a) Scope of delivery without installation package electro: - adjust the signalling point of the proximity switch.
- b) Scope of delivery with installation package electro (Aktor-Sensor-Box/ Distributor):
 The electro installation is complete; the signalling point of the proximity switch
 - is adjusted.
 - The control connection is doneaccording to customer`s control via the plug connection at the Aktor-Sensor-Bocx/distributor.
 - Check signalling point of the proximity switch, readjust if necessary.
- c) Scope of delivery with installation package electro (Interbus module):
 - The electro installation is complete; the signalling point of the proximity switch is adjusted.
 - Incoming and continuing signal cable are plugged in via the plug connection of the BUS module according to customer's control.
 - check signalling point of the proximity switch, readjust if necessary.



Comments to application preparation

9 Comments to application preparation

Adjust the signalling point of the proximity switch.

The tool parking station must stand within the working area of the robot to enable a direct parking of the tool.

To avoid that the tool (tool changer) falls out of the receptacles the mass center of gravitiy of the tool must be within the extension of the support width. As the distance of the locating bolt is 200 mm, a position of the center of gravity within an area of 150 mm is regarded as safe (75 mm from the center line).

The parking of tools into the tool parking station as well as the picking up of tools from the tool parking station is done fully automatically by the robot. The opening of the protection cover before the tool is picked up and the closing of the protection cover after the tool is picked up is robot controlled.

Flow chart see documentation of the tool changer.

When parking the tool strong shock loads caused by too high disconnecting speed of the tool changer or the free fall of the load are to be avoided!

Please observe a sufficiently great distance to interference contours when lifting the tool/tool changer out of the tool parking station!

The insertion depth of the guiding bolts is 30 mm so that before an extension movement taking place radial to the robot axis 6 the tool side of the tool changer must be lifted by at least 35 mm

In case of mounted tool please observe that the tool during this extension movement does not collide with the holding device (Rob-CAD-test).



Commissioning, working and maintenance

10 Commisssioning, working and maintenance

10.1 General safety instructions

- Prior to commissioning check the anchorage in the floor of the hall on its interference fit!
- Keep away parts of the body especially hands from the hinged cover mechanism during automatic and hand operation, danger of injury!

10.2 <u>Preventive checks</u>

WALTHER tool parking stations are to be operated in such a way that external damages especially all moving parts are excluded.

According to our practical experience tool parking stations will give long-term, trouble free service if care is taken to recognize and repair any possible damages in good time.

Preventive visual checks are to be carried out once a week or after 10,000 couple cycles each.

- Please observe the interference fit of all screwed cable glands!
- Check the welding construction of the stand on cracks and deformations!
- Check the hinged mechanism of the protection cover for ease of movement and deformations!
- Check the signalling point of the proximity switch!

10.3 Maintenance

To reduce connecting forces of the tool changer to a minimum and to prolong lifetime the following parts must be slightly greased:

- sword guidances.
- all hinged parts at the pneumatic clamping unit.

Use greases (e.g. Arcanol Multi 3) and contact sprays which do not attack the mounted FKM seals and meet the requested cleanliness requirements (observe internal instructions).

Recommended maintenance cycle:

once a week or after 10,000 couple cycles each.



Works on malfunctions and damages

11 Works on malfunctions and damages

11.1 General safety instructions

Works on tool parking stations shall only be carried out

- if <u>no</u> tool is in the parking station.
- without pressure (in case of version with protection cover).
- if the robot was moved into a safe position and stopped.

11.2 <u>Malfunctions and assessment of damage</u>

Malfunctions can only arise by:

- failure at the proximity switches/ connecting pieces/BUS or distribution modules.
- failure at the pneumatic components.
- mechanical deformation/cracks at the stand, support, protection cover owing to a crash or overload and/or use not in accordance with the requirements.
- wear at the bearing places by insufficient lubrication.

The main function dimensions must be checked after a crash especially the distance dimension of the sword guidances = $200^{\pm 0,2}$ mm.

In case of smaller deformations it can be readjusted. If it concerns larger damages the defect parts are to be replaced by new ones..

Attention!

After a crash check fastening / anchorage at the floor of the hall!

11.3 Repair

Faulty electrical or pneumatic components are to be replaced. The signalling point of the proximity switches is to be readjusted.

The tool parking station must be readjusted and levelled after a repair (straighten or exchange stand parts).

If necessary the robot aim positions are to be programmed once again.

Attention!

Close cap of the protection cover prior to reoperation and/or connection to the air pressure system. After the exchange of pneumatic cylinder or one way restrictors the cap speed must be readjusted.




Drawings and parts lists

12 Drawings and parts lists



Drawings and parts lists

12.1 <u>1-95813-9-00034-AAAA-Z03</u> parking station



				1 °		
Pos.	Benennung	ldentnr.	Zeichnungsnr.	Stueck	Werkstoff/Werkstoffnr. Bemerkung	Bemerkung
03	ABSTÜTZUNG	76964	1-95813-B-00003-AAAA-Z03	1.000		
04	KLAPPDECKEL-ABDECKUNG/LWL	82944	1-95813-B-00008-AAAA-Z03	1.000		
05	Installationspaket Elektro	106080	1-95813-E-00008-AAAA-Z03	1.000		
90	Installationspaket Pneumatik	101807	1-95813-P-00007-AAAA-Z03	1.000		
07	WERKZEUGKENNUNG	76979	1-95813-B-00005-AAAA-Z03	1.000		
60	SICHERHEITSMODUL (ABLAGE)	76982	1-95813-B-00006-AAAA-Z03	1.000		
10	BESCHRIFTUNG	42517	1-95813-B-00016-AAAA-Z03	1.000		Firmenschild Typenschild
	SECHSKANTSCHRAUBE	3670	DIN 933-M12 X 45- 8.8	4.000	STAHL	
12	SCHEIBE	1182	DIN 125-A 13 -ST	4.000	STAHL	


Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte Personen ist daher strafbar und wird gerichtlich verfolgt. (Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb, BGB). Alle Rechte für den Fall der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.

Name Werkzeugabiage Kopf - Master TGrah Bestellhummer: TGrah Bestellhummer: AHeinemann 1-95813-9-00034-AAAA-Z03	A200753	Ausf.: A vom 16.04.2007		Aust.: A vom 16.04.2007 Aust.: A vom 16.04.2007 A200753 A200753 A200753 A200753 A200753 A200753 A200753 A200753 A200753 A20077 Datum Name Ersterst. 16.04.2007 TGrah Geschr. 19.04.2007 AHeinemann Geprüft 19.04.2007 AHeinemann	
	DatumNameWerkZeugabiage Kopi - MasterErsterst.16.04.2007TGrahSachnummer:Geschr.19.04.2007TGrahBestellhummer:Geprüft19.04.2007AHeinemann1-95813-9-00034-AAAA-Z03	A200753A200753DatumNameErsterst.DatumI 6.04.2007TGrahErsterst.16.04.2007TGrahSachnummer:Geschr.19.04.2007AHeinemann195813-9:00034.AAAA.Z03Geprüft19.04.2007AHeinemann106082	Ausf.: A vom 16.04.2007 Ausf.: A vom 16.04.2007 A200753 Verkzeugablage Kopf - Master I Datum Name Ersterst. 16.04.2007 T Grah Sachnumer: Geschr. 19.04.2007 T Grah Sachnumer: Geprüft 19.04.2007 AHeineman 106082	16.05.2007	Seite: 1/1



Drawings and parts lists

12.2 <u>1-95813-B-00003-AAAA-Z03</u> <u>Support for welding guns</u> <u>1-95813-B-00024-AAAA-Z03</u> group zero-sockets



Grundkörper 76965 Aufnahme 76966 Aufnahme 76966 Deckel 76966 Deckel 76967 Distanzbuchse 76968 Distanzbuchse 76968 SECHSKANTSCHRAUBE 76968 SCHEIBE 1182 Scheibe 1182 Scheibe 3428 SechskantSchraube 3428 Gruppe Nullbuchse 99891	Pos.	Benennung	ldentnr.	Zeichnungsnr.	Stueck	Werkstoff/Werkstoffnr.	Bemerkung
Authahme 76966 4-95813-504-00-203 20000 1/2311 V Deckel 76967 4-95813-505-11-203 20000 1/05701.003 Distanzbuchse 76963 4-95813-513-11-203 20000 1/0716K Distanzbuchse 7713 78963 4-95813-513-11-203 20000 1/0716K Distanzbuchse 7713 7713 7113 DIN 933-M12 X 35-10.9 4.0000 STAHL SECHSKANTSCHRAUDE 7713 DIN 125-413-51 4.0000 STAHL SECHSKANTSCHRAUDE 7713 DIN 125-413-51 4.0000 STAHL SCHEIBE 7713 DIN 125-413-51 4.0000 STAHL Spannstit 73923 DIN 148-8 X20-A2 2.0000 1.0160 Scheibe 73923 DIN 135-4 13-51 2.0000 1.4305 Spannstit 20000 1.0000 1.4305 1.4305 Scheisterbuchse 3428 DIN 933-M6 X 10-A2-70 8.000 1.4305 Scheisterbuchse 99891 1-95813-B-00024-AAA-203 1.000 1.4		Grundkörper	76965	4-95813-503-11-203	1.0000	1.0570/1.003	
Decket Ze000 Ze000 Ze000 Ze000 Ze000 Ze001.003 Distanzbuchse Ze011	2	Aufnahme	76966	4-95813-504-00-203	2.0000	1.2311 V	
Image: Distanzbuchse 78968 4-95813-513-11-203 4-0000 SSMMPB28K Image: Distanzbuchse 77113 DIN 933-M12 X 35-10.9 4-0000 STAHL Image: Distanzbuchse 77113 DIN 933-M12 X 35-10.9 4-0000 STAHL Image: Distanzbuchse 77132 DIN 125-A 13-ST 4-0000 STAHL Image: Distanzbuchse 73923 DIN 1481-B X 20-A2 2-0000 STAHL Image: Distanzbuchse 3428 DIN 1481-B X 20-A2 2-0000 14305 Image: Distanzbuchse 3428 DIN 333-M6 X 10-A2-70 2-0000 14305 Image: Distanzbuchse 3428 DIN 933-M6 X 10-A2-70 2-0000 14305 Image: Distanzbuchse 9881 1-95813-B-00024-AAA-Z03 1-0000 7-1000	ю	Deckel	76967	4-95813-505-11-Z03	2.0000	1.0570/1.003	
RECHSKANTSCHRAUBE 77113 DIN 933-M12 X 35-10.9 4.0000 STAHL SCHEIBE 1182 DIN 125-A 13 -ST 4.0000 STAHL Scheibe 73923 DIN 1451- 8 X 20-A2 2.0000 StAHL Spannstift 73923 DIN 1461- 8 X 20-A2 2.0000 1.4305 Schristbe 3428 DIN 933-M 6 X 10-A2-70 6.000 1.4305 Gruppe Nullbuchse 9891 1-95813-B-00024-AAAA-Z03 1.0000 1.4305	4	Distanzbuchse	76968	4-95813-513-11-Z03	4.0000	9SMNPB28K 1.0718K	
SCHEIBE 1182 DIN 125-A 13 -ST 4.0000 STAHL Spannstift 73923 DIN 1481- 8 X 20-A2 2.0000 1.4305 Spannstift 73923 DIN 1481- 8 X 20-A2 2.0000 1.4305 SchtskavTSCHRAUBE 3428 DIN 933-M 6 X 10-A2-70 6.0000 1.4305 Gruppe Nullbuchse 99891 1-95813-B-00024-AAAA-Z03 1.0000 1.4305	2	SECHSKANTSCHRAUBE	77113	DIN 933-M12 X 35-10.9	4.0000	STAHL	
Spannstift 2.0000 X8CrNiS1B-9 Spannstift 1.4305 2.0000 1.4305 SECHSKANTSCHRAUBE 3428 DIN 933-M 6 X 10-A2-70 6.0000 1.4305 Gruppe Nullbuchse 99891 1-95813-B-00024-AAA-Z03 1.0000 1.0000	9	SCHEIBE	1182	DIN 125-A 13 -ST	4.0000	STAHL.	
SECHSKANTSCHRAUBE 3428 DIN 933-M 6 X 10-A2-70 K10CRNIS18 9 SECHSKANTSCHRAUBE 3428 DIN 933-M 6 X 10-A2-70 6.0000 1.4305 Gruppe Nullbuchse 99891 1-95813-B-00024-AAAA-Z03 1.0000 1.0000	2	Spannstift	73923	DIN 1481- 8 X 20-A2	2.0000	X8CrNiS18-9 1.4305	
Gruppe Nullbuchse 99891 1-95813-B-00024-AAAA-Z03 1.0000	œ	SECHSKANTSCHRAUBE	3428	DIN 933-M 6 X 10-A2-70	6.0000	X10CRNIS189 1.4305	
	60	Gruppe Nullbuchse	99891	1-95813-B-00024-AAAA-Z03	1.0000		2 Stk. Nullbuchse 4-95499-509 lose beigelgt und nach dem Ausrichten,beim Kunden,entfernt Aufkleber 7-137-00033

1

Sachnummer: 76964 BGB). Alle Rechte für den Fall der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten. <u>Bestellnummer:</u> ABSTÜTZUNG GNeschen GNeschen Name D vom 22.01.2007 A200468 30.11.2006 30.11.2006 Datum Ausf.: Ersterst. walther präzision Ð

Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte Personen ist daher strafbar und wird gerichtlich verfolgt. (Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb,


24.01.2007

1-95813-B-00003-AAAA-Z03

MHerold

30.11.2006

Geschr. Geprüft. Seite: 1 / 1



Pos.	Pos. Benennung	ldentnr.	Identur. Zeichnungsnr.	Stueck	Stueck Werkstoff/Werkstoffnr. Bemerkung	merkung
					AIMgSi1 F28	
0	Nullbuchse	87737	4-95499-509-36	Z.0000	3.2315.71	
2	Sechsakantschraube	99855	DIN 933-M 6 X 40- 8.8	2.0000	STAHL 8.8	
e	Scheibe	1191	DIN 9021- 6,4-ST	2.0000	STAHL	
4	Spannstift	99856	DIN 7346- 8 X 26-FST	2.0000	FST	
2	Aufkleber Nullbuchsenanleitung	99854	7-137-00041	1.0000	PVC	


Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte Personen ist daher strafbar und wird gerichtlich verfolgt. (Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb, BGB). Alle Rechte für den Falt der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.

	Aus	Ausf.: B vom 30.11.2006	11.2006	
		A200361		
		Datum	Name	
\bigcirc	Ersterst.	30.11.2006	GNeschen	
walther oräzision	Geschr.	30.11.2006	GNeschen	Bestellinummer: 2 00001 00001 00000 00801
	Geprüft.	30.11.2006	MHerold	
				30.11.2006 Seite: 17



Drawings and parts lists

12.3 <u>1-95813-B-00008-AAAA-Z03</u> <u>Hinged cover</u>



Pos.	Benennung	ldentnr.	Zeichnungsnr.	Stueck	Werkstoff/Werkstoffnr. Bemerkung	kung
				0000 P	St37-2	
	Arm	76970	4-95813-506-11-203	0000-1	1.0037	
2	Deckel	81707	4-95813-518-00-203	1.0000	RECA-PUR GELB	
e	Adapterplatte	76971	4-95813-507-11-203	1.0000	ST37.2 1.0037K	
4	KOMPAKTSPANNER MIT SELBSTHALT.	72299	7-129-K50 T12 A10 90	1.0000	Fa.TÜN Kunden	Fa.TÜNKERS (VW Ausführung) oder Kundenbeistellung
2	ZYLINDERSCHRAUBE	3185	DIN 912-M 8X X 20-A2-70	4.0000	X10CRNIS18 9 1.4305	
Q	Spannstift	73923	DIN 1481- 8 X 20-A2	2.0000	X8CrNiS18-9 1.4305	
~	SPANNSTIFT	73922	DIN 1481- 8 X 24-A2	1.0000	X10CRNIS18 9 1.4305	
œ	SECHSKANTSCHRAUBE	77121	DIN 933-M12 X 40-10.9	2.0000	STAHL	
6	SCHEIBE	1182	DIN 125-A 13 -ST	2.0000	STAHL	
10	SECHSKANTSCHRAUBE	19798	DIN 931-M 8 X 40-A2-70	2.0000	X10CRNIS18 9 1.4305	
1	ZYLINDERSCHRAUBE	19664	DIN 912-M 5X X 16-A2-70	4.0000	X10CRNIS18 9 1.4305	
Die	Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte Personen ist daher str BGB). Alle Rechte für den Fall der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.	r Mitteilung (I-Eintragung	an dritte Personen ist daher strafbar und wird gerichtlich verfolgt.(Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb, (§5 Abs.4 GMG) vorbehalten.	ichtlich verfo	lgt.(Urheberrechtsgesetz, Gesetz ç	gegen unlauteren Wettbewerb,


	Aus	Ausf.: B vom 22.01.2007	01.2007		
		A200464			
		Datum	Name		
	Ersterst.	22.01.2007	GNeschen		
walther oräzision	Geschr.	22.01.2007	GNeschen	Bestellnummer: 2 Acres 5 AAAA 703	
	Geprüft.	22.01.2007	AHeinemann		
				22.01.2007	Seite: 1/2

SCHEIBE			7	1431 1	DIN 9021- 5,3-A4	4.0000	X6CRNIMOT117 12 2 1.4571	
chnung ist unser E	Eigentum. Jede Verv Ausf.:	ervielfältigung, Verwertu rteilung(§7 Abs.1 PG) or f:: B vom 22.01.2007	erwertung oder M 1 PG) oder GM-Ei	Intragung (Die Zeichnung Ist unser Eigentum, Jade Verweitlung oder Mitchlung an dritte Personen ist daher starthar und wird gerchtlich verlögt, (Urhoberrechtigsestz, Gasetz gegen unlauteren Weitbeweh. BOS). Alle Reiche für den Fallen erst den Schlend GMC) vorbehalten. BOS). Alle Reiche für den Fallen erst den Schlend GMC) vorbehalten. Austi: B. vom z2.01.2007 Austi: B. vom z2.01.2007 K. KAPPDECKEL-AUDIC/KUNGLWM.	ichtlich verk	olgt.(Urheberrechtsgesetz, G	esetz gegen unlauteren Wettbewerb,
(F)	Ersterst.	Datum 22.01.2007	Name GNeschen	. <u> </u>				
walther oräzision		22.01.2007	GNeschen	Bestellnummer.			Sachnummer.	
	Geprüft.	22.01.2007	AHeinemann	1-95813	1-95813-B-00008-AAAA-203		*******	
					22.01.2007			Saita: 2/2



Drawings and parts lists

12.4 <u>1-95813-E-00008-AAAA-Z03</u> electrical equipment



Pos.	Benennung	ldentnr.	Zeichnungsnr.	Stueck	Werkstoff/Werkstoffnr.	Bemerkung
2	RUGGED LINE (INTERBUS)	39859	7-217-IBS RL 24 DIO 8/8/8-RLK	1.0000		
02	MONTAGEPLATTE	78920	7-217-IBS RL AP	1.0000		
03	Schutzkappe	61976	7-054-IBS IP PROT IO	6.0000		
05	Verbindungskabel	39884	7-113-RST5-RKWT- LED P5 181	1.0000		
90	Verbindungskabel	39884	7-113-RST5-RKWT- LED P5 181	2.0000		
10	Verbindungskabel	39884	7-113-RST5-RKWT- LED P5 181	1.0000		
80	ZYLINDERSCHRAUBE	4629	DIN 84-M 4 X12-A2-70	4.0000	X10CRNIS18 9 1.4305	
60	Beschriftungsschild	84155	7-137-IBS RL MARKER-SET-KLEIN	2.0000		
10	ZYLINDERSCHRAUBE	1017	DIN 912-M 4X X 10-A2-70	2.0000	X10CRNIS18 9 1.4305	
£	Anschlußleitung Doppelmagnetv.	41025	7-113-VAS22-2.048-0,4-VZSA22-2.048-F	1.0000		
12	BLINDNIETE	65755	DIN 7337-A 2,4 X 8	2.0000		
13	BLOCKVERTEILER 2FACH	72744	7-217-FSM5-2 FKM5.4/S89	2.0000		
20	Kennzeichnungsschild	47947	7-137-7723-ELOX	10.0000	AL	
21	Kennzeichnungsschild	106081	4-91489-574-31AD-00001-Y10	1.0000	AIMgSi1 F28 3.2315.71	
Die Z. BGB).	Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte Personen ist daher str BGB). Alle Rechte für den Fall der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.	der Mitteilung an c 3M-Eintragung (§5	iritte Personen ist daher strafbar und wird gerichtlich verfolgt.(Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb, Abs.4 GMG) vorbehalten.	ichtlich verfe	olgt.(Urheberrechtsgesetz,	Gesetz gegen unlauteren Wettbewerb,
	Ausf.: A vom 16.04.2007					
		1				


DatumDatumNameErsterst.16.04.2007TGrahBestellnummer.Bestellnummer.Ceprüft19.04.2007HeinemannJohnemann1-95813-E-00008-AAAA-Z03Ceprüft19.04.2007AHeinemann106080	Datum Name	A200753 Actualitionscrabet Flakter	Ausf.: A vom 16.04.2007	Ausf.: A vom 16.04.2007Ausf.: A vom 16.04.2007A200753Installationspaket ElektroDatumNameErsterst.16.04.2007TGrahBestellhummer.Geschr.19.04.2007AHeinemann1-95813-E-00008-AAAA-Z03
	Ersterst. 16.04.2007 TGrah Bestellnummer. Geschr. 19.04.2007 TGrah Bestellnummer. Geprüft 19.04.2007 AHeinemann 195813-E-00008-AAAA-Z03	DatumNameInstanton power Low OErsterst.16.04.2007TGrahSachnummer.Geschr.19.04.2007TGrahBestellnummer.Geprüft19.04.2007AHeinemann106080	A200753A200753Installationspaket ElektroInstallationspaket ElektroErsterst.16.04.2007TGrahInstallationspaket ElektroSachnummer:Installationspaket ElektroSachnummer:Installationspaket ElektroSachnummer:Installationspaket ElektroSachnummer:Installationspaket ElektroInstallationspaket ElektroInstallationsp	

19.04.2007



Drawings and parts lists

12.5 <u>1-95813-P-00007-AAAA-Z03</u> Installationspaket Pneumatik



Pos.	Benennung	ldentnr.	Zeichnungsnr.	Stueck	Werkstoff/Werkstoffnr.	Bemerkung
,	Wedeventil	42549	7-092-00.100 44	1.000		
				0	X10CRNIS18 9	
2	ZYLINDERSCHRAUBE	19664	DIN 912-M 5X X 16-A2-70	2.000	1.4305	
				000 0	X10CRNIS189	
e	SCHEIBE	1427	DIN 125-A 5,3-A2	2 .000	1.4305	
4	Schalldämofer	89331	7-039-U-1/4-B	2.000		
L L		62594	7-116-SA 816/00	2.000		
,				6 000		
9	Schlauchtülle	62610	7-207-VW 39-V-16631	0.000	1.4305	
7	Doppelnippel	62702	7-079-39 D 1403/1	3.000		
∞	Steckschlauch	62539	7-027-VW 39-V-16662 NW 6	4.000	NEOPRENE M.TEXTILE.	4 Stück a 0,4 Meter
		00100		2 000		
л О	Kabelbinder	70/00			PA 6.0	


Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte Personen ist daher strafbar und wird gerichtlich verfolgt. (Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb, BGB). Alle Rechte für den Fall der Patenterteilung (§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.

BGB). Alle Rechte für den Fall der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.	Aust.: B vom 16.05.2007	A200861	Datum Name Installationspared i recontains	16.05.2007 NHeinz	16.05.2007 NHeinz Bestellnummer: Sachnummer: 10.05.2007 NHeinz 1.0523.00007-0.0007-0.0003.000000000000000000		Seite: 1/1
oder GM-Eintragung (§5 Ab		 netal ationenakat E		łeinz			
eilung(§7 Abs.1 PG)	B vom 16.05.2007	A200861				16.05.2007 AHe	
all der Patenterte	:Jausf.:			Ersterst.	Geschr.	Geprüft	
BGB). Alle Rechte für den F					walther		



Drawings and parts lists

12.6 <u>1-95813-B-00005-AAAA-Z03</u> <u>Tool identification</u>



Pos.	Benennung	ldentnr.	Zeichnungsnr.	Stueck	Werkstoff/Werkstoffnr. Bemerkung
					ST37.2
~	Haltewinkel	169/3	4-95613-906-11-206-5	7.000	1.0037K
5	Trageschiene	76978	4-95813-509-11-203	2.0000	STAHL
					ST37.2
<u>~</u>	Bolzenhalter	76974	4-95813-510-11-203	1.0000	1.0037K
					9SMNPB28K
4	Bolzenhalter	76977	4-95813-511-11-203	1.000	1.0718K
					ST37.2
ŝ	Schaltbolzen	76975	4-95813-512-11-203	2,0000	1.0037K
				4 0000	ST37.2
9	Schaltblech	1/128	4-85813-516-11-203	0000.1	1.0037K
					ST37.2
2	Schattblech	77130	4-95813-517-11-203	1.000	1.0037K
				00000	X12CRNI177
ø	Rückstellfeder	66327	4-95806-506-05-203	2.0000	1.4310
6	Schelle	76976	7-066-SM 112 A PP-IS	2.0000	
9	Näherungsinitiator	97945	7-119-IMG 12 BBDIX-35049	2.0000	
				6 0000 8	X10CRNIS18 9
1	SCHEIBE	29019	DIN 125-A 8,4-AZ	0.000	1.4305
Die Z	Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte	sr Mitteilung a	an dritte Personen ist daher strafbar und wird geri	ichtlich verfo	Personen ist daher strafbar und wird gerichtlich verfolgt.(Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb,
BGB)	BGB). Alle Rechte für den Fall der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.	1-Eintragung	(§5 Abs.4 GMG) vorbehalten.		

BGB). Alle Rechte für den Fall der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.

				Sachnummer: 76979		Seite: 1/2
				Bestellnummer.		24.01.2007
 1.2007		Name	GNeschen	GNeschen	AHeinemann	
Ausf.: B vom 24.01.2007	A200481	Datum	24.01.2007	24.01.2007	24.01.2007	
Aust			Ersterst.	Geschr.	Geprüft.	
	_		\bigcirc	walther oräzision		

Pos.	Benennung	Identnr.	Zeichnungsnr.	Stueck	Stueck Werkstoff/Werkstoffnr. Bemerkung	
				0000	X10CRNIS18 9	
12	SECHSKANTSCHRAUBE	19977	DIN 933-M 8 X 20-A2-70	4.000	1.4305	
				00000	X10CRNIS18 9	
13	SECHSKANTMUTTER	3768	DIN 934-M 8 X -A2-70	7.0000	1.4305	
				0000	X10CRNIS18 9	
44	ZYLINDERSCHRAUBE	943	DIN 912-M 6X X 20-A2-70	4.0000	1.4305	
					X10CRNIS18 9	
15	ZYLINDERSCHRAUBE	3554	DIN 7984-M 6X 35-A2-70	2.0000	1.4305	
					X10CRNIS189	
16	ZYLINDERSCHRAUBE	1347	DIN 7984-M 5X 10-A2-70	4,0000	1.4305	


Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte Personen ist daher strafbar und wird gerichtlich verfolgt. (Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb, BGB), Alle Rechte für den Fall der Patenterteitung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.

					Sachnummer. 76979		24.01.2007 Seite: 2/2
	2007		Name	GNeschen	GNeschen Bestellnummer:	AHeinemann	
217	Ausf.: B vom 24.01.2007	A200481	Datum	24.01.2007	24.01.2007	24.01.2007	-
	Ausf.			Ersterst.	Geschr.	Geprüft.	
					walther		



Drawings and parts lists

12.7 <u>1-95813-B-00006-AAAA-Z03</u> Security module (parking station)



Pos.	Benennung	ldentnr.	Zeichnungsnr.	Stueck	Werkstoff/Werkstoffnr. Bemerkung
<u> </u>	Befestigungswinkel	76981	4-95813-515-11-203	1.0000	St37-2 1.0037K
2	Haltewinkel	76980	4-95813-514-11-Z03	1.0000	St37-2 1.0037K
3	Schatthocken	72311	4-95813-591-11-Z01	1.0000	ST37.2 1.0037K
4	SCHEIBE	29019	DIN 125-A 8,4-A2	2.0000	X10CRNIS18 9 1.4305
5	SECHSKANTSCHRAUBE	19977	DIN 933-M 8 X 20-A2-70	2.0000	X10CRNIS18 9 1.4305
و	SCHEIBE	4398	DIN 125-A 6,4-A2	6.0000	X10CRNIS18 9 1.4305
~	SECHSKANTSCHRAUBE	3429	DIN 933-M 6 X 12-A2-70	3.0000	X10CRNIS18 9 1.4305
ß	SECHSKANTSCHRAUBE	61952	DIN 933-M 6 X 16-A2-70	3.0000	X10CRNIS18 9 1.4305

Sachnummer: 76982 BGB). Alle Rechte für den Fall der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten. SICHERHEITSMODUL (ABLAGE) 1-95813-B-00006-AAAA-Z03 **Bestellnummer:** AHeinemann GNeschen GNeschen Name B vom 24.01.2007 A200481 24.01.2007 24.01.2007 24.01.2007 Datum Ausf.: Geprüft. Ersterst. Geschr. walther präzision Ð

Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte Personen ist daher strafbar und wird gerichtlich verfolgt. (Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb,


24.01.2007

Seite: 1/1



Drawings and parts lists

12.8 <u>1-95813-B-00016-AAAA-Z03</u> Inscription



Pos.	Benennung	ldentnr.	ldentnr. Zeichnungsnr.	Stueck	Werkstoff/Werkstoffnr. Bemerkung	nerkung
					ST37.2	
01	Beschriftungsblech	83822	4-95813-520-11-203	1.0000	1.0037K	
02	Kennzeichnungsschild	47947	7-137-7723-ELOX	14.0000 AL	AL	
80	Kennzeichnungsschild	83781	7-137-7723-Z1	1.0000	AL	
8		83823	DIN 1476 3 X 6	14.0000	CTAHI	
۶ C	NENDINAGEL					
			DIN 033 M 6 V 13 A2-Z0	2 0000	X10CRNIS189	
10	SECHSKANTSCHRAUBE	0423		2222	1.4305	

Die Zeichnung ist unser Eigentum. Jede Vervielfältigung, Verwertung oder Mitteilung an dritte Personen ist daher strafbar und wird gerichtlich verfolgt. (Urheberrechtsgesetz, Gesetz gegen unlauteren Wettbewerb, BGB). Alle Rechte für den Fall der Patenterteilung(§7 Abs.1 PG) oder GM-Eintragung (§5 Abs.4 GMG) vorbehalten.

						Seite: 1/1
				Bestellnummer: 1 05913 B 00016 A A A 703		24.01.2007 Se
01.2007		Name	GNeschen	GNeschen	AHeinemann	
Ausf.: B vom 24.01.2007	A200481	Datum	24.01.2007	24.01.2007	24.01.2007	
Aust			Ersterst.	Geschr.	Geprüft.	
				walther oräzision		



Index

13 <u>Index</u>

A

according	5
Acquired knowledge	
Air pressure connection	
Aktor sensor box	
Alterations	4
anchored	7, 9
Apperture angle of protection cover	
applications	7

С

center of gravity	11
check	. 12, 13
commissioning	12
Commissioning	
contaminations	
coupling	4, 5
Customer care	2

D

damage	5
Damage	
Damage compensation	
Danger references	
dangerous spreading	
disconnection	
dismounting	
Drill picture	
Ł	

Ε

Equipment	. 4
Experience	. 4

F

Faults	
first use	
functional	
functional test	
Functionality	
~	

G

General safety instructions	. 12, 13
guarantee	5
Н	
Height of parking station	8

Ι

Improvement	4
individual particles	5
Inhaltsverzeichnis	
Inspection	2
installation package electro	
installation package pneumatic	
Interbus module	8, 10

L

level adjustment	7,	8,	9
Liability			4

М

Main dimensions	7
maintenance	
Maintenance	2, 4, 5
Manual	
mass center	11
Maximum load	7
medium	5
mounting	5

0

observed	5
operating instruction	5
Operation	2
operator	
Operators	
orderly	5
orderly operation	
original	4

Р

Performance capability2
plan protective measures
plastic plate
pressurized 5
Property
protection cover7, 11, 12, 13
protection cover (hinged cover)7
Q
questions
R

readable form



Index

realization	5
receptacles	11
Regulations	
relevant industrial safety regulations	5
Reliability	
removed	
repair	5
result	
a.	
S	

Safety	2
safety devices	
safety instructions	
safety module	7
Scope of delivery	
screwed	
screw-type connections	
Service	
Sicherheitshinweise	
Special designs	4
Specialists	
specification	
stand	
Status of development	
support	
T T	, , , -

Support distance	7
Systems	2
Т	
Technical equipment	2
Tool clearance	7
tool geometry	7
tool identification	7
tool parking station	. 7, 11, 13
tool strong shock	11
Tools	2
torque	8
Translation errors	4
U	
usage	5
Use	
V	
Version	
W	
working area wrong product selection	