

# NX100

# MAINTENANCE MANUAL

---

Upon receipt of the product and prior to initial operation, read these instructions thoroughly, and retain for future reference.

---

## MOTOMAN INSTRUCTIONS

MOTOMAN-□□□ INSTRUCTIONS

NX100 INSTRUCTIONS

NX100 OPERATOR'S MANUAL

NX100 MAINTENANCE MANUAL

The NX100 operator's manuals above correspond to specific usage.  
Be sure to use the appropriate manual.



## MANDATORY

- This manual explains maintenance procedures of the NX100 system. Read this manual carefully and be sure to understand its contents before handling the NX100.
- General items related to safety are listed in Section 1: Safety of the NX100 Instructions. To ensure correct and safe operation, carefully read the NX100 Instructions before reading this manual.



## CAUTION

- Some drawings in this manual are shown with the protective covers or shields removed for clarity. Be sure all covers and shields are replaced before operating this product.
- The drawings and photos in this manual are representative examples and differences may exist between them and the delivered product.
- YASKAWA may modify this model without notice when necessary due to product improvements, modifications, or changes in specifications. If such modification is made, the manual number will also be revised.
- If your copy of the manual is damaged or lost, contact a YASKAWA representative to order a new copy. The representatives are listed on the back cover. Be sure to tell the representative the manual number listed on the front cover.
- YASKAWA is not responsible for incidents arising from unauthorized modification of its products. Unauthorized modification voids your product's warranty.

---

## Notes for Safe Operation

Read this manual carefully before maintenance or inspection of the NX100.

In this manual, the Notes for Safe Operation are classified as "WARNING," "CAUTION," "MANDATORY," or "PROHIBITED."



### WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury to personnel.



### CAUTION

Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury to personnel and damage to equipment. It may also be used to alert against unsafe practices.



### MANDATORY

Always be sure to follow explicitly the items listed under this heading.



### PROHIBITED

Must never be performed.

Even items described as "CAUTION" may result in a serious accident in some situations. At any rate, be sure to follow these important items.



#### NOTE

To ensure safe and efficient operation at all times, be sure to follow all instructions, even if not designated as "CAUTION" and "WARNING."



## WARNING

- Before maintenance, inspection, and wiring, check that servo power is turned OFF when the emergency stop buttons on the front door of the NX100 and programming pendant are pressed. When the servo power is turned OFF, the SERVO ON LED on the programming pendant is turned OFF.

Injury or damage to machinery may result if the emergency stop circuit cannot stop the manipulator during an emergency. The manipulator should not be used if the emergency stop buttons do not function.



Emergency Stop Button

- Once the emergency stop button is released, clear the cell of all items which could interfere with the operation of the manipulator. Then turn the servo power ON.

Injury may result from unintentional or unexpected manipulator motion.



Release of Emergency Stop

- Observe the following precautions when performing teaching operations within the P-point maximum envelope of the manipulator :
  - View the manipulator from the front whenever possible.
  - Always follow the predetermined operating procedure.
  - Ensure that you have a safe place to retreat in case of emergency.

Improper or unintended manipulator operation may result in injury.

- Confirm that no persons are present in the P-point maximum envelope of the manipulator and that you are in a safe location before:
  - Turning ON the NX100 power
  - Moving the manipulator with the programming pendant
  - Running the system in the check mode
  - Performing automatic operations

Injury may result if anyone enters the P-point maximum envelope of the manipulator during operation. Always press an emergency stop button immediately if there are problems. The emergency stop buttons are located on the right of the front door of the NX100 and the programming pendant.



## CAUTION

- Perform the following inspection procedures prior to conducting manipulator teaching. If problems are found, repair them immediately, and be sure that all other necessary processing has been performed.
  - Check for problems in manipulator movement.
  - Check for damage to insulation and sheathing of external wires.

- Always return the programming pendant to the hook on the NX100 cabinet after use.

The programming pendant can be damaged if it is left in the P-point maximum envelope of the manipulator, on the floor, or near fixtures.

- Read and understand the Explanation of Warning Labels in the NX100 Instructions before operating the manipulator.

## Definition of Terms Used Often in This Manual

The MOTOMAN manipulator is the YASKAWA industrial robot product.


The manipulator usually consists of the controller, the programming pendant, and supply cables.

In this manual, the equipment is designated as follows.

Equipment	Manual Designation
NX100 Controller	NX100
NX100 Programming Pendant	Programming Pendant
Cable between the manipulator and the controller	Manipulator cable

---

Descriptions of the programming pendant keys, buttons, and displays are shown as follows:

Equipment		Manual Designation
Programming Pendant	Character Keys	The keys which have characters printed on them are denoted with [ ]. ex. [ENTER]
	Symbol Keys	The keys which have a symbol printed on them are not denoted with [ ] but depicted with a small picture. ex. page key  The cursor key is an exception, and a picture is not shown.
	Axis Keys Numeric Keys	"Axis Keys" and "Numeric Keys" are generic names for the keys for axis operation and number input.
	Keys pressed simultaneously	When two keys are to be pressed simultaneously, the keys are shown with a "+" sign between them, ex. [SHIFT]+[COORD]
	Displays	The menu displayed in the programming pendant is denoted with { }. ex. {JOB}

## Description of the Operation Procedure

In the explanation of the operation procedure, the expression "Select •••" means that the cursor is moved to the object item and the SELECT key is pressed, or that the item is directly selected by touching the screen.

---

# 1 Equipment Configuration

1.1 Arrangement of Units and Circuit Boards .....	1-1
1.2 Power Flow.....	1-3
1.3 Signal Flow.....	1-4

# 2 Security System

2.1 Protection Through Security Mode Settings .....	2-1
2.1.1 Security Mode .....	2-1
■ Changing the Security Mode .....	2-6
2.1.2 User ID .....	2-8
■ Changing a User ID .....	2-8

# 3 Inspections

3.1 Regular Inspections .....	3-1
3.2 NX100 Inspections .....	3-2
3.2.1 Checking if the Doors are Firmly Closed .....	3-2
3.2.2 Checking for Gaps or Damage in the Sealed Construction Section .....	3-2
3.3 Cooling Fan Inspections .....	3-3
3.4 Emergency Stop Button Inspections .....	3-5
3.5 Enable Switch Inspections .....	3-5
3.6 Battery Inspections .....	3-6
3.7 Power Supply Voltage Confirmation .....	3-6
3.8 Open Phase Check .....	3-7

# 4 Preparation before Replacing Parts

4.1 Creating a Check Program .....	4-3
------------------------------------	-----

# 5 Replacing Parts

5.1 Replacing NX100 Parts .....	5-1
5.1.1 Replacing Parts of the CPU Unit .....	5-2
■ Replacing the Battery .....	5-3
■ Replacing the Control Circuit Board (JANCD-NCP01) .....	5-3
■ Replacing the Control Power Supply (CPS-420F) .....	5-4

■ Replacing the Servo Control Circuit Board (SGDR-AXA01A) .....	5-5
■ Replacing the Robot I/F Unit (JZNC-NIF01□) .....	5-6
■ Replacing the Robot I/F Circuit Board (JANCD-NIF01) .....	5-8
■ Replacing the I/O Circuit Board (JANCD-NIO01□) .....	5-9
5.1.2 Replacing the SERVOPACK .....	5-10
5.1.3 Checking and Replacing Fuses .....	5-13
■ Power Supply Contactor Unit .....	5-13
■ Robot I/F Unit .....	5-14
5.2 NX100 Parts List .....	5-15
5.3 Supplied Parts List .....	5-18
5.4 Recommended Spare Parts .....	5-18

## 6 Operations after Replacing Parts

6.1 Home Position Calibration .....	6-2
6.1.1 Home Position Calibration .....	6-2
6.1.2 Calibrating Operation .....	6-3
■ Registering All Axes at One Time .....	6-3
■ Registering Individual Axes .....	6-6
■ Changing the Absolute Data .....	6-7
■ Clearing Absolute Data .....	6-8
6.1.3 Manipulator Home Position .....	6-9
6.2 Position Deviation Check Using the Check Program .....	6-10
6.3 Home Position Data Correction .....	6-11
6.4 Setting the Second Home Position (Check Point) ..	6-12
6.4.1 Purpose of Position Check Operation .....	6-14
6.4.2 Procedure for the Second Home Position Setting (Check Point) .....	6-16
6.4.3 Procedure after the Alarm .....	6-17

## 7 System Diagnosis

7.1 System Version .....	7-1
7.2 Manipulator Model .....	7-2
7.3 Input/Output Status .....	7-3
7.3.1 Universal Input .....	7-3
■ Universal Input Window .....	7-3
■ Universal Input Simple Window .....	7-3
7.3.2 Universal Output .....	7-4
■ Universal Output Window .....	7-4
■ Universal Output Simple Window .....	7-4



---

---

■	Modifying the Output Status .....	7-5
7.3.3	Specific Input .....	7-6
■	Specific Input Window .....	7-6
■	Specific Input Simple Window .....	7-6
7.3.4	Specific Output .....	7-7
■	Specific Output Window .....	7-7
■	Specific Output Simple Window .....	7-7
7.3.5	RIN Input .....	7-8
■	RIN Input Window .....	7-8
7.3.6	Signal Number Search .....	7-9
■	Direct Search on the Universal/Specified Input/Output Window .....	7-10
■	Search from the Menu .....	7-11
7.3.7	Relay Number Search .....	7-12
■	Direct Search on the Universal/Specified Input/Output Window .....	7-13
■	Search from the Menu .....	7-14
7.3.8	Modification of the Signal Name .....	7-15
■	Direct Modification on the Universal/Specified Input/Output Window .....	7-15
■	Modification from the Menu .....	7-16
7.4	System Monitoring Time Display .....	7-17
7.4.1	System Monitoring Time Display Window .....	7-17
7.4.2	Individual Window of the System Monitoring Time Display .....	7-18
7.4.3	Clearing the System Monitoring Time Display .....	7-19
7.5	Alarm History .....	7-20
7.5.1	Alarm History Window .....	7-20
7.5.2	Clearing the Alarm History .....	7-21
7.6	I/O Message History .....	7-22
7.6.1	I/O Message History Window .....	7-22
■	Search .....	7-22
7.6.2	Clearing the I/O Message History .....	7-23
7.7	Position Data When Power is Turned ON/OFF .....	7-24
7.7.1	Power ON/OFF Position Window .....	7-24
7.8	Current Position .....	7-25
7.8.1	Current Position Window .....	7-25
7.9	Servo Monitoring .....	7-26
7.9.1	Servo Monitor Window .....	7-26
7.9.2	Changing the Monitor Items .....	7-27
7.9.3	Clearing Maximum Torque Data .....	7-28

---

## 8 Alarm

8.1 Outline of Alarm .....	8-1
8.2 Alarm Display .....	8-2
8.2.1 Displaying and Releasing Alarm .....	8-2
■ Releasing Alarms .....	8-2
8.2.2 Special Alarm Display .....	8-3
■ Sub Data .....	8-3
■ Multiple SERVOPACK System .....	8-3
■ Independent Control Function (Optional) .....	8-4
8.3 Alarm Message List .....	8-5

## 9 Error

9.1 Error Message List .....	9-1
9.1.1 System and General Operation .....	9-2
9.1.2 Editing .....	9-5
9.1.3 Job Defined Data .....	9-5
9.1.4 External Memory Equipment .....	9-9
9.1.5 Concurrent I/O .....	9-15
9.1.6 Maintenance Mode .....	9-16

## 10 LED Indicator on Circuit Board

10.1 LED Indicator on NCP 01 Circuit Board .....	10-1
10.2 LED Indicator on Robot I/F Unit .....	10-2
10.3 7 SEG-LED Indicator .....	10-3
■ 7 SEG-LED Indicator Status (1-digit indication) of Each Unit at Error Occurrence .....	10-4
■ 7 SEG-LED Indicator Status (4 digit-indication) of Each Unit at Error Occurrence .....	10-6


# 1 Equipment Configuration

The NX100 is comprised of individual units and modules (circuit boards). Malfunctioning components can generally be easily repaired after a failure by replacing a unit or a module. This section explains the configuration of the NX100 equipment.

## 1.1 Arrangement of Units and Circuit Boards

The arrangements of units and circuit boards in small-capacity, medium-capacity, and large-capacity NX100s are shown.


### Small Capacity



Model Type	NX100	SERVOPACK (Converter Integrated)	Breaker	Power Supply Contactor Unit
HP3	ERCR-HP3-AA00	SGDR-EA1400NY26	NF30SW 3P 5A	JZRRCR-NTU01□-1
EA1400N	ERCR-EA1400N-AA00	SGDR-EA1400N	NF30SW 3P 10A	
HP6				

Configuration 1 for Small-Capacity NX100


## 1.1 Arrangement of Units and Circuit Boards



Model Type	NX100	SERVOPACK	Converter	Breaker	Power Supply Contactor Unit
HP20	ERCR-HP20-AA00	SGDR-HP20Y30	SGDR-COA080A01B	NF30SW 3P 15A	JZRCR-NTU01□-1
EA1900N					

Configuration 2 for Small-Capacity NX100


## Medium or Large Capacity



Model Type	NX100	SERVOPACK	Converter	Breaker	Power Supply Contactor Unit
UP20MN	ERCR-UP20MN-AA00	SGDR-EH50Y27	SGDR-COA250A01B	NF30SW 3P 20A	JZRCR-NTU02□-1
UP50N	ERCR-UP50N-AA00	SGDR-EH50Y24			
ES165N	ERCR-ES165N-AA00	SGDR-ES165N		NF30SW 3P 30A	
HP165					
ES200N	ERCR-ES200N-AA00	SGDR-ES165NY28			
ES165RN	ERCR-ES165RN-AA00				
ES200RN	ERCR-ES200RN-AA00				

Configuration for Medium- or Large-Capacity NX100

## 1.2 Power Flow





## 2 Security System

### 2.1 Protection Through Security Mode Settings

The NX100 modes setting are protected by a security system. The system allows operation and modification of settings according to operator clearance. Be sure operators have the correct level of training for each level to which they are granted access.

#### 2.1.1 Security Mode

There are three security modes. Editing mode and management mode require a user ID. The user ID consists of numbers and letters, and contains no less than 4 and no more than 8 characters. (Significant numbers and signs: "0 to 9", "-", ".".

Security Mode Descriptions

Security Mode	Explanation
Operation Mode	This mode allows basic operation of the robot (stopping, starting, etc.) for people operating the robot work on the line.
Editing Mode	This mode allows the operator to teach and edit jobs and robot settings.
Management Mode	This mode allows those authorized to set up and maintain robot system: parameters, system time and modifying user IDs.

## 2.1 Protection Through Security Mode Settings

Menu & Security Mode			
Main Menu	Sub Menu	Allowed Security Mode	
		DISPLAY	EDIT
JOB	JOB	Operation	Edit
	SELECT JOB	Operation	Operation
	CREATE NEW JOB <sup>*1</sup>	Edit	Edit
	MASTER JOB	Operation	Edit
	JOB CAPACITY	Operation	-
	RES. START (JOB) <sup>*1</sup>	Edit	Edit
	RES. STATUS <sup>*2</sup>	Operation	-
	CYCLE	Operation	Operation
VARIABLE	BYTE	Operation	Edit
	INTEGER	Operation	Edit
	DOUBLE	Operation	Edit
	REAL	Operation	Edit
	STRING	Operation	Edit
	POSITION (ROBOT)	Operation	Edit
	POSITION (BASE)	Operation	Edit
	POSITION (ST)	Operation	Edit
	LOCAL VARIABLE	Operation	-
IN/OUT	EXTERNAL INPUT	Operation	-
	EXTERNAL OUTPUT	Operation	-
	UNIVERSAL INPUT	Operation	-
	UNIVERSAL OUTPUT	Operation	-
	SPECIFIC INPUT	Edit	-
	SPECIFIC OUTPUT	Edit	-
	RIN	Edit	-
	CPRIN	Operation	-
	REGISTER	Edit	-
	AUXILIARY RELAY	Edit	-
	CONTROL INPUT	Edit	-
	PSEUDO INPUT SIG	Edit	Management
	NETWORK INPUT	Edit	-
	NETWORK OUTPUT	Operation	-
	ANALOG OUTPUT	Edit	-
	SV POWER STATUS	Edit	-
	LADDER PROGRAM	Management	Management
	I/O ALARM	Management	Management
	I/O MESSAGE	Management	Management

<sup>\*1</sup> Teach mode only

<sup>\*2</sup> Play mode only



Menu & Security Mode			
Main Menu	Sub Menu	Allowed Security Mode	
		DISPLAY	EDIT
ROBOT	CURRENT POSITION	Operation	-
	COMMAND POSITION	Operation	-
	SERVO MONITOR	Management	-
	WORK HOME POS	Operation	Edit
	SECOND HOME POS	Operation	Edit
	DROP AMOUNT	Management	Management
	POWER ON/OFF POS	Operation	-
	TOOL	Edit	Edit
	INTERFERENCE	Management	Management
	SHOCK SENS LEVEL	Operation	Management
	USER COORDINATE	Edit	Edit
	HOME POSITION	Management	Management
	MANIPULATOR TYPE	Management	-
	ROBOT CALIBRATION	Edit	Edit
	ANALOG MONITOR	Management	Management
	OVERRUN&S-SENSOR <sup>*1</sup>	Edit	Edit
	LIMIT RELEASE <sup>*1</sup>	Edit	Management
	ARM CONTROL <sup>*1</sup>	Management	Management
	SHIFT VALUE	Operation	-
SYSTEM INFO	VERSION	Operation	-
	MONITORING TIME	Operation	Management
	ALARM HISTORY	Operation	Management
	I/O MSG HISTORY	Operation	Management
	SECURITY	Operation	Operation
FD/CF	LOAD	Edit	-
	SAVE	Operation	-
	VERIFY	Operation	-
	DELETE	Operation	-
	DEVICE	Operation	Operation
	FOLDER	Edit	Management

<sup>\*1</sup> Teach mode only

## 2.1 Protection Through Security Mode Settings




Menu & Security Mode			
Main Menu	Sub Menu	Allowed Security Mode	
		DISPLAY	EDIT
PARAMETER	S1CxG	Management	Management
	S2C	Management	Management
	S3C	Management	Management
	S4C	Management	Management
	A1P	Management	Management
	A2P	Management	Management
	A3P	Management	Management
	A4P	Management	Management
	RS	Management	Management
	S1E	Management	Management
	S2E	Management	Management
	S3E	Management	Management
	S4E	Management	Management
SETUP	TEACHING COND	Edit	Edit
	OPERATE COND	Management	Management
	DATE/TIME	Management	Management
	GRP COMBINATION	Management	Management
	RESERVE JOB NAME	Edit	Edit
	USER ID	Edit	Edit
	SET SPEED	Management	Management
	KEY ALLOCATION <sup>*1</sup>	Management	Management
	RES. START (CNCT)	Management	Management
ARC WELDING	ARC START COND.	Operation	Edit
	ARC END COND.	Operation	Edit
	ARC AUX COND.	Operation	Edit
	POWER SOURCE COND.	Operation	Edit
	ARC WELD DIAG.	Operation	Edit
	WEAVING	Operation	Edit
HANDLING	HANDLING DIAGNOSIS	Operation	Edit
SPOT WELDING	WELD DIAGNOSIS	Operation	Edit
	I/O ALLOCATION	Management	Management
	GUN CONDITION	Management	Management
	POWER SOURCE COND	Management	Management


<sup>\*1</sup> Teach mode only

Menu &amp; Security Mode

Main Menu	Sub Menu	Allowed Security Mode	
		DISPLAY	EDIT
SPOT WELDING (MOTOR GUN)	WELD DIAGNOSIS	Operation	Edit
	GUN PRESSURE	Edit	Edit
	PRESSURE	Edit	Edit
	I/O ALLOCATION	Management	Management
	GUN CONDITION	Management	Management
	CLEARANCE SETTING	Operation	Management
	POWER SOURCE COND.	Management	Management
GENERAL	WEAVING	Operation	Edit
	GENERAL DIAG.	Operation	Edit
COMMON TO ALL APPLI- CATIONS	I/O VARIABLE CUSTOMIZE	Operation	Operation

■ Changing the Security Mode

	Operation	Explanation
1	Select {SYSTEM INFO} under the main menu.	<p>The sub menu appears.</p>  <p>Note: Icons for the main menu such as arc welding system differ depending on the system being used.</p>
2	Select {SECURITY}.	<p>The selection window of security mode appears.</p> 
3	Press [SELECT] and select "SECURITY MODE."	



	Operation	Explanation
4	Input the user ID.	<p>The user ID input window appears.</p>  <p>At the factory, the following below user ID number is preset.</p> <ul style="list-style-type: none"><li>• Editing Mode:[00000000]</li><li>• Management Mode:[99999999]</li></ul>
5	Press [ENTER].	<p>The input user ID is compared with the user ID of the selected security mode. When the correct user ID is entered, the security mode is changed.</p>



## 2.1.2 User ID

User ID is requested when Editing Mode or Management Mode is operated.  
User ID must be between 4 characters and 8, and they must be numbers and symbols (“0 to 9”, “-” and “.”).

### ■ Changing a User ID

In order to change the user ID, the NX100 must be in Editing Mode or Management Mode.  
Higher security modes can make changes the user ID of to lower security modes.

	Operation	Explanation
1	Select {SETUP} under the main menu.	<p>The sub menu appears.</p>  <p>The screenshot shows the main menu of the NX100 interface. At the top, there are tabs for DATA, EDIT, DISPLAY, and UTILITY. Below these are various function buttons: JOB, FD/CF, ARC WELDING, PARAMETER, VARIABLE [B001], SETUP (highlighted in blue), IN/OUT, DISPLAY SETUP, ROBOT, and SYSTEM INFO. On the right side, there are additional options: TEACHING COND, KEY ALLOCATION, OPERATE COND, DATE/TIME, GRP COMBINATION, RESERVE JOB NAME, USER ID, and SET SPEED. At the bottom, there are buttons for Main Menu and Short Cut.</p>
2	Select {USER ID}.	<p>The USER ID window appears.</p>  <p>The screenshot shows the USER ID window. It has a title bar that says 'USER ID'. Inside, there are two sections: 'EDITING MODE' with a field containing '*****' and 'MANAGEMENT MODE' with a field containing '*****'. At the bottom, there are four empty input fields. The background shows the same main menu as in the previous screenshot, but the 'SETUP' button is no longer highlighted.</p>

	Operation	Explanation
3	Select the desired ID.	<p>The character input line appears, and the message "Input current ID no. (4 to 8 digits)" is shown.</p>  <p>The screenshot shows a control panel interface. At the top are tabs: DATA, EDIT, DISPLAY, and UTILITY. Below these are various function buttons: JOB, FD/CF, ARC WELDING, PARAMETER, VARIABLE (B001), SETUP, IN/OUT, DISPLAY SETUP, ROBOT, and SYSTEM INFO. On the right, the 'USER ID' screen is active, showing 'EDITING MODE' with a 'Password=' field and 'MANAGEMENT MODE' with a field of asterisks. At the bottom, a status bar indicates 'Main Menu', 'Short Cut', and 'Input current ID no. (4 to 8 digits)'.</p>
4	Input current ID and press [ENTER].	<p>When the correct user ID is entered, a new ID is requested to be input. "Input new ID no.(4 to 8 digits)" appears.</p>  <p>This screenshot is identical to the previous one, showing the same control panel interface. The status bar at the bottom now indicates 'Input new ID no. (4 to 8 digits)', reflecting the change in the security mode after the first ID is entered.</p>
5	Input new ID and press [ENTER].	<p>User ID is changed.</p>

## 3 Inspections

### 3.1 Regular Inspections



#### CAUTION

- Do not touch the cooling fan or other equipment while the power is turned ON.

Failure to observe this caution may result in electric shock or injury.

Carry out the following inspections.

Inspection Equipment	Inspection Item	Inspection Frequency	Comments
NX100 Controller	Check that the doors are completely closed.	Daily	
	Check for gaps or damage to the sealed construction.	Monthly	
Interior circulation fan and backside duct fan	Check operation	As required	While power ON
Emergency stop button	Check operation	As required	While servo ON
Enable switch	Check operation	As required	In teach mode
Battery	Confirm battery alarm or message is displayed or not	As required	




---

## 3.2 NX100 Inspections

### 3.2.1 Checking if the Doors are Firmly Closed

- The NX100 has a fully sealed construction, designed to keep external air containing oil mist out of the NX100.  
Be sure to keep the NX100 doors fully closed at all times, even when the controller is not operating.
- Open or close the two locks in each door with the screwdriver when opening or closing the doors for maintenance after the main power is turned OFF. (CW: Open, CCW: Close)  
Make sure push the door closed and turn the door lock with the driver. When the door is closed, turn the door lock until the door clicks.



NX100 Front View

### 3.2.2 Checking for Gaps or Damage in the Sealed Construction Section

- Open the door and check that the seal around the door is undamaged.
- Check that the inside of the NX100 is not excessively dirty. If it is dirty, determine the cause, take measures to correct the problem and immediately clean up the dirt.
- Fully close each door lock and check that no excessive gaps exist around the edge of the door.

## 3.3 Cooling Fan Inspections

Inspect the cooling fans as required. A defective fan can cause the NX100 to malfunction because of excessive high temperatures inside.


The interior circulation fan and backside duct fan normally operate while the power is turned ON. Check if the fans are operating correctly by visual inspection and by feeling air moving into the air inlet and from the outlet.

#### NOTE


When the message of the "Cooling fan in control box stopped" is displayed, it may be caused by the error occurrence at the cooling fan (JZNC-NZU01) inside the control power supply (CPS-420F) of the CPU unit.

The playback operation (execution of the JOB) cannot be performed when the error occurs at the cooling fan. In this case, the alarm 4119 "FAN ERROR (IN CONTROL BOX)" occurs 10 hours later.

When the message of the "Cooling fan in control box stopped" is displayed, carry out an inspection and the replacement of the cooling fan on the CPU rack as soon as possible.



Cooling Fan Construction (Small-capacity NX100)



Cooling Fan Construction (Medium- or large-capacity NX100)

## 3.4 Emergency Stop Button Inspections

The emergency stop buttons are located on both the front door of the NX100 and the programming pendant. Confirm the servo power is OFF by pressing the emergency stop button on the the front door of the NX100 after the servo ON, before the manipulator is operated.


## 3.5 Enable Switch Inspections

The programing pendant is equipped with a three-position enable switch. Perform the following operation to confirm the enable switch operates.

1. Set the mode switch on the programming pendant to "TEACH."



2. Press [SERVO ON READY] on the programming pendant. The [SERVO ON] lamp blinks.



3. When the enable switch is grasped lightly, the servo power is turned ON.  
When the enable switch is grasped firmly or released, the servo power is turned OFF.

### NOTE

If the [SERVO ON] lamp does not light in previous operation (2), check the following:

- The emergency stop button on the front door of the NX100 is pressed.
- The emergency stop button on the programming pendant is pressed.
- The emergency stop signal is input from external.

If the servo is not turned ON in a previous operation (3), check the following:

- The overrun LS is operating.
- If a major alarm is occurring.

## 3.6 Battery Inspections

The NX100 has a battery that backs up the important program files for user data in the CMOS memory.

A battery alarm indicates when a battery has expired and must be replaced. The programming pendant display and the message "Memory battery weak" appears at the bottom of the display.


The way to replace the battery is described in "5.1.1 Replacing Parts of the CPU Unit."

## 3.7 Power Supply Voltage Confirmation

Check the voltage of 1, 3, 5 terminal of the circuit breaker (QF1) with an electric tester.

Power Supply Voltage Confirmation

Measuring Items	Terminals	Correct Value
Correlate voltage	Between 1 and 3, 3 and 5, 5 and 1	200 to 220V (+10%, -15%)
Voltage between earth (phase-S ground)	Between 1 and E, 5 and E	200 to 220V (+10%, -15%)
	Between 3 and E	About 0V




Circuit Breaker (QF1)

## 3.8 Open Phase Check

Open Phase Check List

Check Item	Contents
Lead Cable Check	Confirm if the lead cable for the power supply is wired as shown in the following. If the wiring is wrong or broken, repair it.
Input Power Supply Check	Check the open phase voltage of input power supply with an electric tester. (Normal value: 200-220VAC (+10%, -15%))
Circuit Breaker (QF1) Check	Turn ON the breaker and check the open phase voltage of "2, 4, 6" of the circuit breaker (QF1) with an electric tester. If abnormal, replace the circuit breaker (QF1).



---

## 4 Preparation before Replacing Parts

---



### WARNING

- Before operating the manipulator, check that the SERVO ON lamp turns OFF when the emergency stop buttons on the front door of the NX100 and the programming pendant are pressed.

Injury or damage to machinery may result if the manipulator cannot be stopped in case of an emergency.

- Observe the following precautions when performing teaching operations within the P-point maximum envelope of the manipulator :
  - View the manipulator from the front whenever possible.
  - Always follow the predetermined operating procedure.
  - Ensure that you have a safe place to retreat in case of emergency.

Improper or unintended manipulator operation may result in injury.

- Confirm that no persons are present in the P-point maximum envelope of the manipulator and that you are in a safe location before:
  - Turning ON the NX100 power.
  - Moving the manipulator with the programming pendant

Injury may result if anyone enters the P-point maximum envelope of the manipulator during operation.

- Always press the emergency stop button immediately if there are problems.

Emergency stop buttons are located at the upper right corner of the front door of the NX100 and on the upper right of the programming pendant.




## CAUTION

- Perform the following inspection procedures prior to conducting manipulator teaching. If problems are found, repair them immediately, and be sure that all other necessary processing has been performed.
  - Check for problems in manipulator movement.
  - Check for damage to insulation and sheathing of external wires.
- Always return the programming pendant to the hook on the NX100 cabinet after use.

The programming pendant can be damaged if it is left in the P-point maximum envelope of the manipulator, on the floor, or near fixtures.

The following flowchart shows the operations for replacing parts.



This chapter describes how to create a check program as a preparation for replacing parts. The check program is a program to check the position deviation. If positions are deviated, home position calibration is required. For the calibration, this program data is used to correct the home position data. In the following cases particularly, the home position calibration using the check program is needed. Be sure to create a check program referring to "4.1 Creating a Check Program."



- Change in the combination of the manipulator and NX100
- Replacement of the motor or absolute encoder
- Clearing stored memory (by replacement of NCP01 circuit board, weak battery, etc.)
- Home position deviation caused by hitting the manipulator against a workpiece, etc.



---

## 4.1 Creating a Check Program

To check position deviation whenever necessary, create a program in which a check point is taught (the job for the check point). In the job for the check point, teach two points; one as a check point and the other as the point to approach the check point. This program checks for any deviation between the tool tip position and the check point.



Enlarged View

## 5 Replacing Parts

### 5.1 Replacing NX100 Parts



#### WARNING

- Turn OFF the power supply before opening the NX100 doors.

Failure to observe this warning may result in electric shock.

- After turning OFF the power supply, wait at least 5 minutes before replacing a SREVOPACK (including the converter) or control power supply unit. Do not touch any terminals during this period.

Failure to observe this warning may result in electric shock.



#### CAUTION

- To prevent anyone inadvertently turning ON the power supply during maintenance, put up a warning sign such as "DO NOT TURN ON THE POWER" at the primary power supply (knife switch, wiring circuit breaker, etc.) and at the NX100 and related controllers and use accepted lockout/tagout procedures.

Failure to observe this caution may result in electric shock or injury.

- Do not touch the regeneration resistors. They are very hot.


Failure to observe this caution may result in burn injuries.

- After maintenance is completed, carefully check that no tools are left inside the NX100 and that the doors are securely closed.

Failure to observe this caution may result in electric shock or injury.

### 5.1.1 Replacing Parts of the CPU Unit

CPU unit (JZNC-NRK01) is comprised of the control power supply (CPS-420F), the rack for the various circuit boards, control circuit board (JANCD-NCP01), servo control circuit board (SGDR-AXA01A), and robot I/F unit (JZNC-NIF01□).



CPU Unit Configuration (JZNC-NRK01)

### ■ Replacing the Battery

Replace the battery immediately if a battery alarm occurs. Replace the battery within two hours after the breaker turns OFF.

(The battery alarms appear on the programming pendant display.)

#### Replacement Procedure

1. Remove the left cover of the CPU unit.
2. Remove the battery connector (BAT) on the back board on the left of the CPU unit.
3. Remove the battery from the rack frame.
4. Mount a new battery on the rack frame and connect the battery connector (BAT) on the back board.



Although the CMOS memory is backed up by super capacitor, the battery must be replaced as soon as the battery alarm occurs. The job data and other data may be lost if the battery alarm occurs and the breaker is turned OFF for more than 2 hours.

### ■ Replacing the Control Circuit Board (JANCD-NCP01)


Turn OFF the power before replacing a circuit board.



The JANCD-NCP01 circuit board contains important file data for the user programs, which is backed up by the battery. Incorrect operations can cause this stored file data to be lost.

#### Replacement Procedure

1. Disconnect all cables connected to the circuit board. (Be sure to remove the connectors at the bottom of the circuit board.)
2. Remove 2 screws fixing the circuit board and rack.
3. Pull out the circuit board from the rack.
4. Remove the Compact Flash from the removed circuit board and insert the Compact Flash into a new circuit board.
5. Mount the new circuit board to the rack.
6. Tighten upper and lower screws.
7. Connect all disconnected cables.



## ■ Replacing the Control Power Supply (CPS-420F)




### CAUTION

- After turning OFF the power supply, wait at least 5 minutes before replacing a control power supply. Do not touch any terminals during this period. Confirm all monitor lights are turned OFF.

Failure to observe this caution may result in electric shock or injury.

### Replacement Procedure

1. Disconnect all cables connected to the control power supply.
2. Loosen four upper and lower screws attaching the control power supply and the rack. (two screws on each side).
3. Pull out the control power supply from the rack holding the grips which are attached at the upper and lower side.
4. Insert the new control power supply into the slot of the rack.
5. Push the new control power supply until it is placed in the same position of other boards.
6. Tighten upper and lower screws.
7. Connect all disconnected cables.




## ■ Replacing the Servo Control Circuit Board (SGDR-AXA01A)

Turn OFF the power before replacing a servo control circuit board.

### Replacement Procedure

1. Disconnect all cables connected to the servo control circuit board. (Be sure to remove the connectors at the bottom of the board.)
2. Remove 2 screws fixing the servo control circuit board and rack.
3. Pull out the servo control circuit board from the rack.
4. Insert a new board into the slot of the rack.
5. Tighten upper and lower screws.
6. Connect all disconnected cables.
7. Set the rotary switch to the same value as the removed board's rotary switch.



## ■ Replacing the Robot I/F Unit (JZNC-NIF01□)

### NOTE

- Turn OFF the power before replacing the robot I/F unit (JZNC-NIF01□).
- Be sure to back up robot data before replacing the robot I/F unit since the robot I/F unit contains important data such as robot jobs and parameters.
- There are some versions which require maker mode operations after replacing the robot I/F unit.  
Contact your Yaskawa representative for maker mode operations.
- Before removing the robot I/F unit from the CPU rack temporarily, turn ON the system power and charge the onboard capacitor for one hour. The CMOS data on the robot I/F unit are kept temporarily by the onboard capacitor power. The capacitor is fully charged in one hour, and discharged in 16 hours when the I/F unit is removed from the CPU rack. If the capacitor is discharged, the CMOS data will be cleared and all the system settings and user settings will be lost.

### Replacement Procedure

1. Back up the robot data.
  - 1) Insert a CF card for backup to the programming pendant, and start the system in maintenance mode.
  - 2) Select {TOOL} ⇒ {CompactFlash} ⇒ "CMOS SAVE" to save the CMOS data.




For under NS1.8HA-00 versions, save all individual data in online mode. However, for all versions, all individual data must be saved for safe.

2. Turn OFF the power after making backup.
3. Disconnect all cables on the I/F unit.
4. Remove two screws fixing the robot I/F unit and rack.
5. Pull out the robot I/F unit from the rack.
6. Insert new robot I/F unit into the slot of the rack.
7. Tighten upper and lower screws of the robot I/F unit.
8. Connect all cables disconnected in the procedure 3.
9. Set the rotary switch as the same value as the original I/F unit.
10. Start the system in maintenance mode and load the backup data.
  - 1) Turn ON the power with pressing the [MAIN MENU] key.
  - 2) Change the security to management mode and select {TOOL} ⇒ {CompactFlash} ⇒ "CMOS LOAD"



- For under the versions: NS3.10-00, NS2.30-02, NT2.40-02, NS2.0P-00, NS2.0P-12, and NJ3.20-00, initialize the system in maker mode before loading the CMOS data.
- For under NS1.8HA-00 versions, start the system in online mode after loading the CMOS data, and load all the individual data EXCEPT jobs and parameters.

## 5.1 Replacing NX100 Parts





## ■ Replacing the Robot I/F Circuit Board (JANCD-NIF01)

### NOTE

- Turn OFF the power before replacing the robot I/F circuit board (JANCD-NIF01).
- Be sure to back up robot data before replacing the robot I/F unit since the robot I/F unit contains important data such as robot jobs and parameters.
- There are some versions which require maker mode operations after replacing the robot I/F circuit board.  
Contact your Yaskawa representative for maker mode operations.
- Before removing the robot I/F unit from the CPU rack temporarily, turn ON the system power and charge the onboard capacitor for one hour. The CMOS data on the robot I/F unit are kept temporarily by the onboard capacitor power. The capacitor is fully charged in one hour, and discharged in 16 hours when the I/F unit is removed from the CPU rack. If the capacitor is discharged, the CMOS data will be cleared and all the system settings and user settings will be lost.  
Refer to the procedure 10 of "Replacing the Robot I/F Unit (JZNC-NIF01□)" to recover data.

### Replacement Procedure

1. Follow the replacement procedures 1 to 5 of "Replacing the Robot I/F Unit (JZNC-NIF01□)" to remove the robot I/F unit from the CPU rack.
2. Remove five screws fixing the I/O circuit board (JANCD-NIO01□) and the robot I/F circuit board (JANCD-NIF01).
3. Disconnect the I/O circuit board and the robot I/F circuit board with due care.
4. Remove five studs fixing the robot I/F circuit board (JANCD-NIF01) on the base plate.
5. Fix new robot I/F circuit board (JANCD-NIF01) with five studs on the base plate.
6. Connect the I/O circuit board (JANCD-NIO01□) to the new robot I/F circuit board (JANCD-NIF01) with the onboard connector.
7. Tighten five screws to fix the I/O circuit board (JANCD-NIO01□) and the robot I/F circuit board (JANCD-NIF01).
8. Insert the robot I/F unit into the slot of the CPU rack.
9. Tighten upper and lower screws of the robot I/F unit.
10. Connect all cables disconnected in the procedure 1.
11. Set the rotary switch as the same value as the removed board.
12. Start the system in maintenance mode and load the backup data.
  - 1) Turn ON the power with pressing the [MAIN MENU] key.
  - 2) Change the security to management mode and select {TOOL} ⇒ {Compact-Flash} ⇒ "CMOS LOAD"



- For under the versions: NS3.10-00, NS2.30-02, NT2.40-02, NS2.0P-00, NS2.0P-12, and NJ3.20-00, initialize the system in maker mode before loading the CMOS data.
- For under NS1.8HA-00 versions, start the system in online mode after loading the CMOS data, and load all the individual data EXCEPT jobs and parameters.

### ■ Replacing the I/O Circuit Board (JANCD-NIO01□)

#### NOTE

- Turn OFF the power before replacing the I/O circuit board (JANCD-NIO01□).
- Be sure to back up robot data before replacing the robot I/F unit since the robot I/F unit contains important data such as robot jobs and parameters.
- Before removing the robot I/F unit from the CPU rack temporarily, turn ON the system power and charge the onboard capacitor for one hour. The CMOS data on the robot I/F unit are kept temporarily by the onboard capacitor power. The capacitor is fully charged in one hour, and discharged in 16 hours when the I/F unit is removed from the CPU rack. If the capacitor is discharged, the CMOS data will be cleared and all the system settings and user settings will be lost.  
Refer to the procedure 10 of "Replacing the Robot I/F Unit (JZNC-NIF01□)" to recover data.

#### Replacement Procedure

1. Follow the replacement procedures 1 to 5 of "Replacing the Robot I/F Unit (JZNC-NIF01□)" to remove the robot I/F unit from the CPU rack.
2. Remove five screws fixing the I/O circuit board (JANCD-NIO01□) and the robot I/F circuit board (JANCD-NIF01).
3. Disconnect the I/O circuit board and the robot I/F circuit board with due care.
4. Connect new I/O circuit board (JANCD-NIO01□) to the robot I/F circuit board (JANCD-NIF01) with the onboard connector.
5. Tighten five screws to fix the I/O circuit board (JANCD-NIO01□) and the robot I/F circuit board (JANCD-NIF01).
6. Insert the robot I/F unit into the slot of the CPU rack.
7. Tighten upper and lower screws of the robot I/F unit.
8. Connect all cables disconnected in the procedure 1.

## 5.1.2 Replacing the SERVOPACK



### WARNING

- After turning OFF the power supply, wait at least 5 minutes before replacing a SERVOPACK. Do not touch any terminals during this period.

Failure to observe this warning may result in electric shock.


There are two kinds of SERVOPACKs.

Type	Manipulator
Integrated Type	HP3, HP6, EA1400N
Separated Type	HP20, EA1900N, UP20MN, UP50N, ES165N, HP165, ES200N, ES165RN, ES200RN

### Replacement Procedure (Integrated Type)

1. Turn OFF the breaker and the primary power supply and wait at least 5 minutes before replacing. Do not touch any terminals during this period.
2. Verify that the SERVOPACK CHARGE lamp (red LED) is unlit.
3. Disconnect all the cables connected externally to the SERVOPACK.
  - ①Three-phase AC power supply connector (CNP1)
  - ②Regenerative resistor connector (CNP3)
  - ③AC control power supply connector (CNP11)
  - ④DC control power supply connector (CN101)
  - ⑤Converter control signal connector (CN1)
  - ⑥PWM signal connectors (AMP1 to AMP6-CN1)
  - ⑦Motor power connectors (AMP1 to AMP6-CNP6)
4. Remove the ground wiring connected to the SERVOPACK.
5. Remove the two screws at the top on each side of the SERVOPACK.
6. Hold the top and bottom grips and lift them to pull out the SERVOPACK.
7. Install the new SERVOPACK and reconnect the connectors in the reverse order of the removing procedure.

## 5.1 Replacing NX100 Parts



Configuration of Integrated Type SERVOPACK


### Replacement Procedure (Separated Type)

#### • How to Replace Converter

1. Turn OFF the breaker and the primary power supply and wait at least 5 minutes before replacing. Do not touch any terminals during this period.
2. Verify that the converter CHARGE lamp (red LED) is unlit.
3. Disconnect all the cables connected externally to the converter.
  - ① Three-phase AC power supply connector (CNP1)
  - ② Regenerative resistor connector (CNP3)
  - ③ AC control power supply connector (CNP11)
  - ④ DC control power supply connector (CN101)
  - ⑤ Converter control signal connector (CN1)
  - ⑥ PWM amplifier control power supply connector (CN102)
  - ⑦ PN power supply connector (CNP4)
4. Remove the ground wiring connected to the converter.
5. Remove the two screws at the top on each side of the converter.
6. Hold the top grip and lift it to pull out the converter.
7. Install the new converter and reconnect the connectors in the reverse order of the removing procedure.

### • How to Replace SERVOPACK

1. Turn OFF the breaker and the primary power supply and wait at least 5 minutes before replacing. Do not touch any terminals during this period.
2. Verify that the converter CHARGE lamp (red LED) is unlit.
3. Disconnect all the cables connected externally to the SERVOPACK.
  - ① PWM signal connectors (AMP1 to AMP6-CN1)
  - ② PWM amplifier control power supply connector (CN102) (at converter side)
  - ③ PN power supply connector (CNP4) (at converter side)
  - ④ Motor power connectors (AMP1 to AMP6-CNP6)
4. Remove the ground wiring connected to the SERVOPACK.
5. Remove the two screws at the top on each side of the SERVOPACK.
6. Hold the top and bottom grips and lift them to pull out the SERVOPACK.
7. Install the new PWM amplifier and reconnect the connectors in the reverse order of the removing procedure.




Configuration of Separated Type SERVOPACK

### 5.1.3 Checking and Replacing Fuses

#### ■ Power Supply Contactor Unit

The types of fuses on power supply contactor unit (JZRCR-NTU□□) are as follows.

Parts No.	Fuse Name	Specification
1FU, 2FU	Control Power Supply Fuse	250V,10A, Time Lag Fuse (326010, 250V, 10A (Littelfuse))
3FU	Brake Fuse	SDP50, 5A, 125V (Daito Communication Apparatus Co., Ltd.)



If a fuse appears to be blown (see "8.3 Alarm Message List"), remove each fuse shown above and check the continuity with an electric tester. If the fuse is blown, replace it with the same type of fuse (supplied).




**NOTE** Determine and correct the cause of the blown fuse. If the problem is uncorrected, the fuse may blow again.

## ■ Robot I/F Unit

The types of fuses on the robot I/F unit (JZNC-NIF01□) are as follows.

Parts No.	Fuse Name	Specification
F1, F2	24VDC Fuse for I/O	250V, 3.15A, Rapid Cut Fuse (2173.15P, 3.15A, 250V (Littelfuse))



If a fuse appears to be blown (see "8.3 Alarm Message List"), remove each fuse shown above and check the continuity with an electric tester. If the fuse is blown, replace it with the same type of fuse (supplied).



**NOTE** Determine and correct the cause of the blown fuse. If the problem is uncorrected, the fuse may blow again.

## 5.2 NX100 Parts List

NX100 Parts List

No.	Name	Model	Comment
1	SERVOPACK	<b>*1</b>	6 axes type
2	CPU unit	JZNC-NRK01	
	Backboard	JANCD-NBB01	
	Control circuit board	JANCD-NCP01	
	Servo control circuit board	SGDR-AXA01A	Not included in CPU unit (JZNC-NRK01)
	Control power supply	CPS-420F	Not included in CPU unit (JZNC-NRK01)
	Robot I/F unit	JZNC-NIF01□	Not included in CPU unit (JZNC-NRK01)
	Robot I/F circuit board	JANCD-NIF01	
	I/O circuit board	JANCD-NIO01□	
3	Power supply contactor unit	<b>*2</b>	
4	Interior circulation fan	4715MS-22T-B50-B00	
5	Backside duct fan	4715MS-22T-B50-B00	HP3, HP6, EA1400N, HP20, EA1900N
		5915PC-22T-B30-B00	UP50N, UP20MN, ES165N, HP165, ES200N, ES165RN, ES200RN
6	Power supply contactor unit fuse	326010, 10A, 250V	Time lag fuse
		SDP50, 5A, 125V	Alarm fuse
	Robot I/F unit fuse	2173.15P, 3.15A, 250V	Rapid cut fuse
7	Battery	ER6VC3N 3.6V	
8	Welder I/F board	JANCD-XEW02	Only for arc welding
	Welder I/F board fuse	0312001.MXP, 1A, 250V	Fast-acting fuse, only for arc welding

**\*1** The type of the SERVOPACK depends on the manipulator model. For details, see the table "SERVOPACK List."

**\*2** The type of the power supply contactor unit depends on the manipulator model. For details, see the table "Power Supply Contactor Unit List."



SERVOPACK List

Component		HP3	HP6, EA1400N
		Model	Model
SERVOPACK		SGDR-EA1400NY26	SGDR-EA1400N
Converter		SGDR-COA040A01B	SGDR-COA040A01B
Amplifier	S	SGDR-SDA060A01B	SGDR-SDA140A01BY22
	L	SGDR-SDA060A01B	SGDR-SDA140A01BY22
	U	SGDR-SDA060A01B	SGDR-SDA140A01BY22
	R	SGDR-SDA060A01B	SGDR-SDA060A01B
	B	SGDR-SDA060A01B	SGDR-SDA060A01B
	T	SGDR-SDA060A01B	SGDR-SDA060A01B

SERVOPACK List

Component		HP20, EA1900N	UP50N	UP20MN
		Model	Model	Model
SERVOPACK		SGDR-HP20Y30	SGDR-EH50Y24	SGDR-EH50Y27
Amplifier	S	SGDR-SDA140A01B	SGDR-SDA710A01BY32	SGDR-SDA710A01B
	L	SGDR-SDA350A01BY23	SGDR-SDA710A01B	SGDR-SDA710A01B
	U	SGDR-SDA140A01BY22	SGDR-SDA350A01BY28	SGDR-SDA350A01B
	R	SGDR-SDA060A01B	SGDR-SDA140A01B	SGDR-SDA060A01B
	B	SGDR-SDA060A01BY31	SGDR-SDA140A01B	SGDR-SDA060A01B
	T	SGDR-SDA060A01B	SGDR-SDA140A01B	SGDR-SDA060A01B
Converter		SGDR-COA080A01B	SGDR-COA250A01B	SGDR-COA250A01B

SERVOPACK List

Component		ES165N, HP165, ES200N	ES165RN, ES200RN
		Model	Model
SERVOPACK		SGDR-ES165N	SGDR-ES165NY28
Amplifier	S	SGDR-SDA710A01B	SGDR-SDA710A01B
	L	SGDR-SDA710A01BY29	SGDR-SDA710A01BY29
	U	SGDR-SDA710A01B	SGDR-SDA710A01BY25
	R	SGDR-SDA350A01B	SGDR-SDA350A01B
	B	SGDR-SDA350A01B	SGDR-SDA350A01B
	T	SGDR-SDA350A01B	SGDR-SDA350A01B
Converter		SGDR-COA250A01B	SGDR-COA250A01B






Power Supply Contactor Unit List

Type	Manipulator Type
JZRCR-NTU01□-□	HP3, HP6, EA1400N, HP20, EA1900N
JZRCR-NTU02□-□	UP50N, UP20MN, ES165N, HP165, ES200N, ES165RN, ES200RN

## 5.3 Supplied Parts List

The supplied parts of NX100 is as follows.

Parts No.1 to 3 are used for fuse for replacement and No.4 and 5 are used as a tool for connecting the I/O.

No	Parts Name	Dimensions	Pcs	Model	Application
1	10A Ceramic fuse		2	326010 10A 250V (Littelfuse)	JZRCR-NTU□□ 1FU, 2FU
2	3.15A Glass-Tube fuse		2	2173.15P 3.15A 250V (Littelfuse)	JZNC-NIF01□ F1, F2
3	5A Alarm fuse		2	SDP50 5A 125V (Daito Commu- nication Appa- ratus Co., Ltd.)	JZRCR-NTU□□ 3FU
4	WAGO Connector wiring tool		2	231-131 (WAGO Com- pany of Japan, Ltd.)	JZRCR-NTU□□- CN06, 07 CPS-420F-CN02 JZNC-NIF01□-CN12
5	WAGO Terminal block wiring tool		1	210-119SB (WAGO Com- pany of Japan, Ltd.)	MXT

## 5.4 Recommended Spare Parts

It is recommended that the following parts and components be kept in stock as spare parts for the NX100. The spare parts list for the NX100 is shown below. Product performance can not be guaranteed when using spare parts from any company other than Yaskawa. To buy the spare parts which are ranked B or C, inform the manufacturing number (or order number) of NX100 to Yaskawa representative. The spare parts are ranked as follows:

- Rank A: Expendable and frequently replaced parts
- Rank B: Parts for which replacement may be necessary as a result of frequent operation
- Rank C: Drive unit



For replacing parts in Rank B or Rank C, contact your Yaskawa representative.

## 5.4 Recommended Spare Parts

Recommended Spare Parts of NX100 for HP3

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
A	1	Battery	ER6VC3N 3.6V	TOSHIBA BATTERY CO., LTD.	1	1	
A	2	Control Power Supply Fan	JZNC-NZU01	Yaskawa Electric Corporation	1	1	
A	3	Backside Duct Fan	4715MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	4	Interior Circulation Fan	4715MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	5	Control Power Supply Fuse	326010 10A 250V	Littelfuse	10	2	
A	6	Brake Fuse	SDP50 5A 125V	Daito Communication Apparatus Co., Ltd.	10	1	
A	7	24VDC Fuse for I/O	2173.15P 3.15A 250V	Littelfuse	10	2	
B	8	Control Power Supply	CPS-420F	Yaskawa Electric Corporation	1	1	
B	9	Servo Control Circuit Board	SGDR-AXA01A	Yaskawa Electric Corporation	1	1	
B	10	Control Circuit Board	JANCD-NCP01	Yaskawa Electric Corporation	1	1	
B	11	Robot I/F Circuit Board	JANCD-NIF01-1	Yaskawa Electric Corporation	1	1	
B	12	I/O Circuit Board	JANCD-NIO01□-1	Yaskawa Electric Corporation	1	1	
B	13	Power-ON Sequence Circuit Board	JANCD-NTU01-1	Yaskawa Electric Corporation	1	1	
C	14	Robot I/F Unit	JZNC-NIF01□-1	Yaskawa Electric Corporation	1	1	
C	15	SERVOPACK	SGDR-EA1400NY26	Yaskawa Electric Corporation	1	1	
C	16	Power Supply Contactor Unit	JZRCR-NTU01□-1	Yaskawa Electric Corporation	1	1	
C	17	CPU Unit <sup>*1</sup>	JZNC-NRK01-1	Yaskawa Electric Corporation	1	1	
C	18	Programming Pendant <sup>*2</sup>	JZRCR-NPP01-1	Yaskawa Electric Corporation	1	1	With 8m cable

**\*1** The CPU unit (JZNC-NRK01-1) does not include the control power supply (CPS-420F), servo control circuit board (SGDR-AXA01A), and robot I/F unit (JZNC-NIF01□). Must be ordered separately if required.

**\*2** Specify application (Arc, General, Spot, Handling) of key sheet when No.18 "Programming Pendant" is ordered.

Recommended Spare Parts of NX100 for HP6 and EA1400N

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
A	1	Battery	ER6VC3N 3.6V	TOSHIBA BATTERY CO., LTD.	1	1	
A	2	Control Power Supply Fan	JZNC-NZU01	Yaskawa Electric Corporation	1	1	
A	3	Backside Duct Fan	4715MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	4	Interior Circulation Fan	4715MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	5	Control Power Supply Fuse	326010 10A 250V	Littelfuse	10	2	
A	6	Brake Fuse	SDP50 5A 125V	Daito Communication Apparatus Co., Ltd.	10	1	
A	7	24VDC Fuse for I/O	2173.15P 3.15A 250V	Littelfuse	10	2	
A	8	Welder I/F board fuse	0312001.MXP 1A 250V	Littelfuse	10	2	Only for arc welding
B	9	Control Power Supply	CPS-420F	Yaskawa Electric Corporation	1	1	
B	10	Servo Control Circuit Board	SGDR-AXA01A	Yaskawa Electric Corporation	1	1	
B	11	Control Circuit Board	JANCD-NCP01	Yaskawa Electric Corporation	1	1	
B	12	Robot I/F Circuit Board	JANCD-NIF01-1	Yaskawa Electric Corporation	1	1	
B	13	I/O Circuit Board	JANCD-NIO01□-1	Yaskawa Electric Corporation	1	1	
B	14	Power-ON Sequence Circuit Board	JANCD-NTU01-1	Yaskawa Electric Corporation	1	1	
B	15	Welder I/F board	JANCD-XEW02	Yaskawa Electric Corporation	1	1	Only for arc welding
C	16	Robot I/F Unit	JZNC-NIF01□-1	Yaskawa Electric Corporation	1	1	
C	17	SERVOPACK	SGDR-EA1400N	Yaskawa Electric Corporation	1	1	
C	18	Power Supply Contactor Unit	JZRCR-NTU01□-1	Yaskawa Electric Corporation	1	1	
C	19	CPU Unit <sup>*1</sup>	JZNC-NRK01-1	Yaskawa Electric Corporation	1	1	
C	20	Programming Pendant <sup>*2</sup>	JZRCR-NPP01-1	Yaskawa Electric Corporation	1	1	With 8m cable

**\*1** The CPU unit (JZNC-NRK01-1) does not include the control power supply (CPS-420F), servo control circuit board (SGDR-AXA01A), and robot I/F unit (JZNC-NIF01□). Must be ordered separately if required.

**\*2** Specify application (Arc, General, Spot, Handling) of key sheet when No.18 "Programming Pendant" is ordered.

## 5.4 Recommended Spare Parts

Recommended Spare Parts of NX100 for HP20 and EA1900N

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
A	1	Battery	ER6VC3N 3.6V	TOSHIBA BATTERY CO., LTD.	1	1	
A	2	Control Power Supply Fan	JZNC-NZU01	Yaskawa Electric Corporation	1	1	
A	3	Backside Duct Fan	4715MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	4	Interior Circulation Fan	4715MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	5	Control Power Supply Fuse	326010 10A 250V	Littelfuse	10	2	
A	6	Brake Fuse	SDP50 5A 125V	Daito Communication Apparatus Co., Ltd.	10	1	
A	7	24VDC Fuse for I/O	2173.15P 3.15A 250V	Littelfuse	10	2	
A	8	Welder I/F board fuse	0312001.MXP 1A 250V	Littelfuse	10	2	Only for arc welding
B	9	Converter	SGDR-COA080A01B	Yaskawa Electric Corporation	1	1	
B	10	Control Power Supply	CPS-420F	Yaskawa Electric Corporation	1	1	
B	11	Servo Control Circuit Board	SGDR-AXA01A	Yaskawa Electric Corporation	1	1	
B	12	Control Circuit Board	JANCD-NCP01	Yaskawa Electric Corporation	1	1	
B	13	Robot I/F Circuit Board	JANCD-NIF01-1	Yaskawa Electric Corporation	1	1	
B	14	I/O Circuit Board	JANCD-NIO01□-1	Yaskawa Electric Corporation	1	1	
B	15	Power-ON Sequence Circuit Board	JANCD-NTU01-1	Yaskawa Electric Corporation	1	1	
B	16	Welder I/F board	JANCD-XEW02	Yaskawa Electric Corporation	1	1	Only for arc welding
C	17	Robot I/F Unit	JZNC-NIF01□-1	Yaskawa Electric Corporation	1	1	
C	18	SERVOPACK	SGDR-HP20	Yaskawa Electric Corporation	1	1	
C	19	Power Supply Contactor Unit	JZRCR-NTU01□-1	Yaskawa Electric Corporation	1	1	
C	20	CPU Unit <sup>*1</sup>	JZNC-NRK01-1	Yaskawa Electric Corporation	1	1	
C	21	Programming Pendant <sup>*2</sup>	JZRCR-NPP01-1	Yaskawa Electric Corporation	1	1	With 8m cable

<sup>\*1</sup> The CPU unit (JZNC-NRK01-1) does not include the control power supply (CPS-420F), servo control circuit board (SGDR-AXA01A), and robot I/F unit (JZNC-NIF01□). Must be ordered separately if required.

<sup>\*2</sup> Specify application (Arc, General, Spot, Handling) of key sheet when No.18 "Programming Pendant" is ordered.

Recommended Spare Parts of NX100 for UP20MN

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
A	1	Battery	ER6VC3N 3.6V	TOSHIBA BATTERY CO., LTD.	1	1	
A	2	Control Power Supply Fan	JZNC-NZU01	Yaskawa Electric Corporation	1	1	
A	3	Backside Duct Fan	5915MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	4	Interior Circulation Fan	4715PC-22T-B30-B00	Minebea Co., Ltd.	2	2	
A	5	Control Power Supply Fuse	326010 10A 250V	Littelfuse	10	2	
A	6	Brake Fuse	SDP50 5A 125V	Daito Communication Apparatus Co., Ltd.	10	1	
A	7	24VDC Fuse for I/O	2173.15P 3.15A 250V	Littelfuse	10	2	
B	8	Converter	SGDR-COA250A01B	Yaskawa Electric Corporation	1	1	
B	9	Control Power Supply	CPS-420F	Yaskawa Electric Corporation	1	1	
B	10	Servo Control Circuit Board	SGDR-AXA01A	Yaskawa Electric Corporation	1	1	
B	11	Control Circuit Board	JANCD-NCP01	Yaskawa Electric Corporation	1	1	
B	12	Robot I/F Circuit Board	JANCD-NIF01-1	Yaskawa Electric Corporation	1	1	
B	13	I/O Circuit Board	JANCD-NIO01□-1	Yaskawa Electric Corporation	1	1	
B	14	Power-ON Sequence Circuit Board	JANCD-NTU01-1	Yaskawa Electric Corporation	1	1	
C	15	Robot I/F Unit	JZNC-NIF01□-1	Yaskawa Electric Corporation	1	1	
C	16	SERVOPACK	SGDR-EH50Y27	Yaskawa Electric Corporation	1	1	
C	17	Power Supply Contactor Unit	JZRRCR-NTU02□-1	Yaskawa Electric Corporation	1	1	
C	18	CPU Unit <sup>*1</sup>	JZNC-NRK01-1	Yaskawa Electric Corporation	1	1	
C	19	Programming Pendant <sup>*2</sup>	JZRRCR-NPP01-1	Yaskawa Electric Corporation	1	1	With 8m cable

**\*1** The CPU unit (JZNC-NRK01-1) does not include the control power supply (CPS-420F), servo control circuit board (SGDR-AXA01A), and robot I/F unit (JZNC-NIF01□). Must be ordered separately if required.

**\*2** Specify application (Arc, General, Spot, Handling) of key sheet when No.18 "Programming Pendant" is ordered.

## 5.4 Recommended Spare Parts

Recommended Spare Parts of NX100 for UP50N

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
A	1	Battery	ER6VC3N 3.6V	TOSHIBA BATTERY CO., LTD.	1	1	
A	2	Control Power Supply Fan	JZNC-NZU01	Yaskawa Electric Corporation	1	1	
A	3	Backside Duct Fan	5915MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	4	Interior Circulation Fan	4715PC-22T-B30-B00	Minebea Co., Ltd.	2	2	
A	5	Control Power Supply Fuse	326010 10A 250V	Littelfuse	10	2	
A	6	Brake Fuse	SDP50 5A 125V	Daito Communication Apparatus Co., Ltd.	10	1	
A	7	24VDC Fuse for I/O	2173.15P 3.15A 250V	Littelfuse	10	2	
B	8	Converter	SGDR-COA250A01B	Yaskawa Electric Corporation	1	1	
B	9	Control Power Supply	CPS-420F	Yaskawa Electric Corporation	1	1	
B	10	Servo Control Circuit Board	SGDR-AXA01A	Yaskawa Electric Corporation	1	1	
B	11	Control Circuit Board	JANCD-NCP01	Yaskawa Electric Corporation	1	1	
B	12	Robot I/F Circuit Board	JANCD-NIF01-1	Yaskawa Electric Corporation	1	1	
B	13	I/O Circuit Board	JANCD-NIO01□-1	Yaskawa Electric Corporation	1	1	
B	14	Power-ON Sequence Circuit Board	JANCD-NTU01-1	Yaskawa Electric Corporation	1	1	
C	15	Robot I/F Unit	JZNC-NIF01□-1	Yaskawa Electric Corporation	1	1	
C	16	SERVOPACK	SGDR-EH50Y24	Yaskawa Electric Corporation	1	1	
C	17	Power Supply Contactor Unit	JZRCR-NTU02□-1	Yaskawa Electric Corporation	1	1	
C	18	CPU Unit <sup>*1</sup>	JZNC-NRK01-1	Yaskawa Electric Corporation	1	1	
C	19	Programming Pendant <sup>*2</sup>	JZRCR-NPP01-1	Yaskawa Electric Corporation	1	1	With 8m cable

**\*1** The CPU unit (JZNC-NRK01-1) does not include the control power supply (CPS-420F), servo control circuit board (SGDR-AXA01A), and robot I/F unit (JZNC-NIF01□). Must be ordered separately if required.

**\*2** Specify application (Arc, General, Spot, Handling) of key sheet when No.18 "Programming Pendant" is ordered.



Recommended Spare Parts of NX100 for ES165N, HP165, and ES200N

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
A	1	Battery	ER6VC3N 3.6V	TOSHIBA BATTERY CO., LTD.	1	1	
A	2	Control Power Supply Fan	JZNC-NZU01	Yaskawa Electric Corporation	1	1	
A	3	Backside Duct Fan	5915MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	4	Interior Circulation Fan	4715PC-22T-B30-B00	Minebea Co., Ltd.	2	2	
A	5	Control Power Supply Fuse	326010 10A 250V	Littelfuse	10	2	
A	6	Brake Fuse	SDP50 5A 125V	Daito Communication Apparatus Co., Ltd.	10	1	
A	7	24VDC Fuse for I/O	2173.15P 3.15A 250V	Littelfuse	10	2	
B	8	Converter	SGDR-COA250A01B	Yaskawa Electric Corporation	1	1	
B	9	Control Power Supply	CPS-420F	Yaskawa Electric Corporation	1	1	
B	10	Servo Control Circuit Board	SGDR-AXA01A	Yaskawa Electric Corporation	1	1	
B	11	Control Circuit Board	JANCD-NCP01	Yaskawa Electric Corporation	1	1	
B	12	Robot I/F Circuit Board	JANCD-NIF01-1	Yaskawa Electric Corporation	1	1	
B	13	I/O Circuit Board	JANCD-NIO01□-1	Yaskawa Electric Corporation	1	1	
B	14	Power-ON Sequence Circuit Board	JANCD-NTU01-1	Yaskawa Electric Corporation	1	1	
C	15	Robot I/F Unit	JZNC-NIF01□-1	Yaskawa Electric Corporation	1	1	
C	16	SERVOPACK	SGDR-ES165N	Yaskawa Electric Corporation	1	1	
C	17	Power Supply Contactor Unit	JZRCR-NTU02□-1	Yaskawa Electric Corporation	1	1	
C	18	CPU Unit <sup>*1</sup>	JZNC-NRK01-1	Yaskawa Electric Corporation	1	1	
C	19	Programming Pendant <sup>*2</sup>	JZRCR-NPP01-1	Yaskawa Electric Corporation	1	1	With 8m cable

**\*1** The CPU unit (JZNC-NRK01-1) does not include the control power supply (CPS-420F), servo control circuit board (SGDR-AXA01A), and robot I/F unit (JZNC-NIF01□). Must be ordered separately if required.

**\*2** Specify application (Arc, General, Spot, Handling) of key sheet when No.18 "Programming Pendant" is ordered.

## 5.4 Recommended Spare Parts

Recommended Spare Parts of NX100 for ES165RN and ES200RN

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
A	1	Battery	ER6VC3N 3.6V	TOSHIBA BATTERY CO., LTD.	1	1	
A	2	Control Power Supply Fan	JZNC-NZU01	Yaskawa Electric Corporation	1	1	
A	3	Backside Duct Fan	5915MS-22T-B50-B00	Minebea Co., Ltd.	2	2	
A	4	Interior Circulation Fan	4715PC-22T-B30-B00	Minebea Co., Ltd.	2	2	
A	5	Control Power Supply Fuse	326010 10A 250V	Littelfuse	10	2	
A	6	Brake Fuse	SDP50 5A 125V	Daito Communication Apparatus Co., Ltd.	10	1	
A	7	24VDC Fuse for I/O	2173.15P 3.15A 250V	Littelfuse	10	2	
B	8	Converter	SGDR-COA250A01B	Yaskawa Electric Corporation	1	1	
B	9	Control Power Supply	CPS-420F	Yaskawa Electric Corporation	1	1	
B	10	Servo Control Circuit Board	SGDR-AXA01A	Yaskawa Electric Corporation	1	1	
B	11	Control Circuit Board	JANCD-NCP01	Yaskawa Electric Corporation	1	1	
B	12	Robot I/F Circuit Board	JANCD-NIF01-1	Yaskawa Electric Corporation	1	1	
B	13	I/O Circuit Board	JANCD-NIO01□-1	Yaskawa Electric Corporation	1	1	
B	14	Power-ON Sequence Circuit Board	JANCD-NTU01-1	Yaskawa Electric Corporation	1	1	
C	15	Robot I/F Unit	JZNC-NIF01□-1	Yaskawa Electric Corporation	1	1	
C	16	SERVOPACK	SGDR-ES165NY28	Yaskawa Electric Corporation	1	1	
C	17	Power Supply Contactor Unit	JZRCR-NTU02□-1	Yaskawa Electric Corporation	1	1	
C	18	CPU Unit <sup>*1</sup>	JZNC-NRK01-1	Yaskawa Electric Corporation	1	1	
C	19	Programming Pendant <sup>*2</sup>	JZRCR-NPP01-1	Yaskawa Electric Corporation	1	1	With 8m cable

**\*1** The CPU unit (JZNC-NRK01-1) does not include the control power supply (CPS-420F), servo control circuit board (SGDR-AXA01A), and robot I/F unit (JZNC-NIF01□). Must be ordered separately if required.

**\*2** Specify application (Arc, General, Spot, Handling) of key sheet when No.18 "Programming Pendant" is ordered.

---

## 6 Operations after Replacing Parts

---



### WARNING

- Before operating the manipulator, check that the SERVO ON lamp turns OFF when the emergency stop buttons on the front door of the NX100 and the programming pendant are pressed.

Injury or damage to machinery may result if the manipulator cannot be stopped in case of an emergency.

- Observe the following precautions when performing teaching operations within the P-point maximum envelope of the manipulator :
  - View the manipulator from the front whenever possible.
  - Always follow the predetermined operating procedure.
  - Ensure that you have a safe place to retreat in case of emergency.

Improper or unintended manipulator operation may result in injury.

- Confirm that no persons are present in the P-point maximum envelope of the manipulator and that you are in a safe location before:
  - Turning ON the NX100 power.
  - Moving the manipulator with the programming pendant

Injury may result if anyone enters the P-point maximum envelope of the manipulator during operation.

- Always press the emergency stop button immediately if there are problems.

Emergency stop buttons are located at the upper right corner of the front door of the NX100 and on the upper right of the programming pendant.



### CAUTION

- Perform the following inspection procedures prior to conducting manipulator teaching. If problems are found, repair them immediately, and be sure that all other necessary processing has been performed.
  - Check for problems in manipulator movement.
  - Check for damage to insulation and sheathing of external wires.
- Always return the programming pendant to the hook on the NX100 cabinet after use.

The programming pendant can be damaged if it is left in the P-point maximum envelope of the manipulator, on the floor, or near fixtures.

## 6.1 Home Position Calibration

### 6.1.1 Home Position Calibration



Teaching and playback are not possible before home position calibration is complete. In a system with two or more manipulators, the home position of all the manipulators must be calibrated before starting teaching or playback. Set the security mode to the management mode to perform home position calibration.

Home position calibration is an operation in which the home position and absolute encoder position coincide. Although this operation is performed prior to shipment at the factory, the following cases require this operation to be performed again.

- Change in the combination of the manipulator and NX100
- Replacement of the motor or absolute encoder
- Clearing stored memory (by replacement of NIF01 circuit board, weak battery, etc.)
- Home position deviation caused by hitting the manipulator against a workpiece, etc.

To calibrate the home position, use the axis keys to calibrate the mark for the home position on each axis so that the manipulator can take its posture for the home position. There are two operations for home position calibration:

- All the axes can be moved at the same time
- Axes can be moved individually

If the absolute data of the home position is already known, set the absolute data again after completing home position registration.




### Home Position





The home position is the position with the pulse value "0" for each axis.  
See "6.1.3 Manipulator Home Position."


## 6.1.2 Calibrating Operation

### ■ Registering All Axes at One Time



	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {HOME POSITION}.	<p>The HOME POSITIONING window appears.</p> 

6.1 Home Position Calibration

	Operation	Explanation
3	<p>Select {DISPLAY} under the menu, or select "PAGE" to display the selection window for the control group,</p> <p>or press  .</p>	<p>The pull-down menu appears.</p>  
4	Select the desired control group.	
5	Select {EDIT} under the menu.	<p>The pull-down menu appears.</p> 

	Operation	Explanation
6	Select {SELECT ALL AXES}.	<p>The confirmation dialog box appears.</p> 
7	Select "YES."	<p>Displayed position data of all axes are registered as home position. When "NO" is selected, the registration will be canceled.</p>


## ■ Registering Individual Axes

	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {HOME POSITION}.	
3	Select the desired control group.	Perform steps 3 and 4 which have been described in " Registering All Axes at One Time " to select the desired control group.
4	Select the axis to be registered.	 <p>The confirmation dialog box appears.</p> 
5	Select "YES".	Displayed position data of the axis are registered as home position. When "NO" is selected, the registration will be canceled.






## ■ Changing the Absolute Data

To change the absolute data of the axis when home position calibration is completed, perform the following:


	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {HOME POSITION}.	
3	Select the desired control group.	Perform steps 3 and 4 which have been described in " Registering All Axes at One Time " to select the desired control group.
4	Select the absolute data to be registered.	<p>The number can now be entered.</p>  <p>The screenshot shows the 'HOME POSITIONING SELECT' screen. On the left is a menu with options: JOB, FD/CF, ARC WELDING, PARAMETER, VARIABLE (B001), SETUP, IN/OUT, DISPLAY SETUP, ROBOT, and SYSTEM INFO. The 'ROBOT' option is selected. The main area is divided into 'SELECT' and 'ABSOLUTE DATA'. Under 'SELECT', there are radio buttons for R1:S, L, U, R, B, and T. Under 'ABSOLUTE DATA', the corresponding values are displayed in input fields: R1:S: -278, L: 30154, U: -29912, R: -217, B: 7745, and T: 15881. At the bottom, there are 'Main Menu' and 'Short Cut' buttons, and a 'PAGE' indicator.</p>
5	Enter the absolute data using the numeric keys.	
6	Press [ENTER].	Absolute data are modified.

## ■ Clearing Absolute Data

	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {HOME POSITION}.	Perform steps 2, 3, and 4 which have been described in " Registering All Axes at One Time " to display the HOME POSITION-ING window and select the desired control group.
3	Select {DATA} under the menu.	The pull-down menu appears. 
4	Select {CLEAR ALL DATA}.	The confirmation dialog box appears. 
5	Select "YES".	The all absolute data are cleared. When "NO" is selected, the operation will be canceled. 

### 6.1.3 Manipulator Home Position

With the MOTOMAN-HP6, the home position is as follows.




**NOTE** Other manipulator models have different positions. Always consult the documentation for the correct manipulator model.

## 6.2 Position Deviation Check Using the Check Program


Use the check program to check if positions are deviated with the following procedure.

1. Call up the check program in which the check point is taught (the job for the check point) and operate the manipulator at low speed.



2. Check the tool tip position.

If it points the check point exactly as shown in the following figure, there is no deviation from the positions. Proceed to "6.4 Setting the Second Home Position (Check Point)." If not, there is a deviation. When the motor or encoder, etc. was replaced, move the corresponding axis only, when the stored memory was cleared or the manipulator was hit against a workpiece, move all axes, to the check point by joint motion. Then, proceed to "6.3 Home Position Data Correction."



Enlarged View

## 6.3 Home Position Data Correction

When there is a deviation from the positions, correct the home position data with the following procedure.

1. Check the values of the following pulses. (If there is no deviation, the following two values coincide.)
  - Command position pulse of the check point which was taught in advance
  - Current position pulse where the manipulator (tool tip) was moved to the check point after performing the check program

### Displaying the Command Position Pulse

	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {COMMAND POSITION}.	The command position pulse values appear. Note the values.

### Displaying the Current Position Pulse

	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {CURRENT POSITION}.	The current position pulse values appear. Note the values.

2. Calculate the difference between the command position pulse and the current position pulse.  
 The difference pulse = Command position pulse – Current position pulse
3. On the HOME POSITIONING window, add the difference pulse value to the absolute data of the axis whose motor or encoder, etc. was replaced.
4. Modify the home position data by following the procedures described in " 6.1.2 Calibrating Operation ".
5. Confirm that the command position pulse and the current position pulse coincide.  
 The home position data have been corrected. Proceed to "6.4 Setting the Second Home Position (Check Point)."

## 6.4 Setting the Second Home Position (Check Point)



### WARNING

- Be aware of safety hazards when performing the position confirmation of the second home position (check point).

Abnormality of the PG system may be a cause for alarm. The manipulator may operate in an unexpected manner, and there is a risk of damage to equipment or injury to personnel.

- Before operating the manipulator, check that the SERVO ON lamp goes out when the emergency stop buttons on the front door of NX100 and the programming pendant are pressed.

Injury or damage to machinery may result if the manipulator cannot be stopped in case of an emergency.

- Observe the following precautions when performing teaching operations within the P-point maximum envelope of the manipulator :
  - View the manipulator from the front whenever possible.
  - Always follow the predetermined operating procedure.
  - Ensure that you have a safe place to retreat in case of emergency.

Improper or unintended manipulator operation may result in injury.

- Prior to performing the following operations, be sure that no one is in the P-point maximum envelope of the manipulator, and be sure that you are in a safe place when:

- Turning ON the NX100 power
- Moving the manipulator with the programming pendant
- Running the system in the check mode
- Performing automatic operations

Injury may result from contact with the manipulator if persons enter the P-point maximum envelope of the manipulator.

- Always press the emergency stop button immediately if there are problems.

Emergency stop buttons are attached on the right of the front door of the NX100 and the programming pendant.



## CAUTION

- Perform the following inspection procedures prior to teaching the manipulator. If problems are found, correct them immediately, and be sure that all other necessary tasks have been performed.
  - Check for problems in manipulator movement.
  - Check for damage to the insulation and sheathing of external wires.
  - Always return the programming pendant to its hook on the NX100 cabinet after use.

If the programming pendant is inadvertently left on the manipulator, a fixture, or on the floor, the manipulator or a tool could collide with it during manipulator movement, possibly causing injury or equipment damage.


### 6.4.1 Purpose of Position Check Operation

If the absolute number of rotation detected at power supply ON does not match the data stored in the absolute encoder the last time the power supply was turned off, an alarm is issued when the controller power is turned ON.

There are two possible causes of this alarm:

- Error in the PG system
- The manipulator was moved after the power supply was turned OFF.

If there is an error with the PG system, the manipulator may stall when playback is started. If the absolute data allowable range error alarm has occurred, playback and test runs will not function and the position must be checked.



#### ① Position Check

After the "OUT OF RANGE (ABSO DATA)" alarm occurs, move to the second home position using the axis keys and perform the position confirmation. Playback, test runs, and FWD operation will not function unless "CONFIRM POSITION" is performed.



### ②Pulse Difference Check

The pulse number at the second home position is compared with that at the current position. If the difference is within the allowable range, playback is enabled. If not, the alarm occurs again.

- The allowable range pulse is the number of pulses per rotation of the motor (PPR data).
- The initial value of the second home position is the home position (where all axes are at pulse 0). The second home position can be changed. For details, refer to "6.4.2 Procedure for the Second Home Position Setting (Check Point)."

### ③Alarm Occurrence

If the alarm occurs again, there may be an error in the PG system. Check the system. After adjusting the erroneous axis, calibrate the home position of the axis, then check the position again.

#### NOTE

- Home position calibration of all the axes at the same time enables playback operations without having to check the position.
- Sometimes in a system with a manipulator that has no brake, it is possible to enable playback without position checking after the alarm occurs. However, as a rule, always perform "CONFIRM POSITION".




Under the above special conditions, the manipulator moves as follows:

After starting, the manipulator moves at low speed (1/10 of the maximum speed) to the step indicated by the cursor. If it is stopped and restarted during this motion, the low speed setting is retained until the step at cursor is reached. Regardless of cycle setting, the manipulator stops after the cursor step is reached. Starting the manipulator again then moves it at the programmed speed and cycle of the job.

## 6.4.2 Procedure for the Second Home Position Setting (Check Point)

Apart from the "home position" of the manipulator, the second home position can be set up as a check point for absolute data. Use the following steps to set the specified point.

If two or more manipulators or stations are controlled by one controller, the second home position must be set for each manipulator or station.

	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {SECOND HOME POS}.	<p>The SECOND HOME POS window appears. The message "Available to move to and modify specified point" is shown.</p> 
3	<p>Press the page key , or select "PAGE" to display the selection window for the control group.</p>	<p>The group axes by which the second home position is set is selected when there are two or more group axes.</p> 
4	Press the axis keys.	Move the manipulator to the new second home position.
5	Press [MODIFY] and [ENTER].	The second home position is changed.

### 6.4.3 Procedure after the Alarm



## WARNING

- Be aware of safety hazards when performing the position confirmation of the specified point.

Abnormality of the PG system may be cause for alarm. The manipulator may operate in an unexpected manner, and there is a risk of damage to equipment or injury to personnel.


If the "OUT OF RANGE (ABS DATA)" alarm occurs, perform the followings

- Reset the alarm
- Turn Servo power ON



and confirm the second home position. After the confirmation, if the PG system is found to be the cause of the alarm, perform the necessary operation, such as replacing the PG, etc. The robot current position data when turning main power supply OFF and ON can be confirmed in "POWER ON/OFF POS" window.



Refer to " 7.7 Position Data When Power is Turned ON/OFF " for details on the "POWER ON/OFF POS" window.

	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {SECOND HOME POS}.	<p>The SECOND HOME POS window appears.</p> 

## 6.4 Setting the Second Home Position (Check Point)

	Operation	Explanation
3	<p>Press the page key  , or select "PAGE" to display the selection window for the control group.</p>	<p>The group axes by which the second home position is set is selected when there are two or more group axes.</p> 
4	Press [FWD].	TCP moves to the second home position. The robot moving speed is set as selected manual speed.
5	Select {DATA} under the menu.	
6	Select {CONFIRM POSITION}.	<p>The message "Home position checked" is shown.</p> <p>Pulse data of the second home position and current pulse data are compared. If the compared error is in allowed range, playback operation can be done.</p> <p>If the error is beyond the allowed range, the alarm occurs again.</p>


# 7 System Diagnosis

## 7.1 System Version

It is possible to check the system CPU version information as follows.

	Operation	Explanation
1	Select {SYSTEM INFO} under the main menu.	
2	Select {VERSION}.	<div>The VERSION window appears.<div><div>DATAEDITDISPLAYUTILITY</div><div>VERSION</div><div>SYSTEM : NS3.12.00A(US)-00 PARAM : 1.92 MODEL : EA1400N-A0* APPLI : ARC WELD LANG : 3.12-00-00 / 3.12-00-00</div><div>CPU           SYSTEM ROM    BOOT ROM NCP01         3.12           ----- NPP01         3.10-00       1.58 AX*#0         *****       *****</div></div><div>Main MenuShort Cut</div></div>

## 7.2 Manipulator Model


	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {MANIPULATOR TYPE}.	<div>The ROBOT AXIS CONFIG window appears.</div> <div></div>

## 7.3 Input/Output Status


### 7.3.1 Universal Input

The status of input signal which is referred to by input instruction of a job can be confirmed.

#### ■ Universal Input Window

	Operation	Explanation
1	Select {IN/OUT} under the main menu.	
2	Select {UNIVERSAL INPUT}.	The UNIVERSAL INPUT window appears. 


#### ■ Universal Input Simple Window

	Operation	Explanation
1	Select {IN/OUT} under the main menu.	
2	Select {UNIVERSAL INPUT}.	The UNIVERSAL INPUT window appears.
2	Select {SIMPLE} from the pull-down menu of {DISPLAY}.	The UNIVERSAL INPUT simple window appears. 


## 7.3.2 Universal Output

The status of the output signal set by the output instruction can be confirmed and modified.

### ■ Universal Output Window

	Operation	Explanation
1	Select {IN/OUT} under the main menu.	
2	Select {UNIVERSAL OUT-PUT}.	<p>The UNIVERSAL OUTPUT window appears.</p> 

### ■ Universal Output Simple Window


	Operation	Explanation
1	Select {IN/OUT} under the main menu.	
2	Select {UNIVERSAL OUT-PUT}.	<p>The UNIVERSAL OUTPUT window appears.</p>
3	Select {SIMPLE} from the pull-down menu of {DISPLAY}.	<p>The UNIVERSAL OUTPUT simple window appears.</p> 



## ■ Modifying the Output Status

The status of universal output signal can be changed by the operation below.


	Operation	Explanation
1	Select the desired output signal number.	Select the status of the desired output signal, “○” or “●,” in the UNIVERSAL OUTPUT window.
2	Press [INTER LOCK] + [SELECT].	The status is changed. (● :ON status, ○ :OFF status)




**NOTE** The status of universal output signal can be changed only when the mode is set to the teach mode.

### 7.3.3 Specific Input

#### ■ Specific Input Window


	Operation	Explanation
1	Select {IN/OUT} under the main menu.	
2	Select {SPECIFIC INPUT}.	<p>The SPECIFIED INPUT window appears.</p> 

#### ■ Specific Input Simple Window


	Operation	Explanation
1	Select {IN/OUT} under the main menu.	
2	Select {SPECIFIC INPUT}.	<p>The SPECIFIED INPUT window appears.</p>
2	Select {SIMPLE} from the pull-down menu of {DISPLAY}.	<p>The SPECIFIED INPUT simple window appears.</p> 

## 7.3.4 Specific Output

### ■ Specific Output Window


	Operation	Explanation
1	Select {IN/OUT} under the main menu.	
2	Select {SPECIFIC OUTPUT}.	The SPECIFIED OUTPUT window appears. 

### ■ Specific Output Simple Window

	Operation	Explanation
1	Select {IN/OUT} under the main menu.	
2	Select {SPECIFIC OUTPUT}.	The SPECIFIED OUTPUT window appears.
2	Select {SIMPLE} from the pull-down menu of {DISPLAY}.	The SPECIFIED OUTPUT simple window appears. 


7.3.5 RIN Input

■ RIN Input Window

	Operation	Explanation
1	Select {IN/OUT} under the main menu.	
2	Select {RIN}.	<div>The RIN window appears.<div><div><div>DATA</div><div>EDIT</div><div>DISPLAY</div><div>UTILITY</div><div></div></div></div></div>

### 7.3.6 Signal Number Search



A search can be made for a signal number of a universal input, universal output, specific input, and specific output.





A search for the signal number can be made in the following two ways.

- Direct search on the UNIVERSAL/SPECIFIED INPUT/OUTPUT window
- Search from the menu

■ Direct Search on the Universal/Specified Input/Output Window

	Operation	Explanation
1	Move the cursor to a signal number in the UNIVERSAL/SPECIFIED INPUT/OUTPUT window, and press [SELECT].	<p>Numeric values can now be entered.</p>  <p>The screenshot shows the 'UNIVERSAL INPUT' window. At the top, there are tabs for 'DATA', 'EDIT', 'DISPLAY', and 'UTILITY'. Below the tabs, the window title is 'UNIVERSAL INPUT' and the group is 'IG#001'. The window displays a list of input signals: IN#0002, IN#0003, IN#0004, IN#0005, IN#0006, IN#0007, and IN#0008. Each signal has a corresponding numeric input field. The bottom of the window has a 'PAGE' button and a 'Main Menu' button.</p>
2	Enter the signal number to be searched.	<p>Type the signal number in the number input line.</p>
3	Press [ENTER] to start the search.	<p>The page where the signal number exists appers.</p>  <p>The screenshot shows the 'UNIVERSAL INPUT' window after a search. The group is now 'IG#006'. The search results are displayed in a list: IN#0041, IN#0042, IN#0043, IN#0044, IN#0045, IN#0046, IN#0047, and IN#0048. Each signal has a corresponding numeric input field. The bottom of the window has a 'PAGE' button and a 'Main Menu' button.</p>

## Search from the Menu

	Operation	Explanation
1	Select {EDIT} under the menu in the UNIVERSAL/SPECIFIED INPUT/OUTPUT window.	<p>The pull-down menu appears.</p>  <p>The screenshot shows the 'UNIVERSAL/SPECIFIED INPUT/OUTPUT' window. The 'EDIT' menu is open, showing options: 'RENAME', 'SELECT ALL SIM', and 'SELECT ALL PHY'. The window also displays a list of input/output groups (IN#0001 to IN#0008) and their corresponding signal numbers (#00015 to #00017). The 'PAGE' button is visible at the bottom right.</p>
2	Select {SEARCH SIGNAL NO.}.	<p>Numeric values can now be entered.</p>  <p>The screenshot shows the 'UNIVERSAL INPUT' window. The 'SEARCH SIGNAL NO.' menu is open, and numeric values can be entered in the input fields. The window displays a list of input/output groups (IN#0001 to IN#0008) and their corresponding signal numbers (#00010 to #00017). The 'PAGE' button is visible at the bottom right.</p>
3	Enter the signal number to be searched.	Type the signal number in the number input line.
4	Press [ENTER] to start the search.	The page where the signal number exists appears.

### 7.3.7 Relay Number Search

A search can be made for a relay number of a universal input, universal output, specific input, and specific output.


GROUP	IG#001	0:DEC	00:HEX	
IN#0001	#00010	<input type="checkbox"/>	<input type="radio"/>	
IN#0002	#00011	<input type="checkbox"/>	<input type="radio"/>	
IN#0003	#00012	<input type="checkbox"/>	<input type="radio"/>	
IN#0004	#00013	<input type="checkbox"/>	<input type="radio"/>	
IN#0005	#00014	<input type="checkbox"/>	<input type="radio"/>	
IN#0006	#00015	<input type="checkbox"/>	<input type="radio"/>	
IN#0007	#00016	<input type="checkbox"/>	<input type="radio"/>	
IN#0008	#00017	<input type="checkbox"/>	<input type="radio"/>	

A search for the relay number can be made in the following two ways.



- Direct search on the UNIVERSAL/SPECIFIED INPUT/OUTPUT window
- Search from the menu



## ■ Direct Search on the Universal/Specified Input/Output Window


	Operation	Explanation
1	Move the cursor to a relay number in the UNIVERSAL/SPECIFIED INPUT/OUTPUT window, and press [SELECT].	<p>Numeric values can now be entered.</p>  <p>The screenshot shows the 'UNIVERSAL INPUT' window. At the top, there are tabs for DATA, EDIT, DISPLAY, and UTILITY. Below the tabs, the window title is 'UNIVERSAL INPUT'. Underneath, it says 'GROUP IG#001' and '0:DEC. 00:HEX.'. The main area contains a list of input channels: IN#0001, IN#0002, IN#0003, IN#0004, IN#0005, IN#0006, IN#0007, and IN#0008. Each channel has a corresponding group number (e.g., #00011 for IN#0002) and a radio button. To the right of each radio button is a numeric input field. At the bottom of the window, there are buttons for 'Main Menu' and 'Short Cut', and a 'PAGE' indicator.</p>
2	Enter the relay number to be searched.	Type the relay number in the number input line.
3	Press [ENTER] to start the search.	The page where the relay number exists appears.

## ■ Search from the Menu

	Operation	Explanation
1	Select {EDIT} under the menu in the UNIVERSAL/SPECIFIED INPUT/OUTPUT window.	<p>The pull-down menu appears.</p> 
2	Select {SEARCH RELAY SIGNAL NO.}.	<p>Numeric values can now be entered.</p> 
3	Enter the relay number to be searched.	Type the relay number in the number input line.
4	Press [ENTER] to start the search.	The page where the relay number exists appears.

### 7.3.8 Modification of the Signal Name

The name of the universal input or output signal can be modified.




The name can be modified in the following two ways.



- Direct modification on the UNIVERSAL/SPECIFIED INPUT/OUTPUT window.
- Modification from the menu

#### ■ Direct Modification on the Universal/Specified Input/Output Window

	Operation	Explanation
1	Move the cursor to the signal name to be modified in the UNIVERSAL/SPECIFIED INPUT/OUTPUT window, and press [SELECT].	The window for character input appears.
2	Enter the signal name.	
3	Press [ENTER].	New signal name is registered.




## ■ Modification from the Menu

	Operation	Explanation
1	Move the cursor to the signal name to be modified in the UNIVERSAL/SPECIFIED INPUT/OUTPUT window.	
2	Select {EDIT} under the menu.	<p>The pull-down menu appears.</p> 
3	Select {RENAME}.	The window for character input appears.
4	Enter the signal name.	
5	Press [ENTER].	<p>New signal name is registered.</p> 


## 7.4 System Monitoring Time Display





### 7.4.1 System Monitoring Time Display Window

The status of system operation, e.g. power ON time, can be checked.

	Operation	Explanation
1	Select {SYSTEM INFO}.	
2	Select {MONITORING TIME}.	<p>The SYS MONITORING TIME window appears.</p>  <p>①CONTROL POWER TIME Displays the cumulative time that the main power supply has been ON.</p> <p>②SERVO POWER TIME Displays the cumulative time that the servo power supply has been ON.</p> <p>③PLAYBACK TIME Displays the cumulative time during which playback was executed.</p> <p>④MOVING TIME Displays the cumulative time that the manipulator was in motion.</p> <p>⑤OPERATING TIME Displays the cumulative time spent in operation. For example, if the manipulator is used for spot welding, it displays the amount of time spent in spot welding; if the manipulator is used for handling, it displays the time spent in handling.</p>

## 7.4.2 Individual Window of the System Monitoring Time Display



If the page key  is pressed, or "PAGE" is selected to display the selection window for the system monitoring time display, the servo power time, playback time, moving time, and each-application operating time by each control group are individually displayed.



The total time of each control group here is not always the same as the time in the SYS MONITORING TIME window because these windows show time as seen from the individual control group.

7.4.3 Clearing the System Monitoring Time Display





The moving time and operating time can be cleared and set back to 0 by following procedure. These operations can be performed in the SYS MONITORING TIME window, or in the individual windows.

	Operation	Explanation
1	Select the time to be cleared.	<div>The confirmation dialog box appears.</div> <div></div>
2	Select "YES."	<div>The cumulative time value at the cursor line is reset to 0, and a new time measurement begins.</div> <div></div>

## 7.5 Alarm History

### 7.5.1 Alarm History Window



The alarm history can be confirmed in the alarm history window. There are five types of alarm history windows: the "MAJOR ALARM" window, the "MINOR ALARM" window, the "USER ALARM (SYSTEM)" window, the "USER ALARM (USER)" window, and the "OFF-LINE ALARM" window. Each window shows the alarm code and the date and time.

	Operation	Explanation
1	Select {SYSTEM INFO} under the main menu.	
2	Select {ALARM HISTORY}.	<p>The alarm history window appears.</p> 
3	Press the page key  to change the window, or select "PAGE" to display the selection window for the alarm windows.	<p>Each time the page key  is pressed, the window changes "MAJOR ALARM"→"MINOR ALARM"→"USER ALARM(SYSTEM)"→"USER ALARM(USER)"→"OFF-LINE ALARM."</p> 



## 7.5.2 Clearing the Alarm History

The history of the minor alarms and the user alarms (system and user) can be cleared.


	Operation	Explanation
1	Display the alarm history window to be cleared.	
2	Select {DATA} under the menu.	<p>The pull-down menu "CLEAR HISTORY" appears.</p>  <p>The screenshot shows a software interface with a top menu bar containing 'DATA', 'EDIT', 'DISPLAY', and 'UTILITY'. A pull-down menu is open under 'DATA', showing 'CLEAR HISTORY' as the selected option. Below the menu, a table displays alarm history with columns 'ARM CODE', 'DATE', and 'CLOCK'. The first entry is '001 4109 2005/07/23 15:01'. Below the table, the text 'DC 24V POWER SUPPLY FAILURE(I/O)' and '[0000_0001]' is shown, followed by 'JOB : ***** LINE : **** STEP : ***'. At the bottom, there are buttons for 'Main Menu' and 'Short Cut'.</p>
3	Select {CLEAR HISTORY}.	<p>The confirmation dialog box appears.</p>  <p>The screenshot shows the same software interface as before, but now a confirmation dialog box is displayed in the center. The dialog box has the title 'Initialize?' and two buttons: 'YES' and 'NO'. The 'NO' button is highlighted with a dashed border. The background window remains visible behind the dialog box.</p>
4	Select "YES."	The alarm history displayed is reset.

## 7.6 I/O Message History

### 7.6.1 I/O Message History Window

The I/O message history can be confirmed in the I/O MESSAGE HISTORY window.

The I/O MESSAGE HISTORY window shows the date and time, job name, line number, and step number of the I/O message that appeared on the window.

	Operation	Explanation
1	Select {SYSTEM INFO} under the main menu.	
2	Select {I/O MSG HISTORY}.	<p>The I/O MESSAGE HISTORY window appears.</p>  <p>Press [SELECT], and numeric values can now be entered. Input the history number, and press [ENTER]. The search for the input history number begins, and the I/O message that appeared on the window is displayed.</p>


### ■ Search

Use the following operation to search for the I/O message history.

	Operation	Explanation
1	Select {EDIT} under the menu.	
2	Select {SEARCH}.	The character input line appears.
3	Enter the history No.	
4	Press [ENTER].	The search for the input history number begins, and the I/O message is displayed.

## 7.6.2 Clearing the I/O Message History

Use the following operation to clear the I/O message history.

	Operation	Explanation
1	Select {DATA} under the menu.	
2	Select {CLEAR HISTORY}.	<p>The confirmation dialog box appears.</p> 
3	Select "YES."	The displayed I/O message history is cleared.

## 7.7 Position Data When Power is Turned ON/OFF




### 7.7.1 Power ON/OFF Position Window

The Power ON/OFF position window shows the position of the manipulator when power was turned OFF the last time, the current position of the manipulator when power was later turned ON, and the amount of difference between the two positions. When alarm 4107, "OUT OF RANGE (ABS DATA)" occurs, the error value of the faulty axes can be verified in this window.

	Operation	Explanation																												
1	Select {ROBOT} under the main menu.																													
2	Select {POWER ON/OFF POS}.	<div>The POWER ON/OFF POSITION window appears.</div> <div><div><div>DATA</div><div>EDIT</div><div>DISPLAY</div><div>UTILITY</div></div><div><div><div>POWER ON/OFF POSITION</div><table><thead><tr><th></th><th>OFF POS</th><th>ON POS</th><th>DIFFERENCE</th></tr></thead><tbody><tr><td>R1: S</td><td>4775</td><td>4120</td><td>665</td></tr><tr><td>L</td><td>8225</td><td>8225</td><td>0</td></tr><tr><td>U</td><td>960</td><td>960</td><td>0</td></tr><tr><td>R</td><td>-336</td><td>-336</td><td>0</td></tr><tr><td>B</td><td>-202</td><td>-203</td><td>1</td></tr><tr><td>T</td><td>-10</td><td>-11</td><td>1</td></tr></tbody></table></div><div><div></div><div></div><div>PAGE</div><div></div></div><div><div>Main Menu</div><div>Short Cut</div><div></div></div></div></div>		OFF POS	ON POS	DIFFERENCE	R1: S	4775	4120	665	L	8225	8225	0	U	960	960	0	R	-336	-336	0	B	-202	-203	1	T	-10	-11	1
	OFF POS	ON POS	DIFFERENCE																											
R1: S	4775	4120	665																											
L	8225	8225	0																											
U	960	960	0																											
R	-336	-336	0																											
B	-202	-203	1																											
T	-10	-11	1																											

## 7.8 Current Position

### 7.8.1 Current Position Window

	Operation	Explanation
1	Select {ROBOT} under the main menu.	
2	Select {CURRENT POSITION} under the sub menu.	<p>The CURRENT POSITION window appears.</p>  <p>The screenshot shows the 'CURRENT POSITION' window with a blue header bar. Below the header, it says 'COORDINATE : PULSE TOOL : 00'. The main area displays a list of coordinates: R1: S, L, U, R, B, T, each followed by a value of 0. At the bottom, there are buttons for 'Main Menu', 'Short Cut', and a 'PAGE' button.</p>
3	Select the types of coordinates to be displayed.	<p>The pull-down menu appears.</p>  <p>The screenshot shows the 'CURRENT POSITION' window with a pull-down menu open over the 'COORDINATE' field. The menu options are PULSE, BASE, ROBOT, and USER. The 'COORDINATE' field currently shows 'PULSE'. The rest of the window is the same as in the previous screenshot.</p>
4	Select the desired coordinate system.	<p>The type of coordinates being displayed is changed.</p>  <p>The screenshot shows the 'CURRENT POSITION' window with 'COORDINATE : BASE TOOL : 00'. The main area displays a list of coordinates: R1: X, Y, Z, each followed by a value in mm (915.00 mm, 0.000 mm, 765.000 mm) and a rotation value in degrees (Rx: 180.00 deg., Ry: 0.00 deg., Rz: 0.00 deg.). Below this, there is a section for '&lt;ROBOT TYPE&gt;' with options: FRONT S&lt; 180, UP R&lt; 180, and FLIP T&lt; 180. At the bottom, there are buttons for 'Main Menu', 'Short Cut', and a 'PAGE' button.</p>





## 7.9 Servo Monitoring

### 7.9.1 Servo Monitor Window

The servo monitor window shows the servo-related data of each axis.



Monitor Items	Description
FEEDBACK PULSE	Feedback position (actual position) of each axis "0" at the home position
ERROR PULSE	Difference between the command position and the feedback position of each axis
SPEED DEVIATION	Difference between the command speed and the feedback speed of each axis
SPEED INST	Speed reference of each axis
FEEDBACK SPEED	Feedback speed (actual speed) of each axis
TORQUE SPEC	Torque reference of each axis
MAX. TORQUE	Keeps the maximum value of the torque refer- ence of each axis. "0" when the maximum torque is cleared or the control power supply is turned ON or OFF
ENCODER ROTATE SUM	Accumulated number of encoder rotation when the control power supply of each axis is turned ON
IN 1 TURN POSITION	Position after one rotation of the encoder when the control power supply of each axis is turned ON
MOTOR ABSOLUTE	Absolute value of the motor is calculated by add- ing the position in one rotation to the sum of the accumulated rotations when the control power supply of each axis is turned ON.

## 7.9.2 Changing the Monitor Items

	Operation	Explanation																								
1	Set the security mode to the management mode.																									
2	Select {ROBOT} under the main menu.																									
3	Select {SERVO MONITOR}.	<p>The SERVO MONITOR window appears.</p>  <table border="1"> <thead> <tr> <th colspan="3">SERVO MONITOR</th> </tr> <tr> <th></th> <th>FEEDBACK PULSE</th> <th>ERROR PULSE</th> </tr> </thead> <tbody> <tr> <td>R1: S</td> <td>1805</td> <td>300</td> </tr> <tr> <td>L</td> <td>234</td> <td>0</td> </tr> <tr> <td>U</td> <td>995</td> <td>0</td> </tr> <tr> <td>R</td> <td>123</td> <td>0</td> </tr> <tr> <td>B</td> <td>237</td> <td>0</td> </tr> <tr> <td>T</td> <td>2432</td> <td>0</td> </tr> </tbody> </table>	SERVO MONITOR				FEEDBACK PULSE	ERROR PULSE	R1: S	1805	300	L	234	0	U	995	0	R	123	0	B	237	0	T	2432	0
SERVO MONITOR																										
	FEEDBACK PULSE	ERROR PULSE																								
R1: S	1805	300																								
L	234	0																								
U	995	0																								
R	123	0																								
B	237	0																								
T	2432	0																								
4	Select {DISPLAY} under the menu.	<p>The pull-down menu appears. MONITOR ITEM 1 is the data on the left, and MONITOR ITEM 2 is the data on the right.</p>  <table border="1"> <thead> <tr> <th colspan="3">SERVO MONITOR</th> </tr> <tr> <th></th> <th>FEEDBACK PULSE</th> <th>ERROR PULSE</th> </tr> </thead> <tbody> <tr> <td>R1: S</td> <td>1805</td> <td>300</td> </tr> <tr> <td>L</td> <td>234</td> <td>0</td> </tr> <tr> <td>U</td> <td>995</td> <td>0</td> </tr> <tr> <td>R</td> <td>123</td> <td>0</td> </tr> <tr> <td>B</td> <td>237</td> <td>0</td> </tr> <tr> <td>T</td> <td>2432</td> <td>0</td> </tr> </tbody> </table>	SERVO MONITOR				FEEDBACK PULSE	ERROR PULSE	R1: S	1805	300	L	234	0	U	995	0	R	123	0	B	237	0	T	2432	0
SERVO MONITOR																										
	FEEDBACK PULSE	ERROR PULSE																								
R1: S	1805	300																								
L	234	0																								
U	995	0																								
R	123	0																								
B	237	0																								
T	2432	0																								
5	Select MONITOR ITEM 1 or 2, and view the sub-menu choices by the cursor key.	<p>The sub-menu choices appear.</p>  <table border="1"> <thead> <tr> <th colspan="3">SERVO MONITOR</th> </tr> <tr> <th></th> <th>FEEDBACK PULSE</th> <th>ERROR PULSE</th> </tr> </thead> <tbody> <tr> <td>R1: S</td> <td>1805</td> <td>300</td> </tr> <tr> <td>L</td> <td>234</td> <td>0</td> </tr> <tr> <td>U</td> <td>995</td> <td>0</td> </tr> <tr> <td>R</td> <td>123</td> <td>0</td> </tr> <tr> <td>B</td> <td>237</td> <td>0</td> </tr> <tr> <td>T</td> <td>2432</td> <td>0</td> </tr> </tbody> </table>	SERVO MONITOR				FEEDBACK PULSE	ERROR PULSE	R1: S	1805	300	L	234	0	U	995	0	R	123	0	B	237	0	T	2432	0
SERVO MONITOR																										
	FEEDBACK PULSE	ERROR PULSE																								
R1: S	1805	300																								
L	234	0																								
U	995	0																								
R	123	0																								
B	237	0																								
T	2432	0																								
6	Select a menu.	<p>The type of monitor-related information is changed.</p>  <table border="1"> <thead> <tr> <th colspan="3">SERVO MONITOR</th> </tr> <tr> <th></th> <th>SPEED INST</th> <th>ERROR PULSE</th> </tr> </thead> <tbody> <tr> <td>R1: S</td> <td>4000</td> <td>300</td> </tr> <tr> <td>L</td> <td>0</td> <td>0</td> </tr> <tr> <td>U</td> <td>0</td> <td>0</td> </tr> <tr> <td>R</td> <td>0</td> <td>0</td> </tr> <tr> <td>B</td> <td>0</td> <td>0</td> </tr> <tr> <td>T</td> <td>0</td> <td>0</td> </tr> </tbody> </table>	SERVO MONITOR				SPEED INST	ERROR PULSE	R1: S	4000	300	L	0	0	U	0	0	R	0	0	B	0	0	T	0	0
SERVO MONITOR																										
	SPEED INST	ERROR PULSE																								
R1: S	4000	300																								
L	0	0																								
U	0	0																								
R	0	0																								
B	0	0																								
T	0	0																								

### 7.9.3 Clearing Maximum Torque Data

The data for the maximum torque can be cleared when the maximum torque-related information is being displayed.

	Operation	Explanation
1	Select {DATA} under the menu.	<div>The clear max torque window appears.</div> <div></div>
2	Select {MAX. TORQUE}.	<div>The maximum torque data is cleared.</div> <div></div>



## 8 Alarm

### 8.1 Outline of Alarm

When an alarm of level 0 to 3 (major alarm) occurs, the servo power supply is turned OFF.


Alarm Code Classification

Alarm Code	Alarm Level	Alarm Reset Method
0□□□	Level 0 (Major alarm) (Off line alarm : Initial diagnosis/ Hardware diagnosis alarm)	It is not possible to reset by "RESET" under the ALARM window or the system input signal (Alarm reset). Turn OFF the main power supply and correct the cause of the alarm. Then turn ON the main power supply again.
1□□□ to 3□□□	Level 1 to 3 (Major alarm)	It is not possible to reset by "RESET" under the ALARM window or the system input signal (Alarm reset). Turn OFF the main power supply and correct the cause of the alarm. Then turn ON the main power supply again.
4□□□ to 8□□□	Level 4 to 8 (Minor alarm)	After correcting the cause, it is possible to reset by "RESET" under the ALARM window or the system input signal (Alarm reset).
9□□□	Level 9 (Minor alarm) (I/O alarm)	After correcting the cause for which the system input signal for the system or user alarm request turns ON, it is possible to reset by "RESET" under the ALARM window or the system input signal (Alarm reset).

## 8.2 Alarm Display

### 8.2.1 Displaying and Releasing Alarm

If an alarm occurs during operation, the manipulator stops immediately and the ALARM window appears on the programming pendant indicating that the machine was stopped by an alarm.



If more than one alarm occurs simultaneously, all the alarms are displayed. Scroll the viewing area with the cursor key to view the alarm that is not currently displayed on the viewing area. The following operations are available in the alarm status: window change, mode change, alarm reset, and emergency stop. If the window is changed to another window during alarm occurrence, the ALARM window can be shown again by selecting {SYSTEM INFO} under the main menu and then selecting {ALARM}.

### ■ Releasing Alarms

Alarms are classified by minor and major alarms.

- Minor Alarms

Select "RESET" on the ALARM window to release alarms.

Or, turn ON the specific signal "ALARM RESET" when using an external input signal (specific input).

- Major Alarms

If a severe alarm such as hardware failure occurs, servo power is automatically shut OFF and the manipulator stops. Turn OFF the main power supply, remove the cause of the alarm, and then turn ON the power supply again.

## 8.2.2 Special Alarm Display

### ■ Sub Data

Sub data such as data for the axis where the alarm occurred, may also be displayed for some alarms.

- Decimal data

Without signs: 0 to 65535

With signs: -32768 to 32767

- Binary data

The alarm occurrence data becomes "1."

With 8 bits: 0000\_0001

With 16 bits: 00000001\_00000001

- Axis data

The axis where the alarm occurred is highlighted.

With robot axis: Robots 1 to 4 [ S **L** U R B T ]

With base axis: Robots 1 to 4 [ **1** 2 3 ]

With station axis: Stations 1 to 12 [ 1 **2** 3 ]

- XYZ coordinate data

The coordinates where the alarm occurred are highlighted.

[ **X** Y Z ]

[ X Y Z **Tx** Ty Tz ]

- 123 data

The data for which the alarm occurred is highlighted.

[ **1** 2 3 ]

- Control group data

The control group where the alarm occurred is highlighted.

[ **R1** R2 S1 S2 S3 ]

### ■ Multiple SERVOPACK System

In a system using more than one SERVOPACK, the number of the SERVOPACK where the alarm occurred is also displayed. The S1 switch of the AXA01 circuit board shows the SERVOPACK number.

SV#1: SERVOPACK 1 (AXA01 circuit board S1 switch: 0)

SV#2: SERVOPACK 2 (AXA01 circuit board S1 switch: 1)

SV#3: SERVOPACK 3 (AXA01 circuit board S1 switch: 2)

SV#4: SERVOPACK 4 (AXA01 circuit board S1 switch: 3)

### ■ Independent Control Function (Optional)

In the independent control function (multi-task job), the tasks that were being done when the alarm occurred are also displayed.

TASK#0: Master-task job

TASK#1: Sub-task1 job (SUB1)

TASK#2: Sub-task2 job (SUB2)

TASK#3: Sub-task3 job (SUB3)

TASK#4: Sub-task4 job (SUB4)

TASK#5: Sub-task5 job (SUB5)

TASK#6: Sub-task6 job (SUB6)

TASK#7: Sub-task7 job (SUB7)

## 8.3 Alarm Message List



### CAUTION

Before handling the system control circuit board “JANCD-NIF\*\*\*” for any remedies, consult YASKAWA representative. To handle the JANCD-NIF\*\*\*, personnel must be appropriately skilled in maintenance mode operation.

JANCD-NIF\*\*\* backs up very important file data for the user program with a battery. Careless operation may delete registered data.

#### Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
0020	CPU COMMUNICATION ERROR	An error occurred in communications between boards when the control power turned ON.		<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check that the optional board is correctly inserted.</li> <li>• If the error occurs again, contact your Yaskawa representative.</li> </ul>
		10	• No response was sent from the optional board #1.	
		20	• No response was sent from the optional board #2.	
		50	• No response was sent from the servo board #1.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check the connections of communications cable, terminator terminal, and the station number settings.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		51	• No response was sent from the servo board #2.	
		52	• No response was sent from the servo board #3.	
		53	• No response was sent from the servo board #4.	
0021	COMMUNICATION ERROR (SERVO)	50	An error occurred in communications with the servo board #1. • The communications CPU for the servo board #1 detected an error when the control power turned ON.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check the connections of communications cable, terminator terminal, and the station number settings.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		51	An error occurred in communications with the servo board #2. • The communications CPU for the servo board #2 detected an error when the control power turned ON.	
		52	An error occurred in communications with the servo board #3. • The communications CPU for the servo board #3 detected an error when the control power turned ON.	
		53	An error occurred in communications with the servo board #4. • The communications CPU for the servo board #4 detected an error when the control power turned ON.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
0030	ROM ERROR	The system program file is damaged.		If the error occurs again, contact your Yaskawa representative.
		1	• The NCP01 system program is damaged.	
		10	• The system program of optional board #1 is damaged.	
		20	• The system program of optional board #2 is damaged.	
		50	• The system program of servo board #1 is damaged.	
		51	• The system program of servo board #2 is damaged.	
		52	• The system program of servo board #3 is damaged.	
		53	• The system program of servo board #4 is damaged.	
0060	COMMUNICATION ERROR (I/O MODULE)	1 to 15	An error was detected in communications with an I/O module board when the control power turned ON.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check the connections of communications cable, terminator terminal, and the station number settings.</li> </ul> If the error occurs again, contact your Yaskawa representative.
0100	COMMUNICATION ERROR (AXA#1)	1	An error occurred in communications with the servo board #1. • The error was detected during the check of the CERF communication watchdog data.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		2	An error occurred in communications with the servo board #1. • The error was detected during the check of the number of the CERF communications.	
0101	COMMUNICATION ERROR (AXA#2)	1	An error occurred in communications with the servo board #2. • The error was detected during the check of the CERF communication watchdog data.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		2	An error occurred in communications with the servo board #2. • The error was detected during the check of the number of the CERF communications.	
0102	COMMUNICATION ERROR (AXA#3)	1	An error occurred in communications with the servo board #3. • The error was detected during the check of the CERF communication watchdog data.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		2	An error occurred in communications with the servo board #3. • The error was detected during the check of the number of the CERF communications.	
0103	COMMUNICATION ERROR (AXA#4)	1	An error occurred in communications with the servo board #4. • The error was detected during the check of the CERF communication watchdog data.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
0103	COMMUNICATION ERROR (AXA#4)	2	An error occurred in communications with the servo board #4. • The error was detected during the check of the number of the CERF communications.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
0200	MEMORY ERROR (PARAMETER FILE)	The parameter file is damaged.		• Initialize the corresponding parameter file in the maintenance mode. If the error occurs again, contact your Yaskawa representative.
		0	RC parameter	
		1	RO parameter	
		2	SV parameter	
		3	SVM parameter	
		4	SC parameter	
		5	SD parameter	
		6	CIO parameter	
		7	FD parameter	
		8	AP parameter	
		9	RS parameter	
		10	SE parameter	
		11	SVC parameter	
		12	AMC parameter	
		13	SVP parameter	
		14	MF parameter	
		15	SVS parameter	
0210	MEMORY ERROR (SYSTEM CONFIG-DATA)	0	The system configuration information data are damaged.	• Initialize the system. If the error occurs again, contact your Yaskawa representative.
0220	MEMORY ERROR (JOB MNG DATA)	0	The management data of job files are damaged.	• Initialize the job files in the maintenance mode. If the error occurs again, contact your Yaskawa representative.
		1	The job files are damaged.	
		2	The management data of position data files are damaged.	
		3	The memory play file is damaged.	• Initialize the memory play file. If the error occurs again, contact your Yaskawa representative.
0230	MEMORY ERROR (LADDER PRG FILE)	0	The concurrent I/O ladder program is damaged.	• Initialize the concurrent I/O ladder program. If the error occurs again, contact your Yaskawa representative.
0240	MEMORRY ERROR (DEVICENET ALLOC FL)	0	The DeviceNet allocation file1 is damaged.	• Use the IO module setting screen in the maintenance mode to initialize the DeviceNet allocation file. If the error occurs again, contact your Yaskawa representative.
		1	The DeviceNet allocation file2 is damaged.	
0270	MEMORY ERROR (CF BACKUP FILE)	---	The system software version is inconsistent with the version when the internal storage data is set or the CompactFlash on the NCP01 board is damaged.	• Perform "DATA REBUILD" in the maintenance mode. • If the error occurs again after execution of "DATA REBUILD," replace the CompactFlash on the NCP01 board. If the error occurs again, contact your Yaskawa representative.
0290	MEMORY ERROR (NETWORK SETUP)	---	The network setting file is damaged.	• Specify network settings again in maintenance mode. If the error occurs again, contact your Yaskawa representative.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
0300	VERIFY ERROR (SYSTEM CONFIG-DATA)	2	The setting of concurrent I/O parameter is incorrect.	Set a correct module for the concurrent I/O parameter in the maintenance mode.
		3	An invalid value is set for the segment clock.	Set a correct value for the segment clock.
		4	Inconsistency was detected in axis-related parameters.	Correctly set the axis-related parameters.
		5	Inconsistency was detected in sensor parameters.	Correctly set the sensor parameters.
		6	System configuration data is inconsistent.	<ul style="list-style-type: none"> <li>Reset the I/O module in maintenance mode. If the error occurs again, contact your Yaskawa representative.</li> </ul>
			The parameter is inconsistent.	
		7	The set optional functions are different from those of the mounted optional board.	Use the functions of the mounted optional board.
0310	VERIFY ERROR (CMOS MEMORY SIZE)	0	The CMOS memory capacity is different from its initial setting.	Initialize the system or use a NIF board with correct CMOS capacity.
		0		
0320	VERIFY ERROR (I/O MODULE)	1 to 15	The connected I/O module is different from the function of the set I/O module.	Connect a correct I/O module.
		16	The I/O module connected to the PCI bus is different from the function of the set I/O module.	
		17		
0330	VERIFY ERROR (APPLICATION SETTING)	0	Inconsistency was detected in the application setting parameters.	Correctly set the application setting parameters.
0340	VERIFY ERROR (SENSOR FUNCTION)	0	Inconsistency was detected in the sensor parameters.	Correctly set the sensor function.
0350	VERIFY ERROR (DEVICENET ALLOC FL)	0	The station No. specified by the DeviceNet allocation file1 is incorrect (the station No. is out of the allowable range, or the specified station board is not the DeviceNet master).	<ul style="list-style-type: none"> <li>Use the IO module setting screen in the maintenance mode to initialize the DeviceNet allocation file.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		1	The MAC_ID specified by the DeviceNet allocation file1 is not consistent with the MAC_ID of the specified station board.	
		2	Inconsistency was detected in the scan list of the DeviceNet allocation file1.	
		10	The station No. specified by the DeviceNet allocation file2 is incorrect (the station No. is out of the allowable range, or the specified board is not the DeviceNet master).	
		11	The MAC_ID specified by the DeviceNet allocation file2 is not consistent with the MAC_ID of the specified station board.	
		12	Inconsistency was found in the scan list of the DeviceNet allocation file2.	



## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
0370	VERIFY ERROR (SPOT POWER SOURCE I/F)	0	The designation in the parameter is different from the connected welding timer.	Set a correct value for the welding timer designation.
0390	VERIFY ERROR (SEGMENT CLOCK)	1	The segment clock value which is out of allowable range is set.	• Set a correct value for the segment clock. If the error occurs again, contact your Yaskawa representative.
		2	The set value of segment clock is insufficient for communication with the servo board. Communication cannot be performed with the servo board	• Set a correct value, which is larger than the current value, for the segment clock. If the error occurs again, contact your Yaskawa representative.
0400	PARAMETER TRANSMISSION ERROR	50 to 53	An error occurred during the parameter/file transfer to the servo board.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
0410	MODE CHANGE ERROR		An error occurred during startup sequence processing with the servo CPU, and the system did not startup normally.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
0420	DEVICENET ALLOC FL TRANSMIT ERR	0	The DeviceNet allocation file1 could not be transmitted to the specified station.	• Verify the connection state of the DeviceNet board specified by the DeviceNet allocation file.
		1	The DeviceNet allocation file2 could not be transmitted to the specified station.	• Use the IO module setting screen in the maintenance mode to initialize the DeviceNet allocation file. If the error occurs again, contact your Yaskawa representative.
0500	SEGMENT PROC NOT READY	---	Motion command processing was not completed within the specified time.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
0510	SOFTWARE VERSION UNMATCH	---	The combination of the main system program and the servo system program is incorrect.	Correct the combination.
0520	AXIS LIMIT OVER	0	More axes than the set value are used.	• Set the control group in the maintenance mode with the connectable number of axes. If the error occurs again, contact your Yaskawa representative.
0600	MEDAR STATUS ERROR	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0601	MEDAR DIAGNOSIS ERROR	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0602	MEDAR VERSION ERROR	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0603	MEDAR REVISION ERROR	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0604	MEDAR MODE CHANGE ERROR	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0605	MEDAR SCHEDULE TRANSMIT ERROR	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0606	MEDAR ERROR1	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0607	MEDAR ERROR2	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0608	MEDAR WELDER TYPE MISMATCH	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
0609	MEDAR PARAMETER ERROR	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0610	MEDAR STEP-PER TRANSMIT ERROR	---	Refer to the instruction manual for the MEDAR function.	Refer to the instruction manual for the MEDAR function.
0710	LADDER INITIALIZE ERROR	---	The ladder could not be initialized successfully.	Refer to the instruction manual for the MEDAR function.
0720	LADDER PROGRAM ERROR	1	An error was found in the relay No. specification.	<ul style="list-style-type: none"> <li>• Use a correct ladder program.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		2	An error was found in the register No. specification.	
		3	An incorrect instruction was entered.	
		4	Output register is used redundantly.	
		5	Output relay is used redundantly.	
		6	Unconnected relay exists.	
		7	The STR instructions are overused.	
		8	The AND-STR instructions are overused.	
		9	A syntax error was found in the CNT instruction.	
		10	The head of the block starts with an instruction other than the STR instruction.	
		11	The memory capacity is exceeded due to excessive machine codes.	
		12	The last instruction is not the END instruction.	
		13	An error was found in the PART instruction.	
		14	An error was found in the GOUT instruction.	
		15	The No. of operand is incorrect.	
		16	The constant value is incorrect.	
		17	The step capacity exceeds the memory capacity.	
		18	The operation instructions are over-used.	
		19	A syntax error was found in the CNT instruction or TMR instruction.	
		20	A syntax error was found in the JMP-LABEL instructions.	
		21	The label of JMP destination does not exist.	
0800	FILE BACKUP ERROR (NCP01 CF)	---	The management area (FAT) of Compact Flash in NCP01 board is damaged.	Replace the CompactFlash in NCP01 board.
0801	FILE LOAD ERROR (NCP01 CF)	File No.	The file in the NCP01 CF could not be retrieved correctly.	<ul style="list-style-type: none"> <li>• Perform "DATA REBUILD" in the maintenance mode.</li> </ul> If the error occurs again, contact your Yaskawa representative.
0802	FILE LOAD ERROR (NCP01 CF)	Error code	An error occurred in access to the NCP01 CF.	<ul style="list-style-type: none"> <li>• Perform "DATA REBUILD" in the maintenance mode.</li> </ul> If the error occurs again, contact your Yaskawa representative.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
0803	FILE ERROR	---	An error occurred during the parameter of Manipulator Model (mecha.rom) loading.	Upgrade to the same version and rewrite the parameter.
0810	TOYOPUC ALLOC DEF ERROR	0	The TOYOPUC board cannot be identified	Verify that the TOYOPUC board is normally installed.
		1	An error was found in the input/output direction data of allocation configuration.	Verify and modify the allocation configuration data for the TOYOPUC.
		3	In the output side setting of allocation configuration data, the specified R-register start No. for the TOYOPUC exceeds the R-register limit.	
		4	In the output side setting of allocation configuration data, the set number to use the input side R-register of the TOYOPUC exceeds the R-register limit.	
		5	In the output side setting of allocation configuration data, the set number to use the M-register of concurrent I/O exceeds the M-register limit.	
		8	An error was found in the type set for output direction of allocation configuration data.	
		9	An error was found in the type set for input direction of allocation configuration data.	
		10	An error was found in the type specified for system data of allocation configuration data.	
		12	An error was found in the specified number of registers which are used by the system data "CURR.POS. (PULSE)" of allocation configuration.	
		14	An error was found in the specified number of registers which are used by the system data "CURR.POS. (XYZ)" of allocation configuration.	
		16	An error was found in the specified number of registers which are used by the system data "WELDING INFO." of allocation configuration.	
		18	An error was found in the specified number of registers which are used by the system data "TASK INFO." of allocation configuration.	
		20	An error was found in the specified number of registers which are used by the system data "EXECUTE PROGRAM INFO." of allocation configuration.	
		22	An error was found in the specified number of registers which are used by the system data "INST. MESSAGE" of allocation configuration.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
0810	TOYOPUC ALLOC DEF ERROR	23	An error was found in the specified number of registers which are used by the system data.	Verify and modify the allocation configuration data for the TOYOPUC.
		30	In the input side setting of allocation configuration data, the specified R-register start No. for the TOYOPUC exceeds the R-register limit.	
		31	In the input side setting of allocation configuration data, the set number to use the input side R-register of the TOYOPUC exceeds the R-register limit.	
		32	In the input side setting of allocation configuration data, the set number to use the M-register of concurrent I/O exceeds the M-register limit.	
		34	An error was found in the specified number of registers which are used by the system data "standard time setting data" of allocation configuration.	
		41	In the output side setting of allocation configuration data, some of the TOYOPUC's R-registers are specified redundantly.	
		42	In the output side setting of allocation configuration data, some of the M-registers of concurrent I/O are specified redundantly.	
		44	In the input side setting of allocation configuration data, some of the TOYOPUC's R-registers are specified redundantly.	
		45	In the input side setting of allocation configuration data, some of the M-registers of concurrent I/O are specified redundantly.	
0900	WATCHDOG TIMER ERROR (NIF BOARD)	---	A system operation error occurred.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
0910	CPU ERROR (NCP01)	Vec- tor No.	An error was detected in the CPU.	Replace the NCP01 board.
0911	CPU ERROR (NCP02#1)	100	An error was detected in the CPU of the optional board#1.	Replace the corresponding optional board.
0912	CPU ERROR (NCP02#2)	100	An error was detected in the CPU of the optional board#2.	Replace the corresponding optional board.
0920	BUS ERROR (NCP01)	1	The JL chip does not operate normally.	Replace the NCP01 board.
0930	CPU HANG UP ERROR (NCP01)	0	Power lost is detected	• Verify the state of primary power supply. • Verify the CPS power supply. If the error occurs again, contact your Yaskawa representative.
0950	CPU ERROR (AXA#1)	100	An error was detected in the CPU of servo board #1.	Replace the corresponding servo board.
0951	CPU ERROR (AXA#2)	100	An error was detected in the CPU of servo board #2.	Replace the corresponding servo board.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
0952	CPU ERROR (AXA#3)	100	An error was detected in the CPU of servo board #3.	Replace the corresponding servo board.
0953	CPU ERROR (AXA#4)	100	An error was detected in the CPU of servo board #4.	Replace the corresponding servo board.
1000	ROM ERROR (NCP01)	1	An error occurred in the board or system software (ROM). • A checksum error occurred in the main ROM.	Replace the NCP01 board.
1001	ROM ERROR (AXA01)	1*	A checksum error occurred in the board or the EEPROM. (*: axis No.)	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		20	The SRDY signal did not turn ON after the WRITE ENABLE command was written. (EEPROM WRITE ENABLE error)	
		21	The SRDY signal did not turn ON after the WRITE PROTECT command was written. (EEPROM WRITE PROTECT error)	
		22	The SRDY signal did not turn ON after the ERASE command was written. (EEPROM ERASE error)	
		23	The SRDY signal did not turn ON after the CLEAR command was written. (EEPROM CLEAR error)	
		24	The SRDY signal did not turn ON after data were written. (EEPROM writing error)	
		25	The SRDY signal did not turn ON after data were read. (EEPROM reading error)	
		26	The written data were rejected at verification. (EEPROM verify error)	
1030	MEMORY ERROR (PARAMETER FILE)	An error was detected at memory check.		Initialize the appropriate parameter file in the maintenance mode, and then load the appropriate parameter file saved in the external memory device.
		0	• The memory for RC parameter file is damaged.	
		1	• The memory for RO parameter file is damaged.	
		2	• The memory for SV parameter file is damaged.	
		3	• The memory for SVM parameter file is damaged.	
		4	• The memory for SC parameter file is damaged.	
		5	• The memory for SD parameter file is damaged.	
		6	• The memory for CIO parameter file is damaged.	
		7	• The memory for FD parameter file is damaged.	
		8	• The memory for AP parameter file is damaged.	
		9	• The memory for RS parameter file is damaged.	
		10	• The memory for SE parameter file is damaged.	

### 8.3 Alarm Message List

Alarm Message List				
Alarm Number	Message	Sub Code	Cause	Remedy
1030	MEMORY ERROR (PARAMETER FILE)	11	• The memory for SVC parameter file is damaged.	Initialize the appropriate parameter file in the maintenance mode, and then load the appropriate parameter file saved in the external memory device.
		12	• The memory for AMC parameter file is damaged.	
		13	• The memory for SVP parameter file is damaged.	
		14	• The memory for MF parameter file is damaged.	
		15	• The memory for SVS parameter file is damaged.	
1031	MEMORY ERROR (MOTION1)	The file data used by MOTION are damaged.		Initialize the damaged file in the maintenance mode.
		1	• The home position calibration file is damaged.	
		2	• The tool file is damaged.	
		3	• The user coordinates file is damaged.	
		4	• The robot calibration file is damaged.	
		5	• The tool calibration file is damaged.	
		6	• The weaving amplitude condition file is damaged.	
		7	• The home position correction data file is damaged.	
		8	• The conveyor calibration file is damaged.	
		9	• The arm and tool interference prevention file is damaged.	
		20	• The weaving file is damaged.	
		21	• The Power Source condition data file is damaged.	
		22	• The welding condition auxiliary file is damaged.	
		23	• The arc start condition file is damaged.	
		24	• The arc end condition file is damaged.	
		25	• The COMARC condition file is damaged.	
		26	• The COMARC data file is damaged.	
		27	• The path correction condition file is damaged.	
		28	• The painting characteristics file is damaged.	
		29	• The painting condition file is damaged.	
		30	• The multi-layer index file is damaged.	
		31	• The multi-layer condition file is damaged.	
		32	• The sensor monitoring condition file is damaged.	

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1031	MEMORY ERROR (MOTION1)		The file data used by MOTION are damaged.	Initialize the damaged file in the maintenance mode.
		33	• The name position file is damaged.	
		34	• The conveyor condition file is damaged.	
		35	• The Press characteristics file is damaged.	
		36	• The servo float condition file is damaged.	
		37	• The spot welding Power Source condition data file is damaged.	
		38	• The air-gun condition file is damaged.	
		39	• The motor-gun condition file is damaged.	
		40	• The gun pressure file is damaged.	
		41	• The dry-spotting gun pressure file is damaged.	
		42	• The anticipation OT# output file is damaged.	
		43	• The anticipation OG# output file is damaged.	
		44	• The handling condition file is damaged.	
		45	• The form cut file is damaged.	
		46	• The spot (user) I/O allocation file is damaged.	
		47	• The linear servo float condition file is damaged.	
		48	• The macro definition file is damaged.	
		49	• The seal amount correction condition file (spray) is damaged.	
		50	• The seal amount correction condition file (undercoating) is damaged.	
		51	• The arc monitor file is damaged.	
		52	• The motor-gun condition auxiliary file is damaged.	
		53	• The job registration table is damaged.	
		54	• The painting device condition file is damaged.	
		55	• The painting system file is damaged.	
		56	• The painting condition file is damaged.	
		57	• The paint characteristics file is damaged.	
		58	• The EVB gun file is damaged.	
		59	• The paint filling file is damaged.	
		60	• The welding pulse condition file is damaged.	
		61	• The clearance file is damaged.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1031	MEMORY ERROR (MOTION1)	The file data used by MOTION are damaged.		Initialize the damaged file in the maintenance mode.
		62	• The linear scale condition file is damaged.	
		63	• The gauging sensor file is damaged.	
		64	• The conveyor condition auxiliary file is damaged.	
1050	SET-UP PROCESS ERROR (SYSCON)	1	An error occurred in the setup processing of the system when the control power turned ON (Setup error). The motion instruction did not start up. (motion instruction setup incomplete.)	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
1050	SET-UP PROCESS ERROR (SYSCON)	2	An error occurred in the setup processing of the system when the control power turned ON (Processing timeout). The motion instruction did not start up. (Setup of the servo control circuit board and NCP02 circuit board incomplete, parameter setting value error)	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
1051	SET-UP PROCESS ERROR (MOTION)	An error occurred in the setup process of MOTION when the control power turned ON.		• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
		1	• The servo control section was not started up.	
		2	• The position data of when the power supply had turned OFF could not be transmitted to the servo control section.	
		3	• The servo control section could not receive the position data of when the power supply had turned OFF.	
		5	• The request to turn ON the PG power supply for the mounted axis could not be sent.	
		6	• The PG power supply for the mounted axis could not turn ON.	
		7	• The request to prepare a feedback pulse could not be sent.	
		8	• The feedback pulse could not be prepared.	
		9	• The request to initialize the arithmetic section could not be sent.	
		10	• The arithmetic section could not be initialized.	
		11	• The request to prepare the current value could not be sent.	
		12	• The current value could not be prepared.	
1100	SYSTEM ERROR	---	An unknown alarm was detected because of noise or control error.	Contact your Yaskawa representative.
1101	SYSTEM ERROR (SYSTEM 1)	---	An error occurred during the system control check.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.



## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1102	SYSTEM ERROR (SYSTEM 2)	---	An error occurred during the system control check.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
1103	SYSTEM ERROR (EVENT)	---	An error occurred during the system event data control check.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
1104	SYSTEM ERROR (CIO)	---	An error occurred during the system I/O control check. (I/O circuit board communications error, C I/O parameter setting value error etc.)	• Check the I/O signal line connectors and cables. • Reset the I/O module in maintenance mode. • Replace the NIF circuit board, I/O contactor unit, and/or I/O module.
1105	SYSTEM ERROR (SERVO)	0	No processing corresponds to the command code sent from MOTION.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
		1	Illegal command data (parameter) is received from MOTION.	
		2	An error occurred in the file transfer sequence at execution of motion command.	
		3	The data size for the file transfer was over housing size at executing a motion command.	
		4	An optional function was commanded to be executed while another optional function was in execution.	
		5	The request to change standardization time was sent without permission.	
		6	The motor instruction standardization time is out of the allowable range.	
		7	The KP parameter input value is out of the allowable range.	
		8	The KP parameter input value for two degrees of freedom control is out of the allowable range.	
		9	No processing corresponds to the command code sent from MOTION.	
		10	An uncontrollable axis was designated.	
		11	An attempt was made to apply the brake to the motor while the power was being supplied.	
		12	An attempt was made to supply power to the motor while the brake was applied to the motor.	
		14	An error occurred in the encoder power supply control process.	
		15	The segment clock was not the specified value.	
		17	An attempt was made to turn ON the servo while the encoder was not ready.	
		18	The request to turn ON the servo power supply again was sent to an axis where the servo's power was already ON.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1105	SYSTEM ERROR (SERVO)	30	The linear servo float does not support the manipulator type specified in the RC parameter at calculation for servo-float-related parameters.	Contact your Yaskawa representative.
		37	The manipulator (B-axis) passed the singular point while the linear servo float was ON.	Correct the job so that the manipulator (B-axis) does not pass the singular point while the linear servo float is ON.
		40	The axes for which the servo were attempted to be turned ON were not connected to the contactor.	• Check the wiring to the contactor. If the error occurs again, contact your Yaskawa representative.
		43	The servo ON command was executed while the encoder was in alarm status.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
		47	The alarm number is illegal.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
		60	The axis endless function is set enabled for motor guns.	Disable the axis endless function of motor guns axis.
		61	The axis endless function is set enabled for the encoder for which this function cannot be used. The axis endless function cannot be used for the encoders manufactured by Tamagawa Seiki Co., Ltd.	Disable the axis endless function for the encoder.
		63	An error occurred while the axis endless function was being used.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
		68	The home position detecting function was used for the axis for which the axis endless function was enabled.	Disable either the axis endless function or the home position detection function.
		69	The servo float function was used for the axis for which the axis endless function was enabled.	Disable the axis endless function, or do not use the servo float function.
		80	An axis number that is not for gun change was specified.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
		81	An axis number that is not for gun change was specified.	
		82	The PG power supply of the axis for gun change is ON.	
		83	The servo power supply of the axis for gun change is ON.	
		90	The gun number allocated to the specified physical axis is different from the specified gun condition file number.	
		91	The gun pressure file number is incorrect.	
		92	The axis specified for gun pressure is not a gun axis.	
		100	The sequence was untimely executed in the general-purpose 10ms process although it was not the execution timing.	
		101	The sequence was untimely executed in the segment_G process although it was not the execution timing.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1105	SYSTEM ERROR (SERVO)	103	The sequence was untimely executed in the general-purpose 2ms process although it was not the execution timing.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		104	The sequence was untimely executed in the general-purpose 4ms process although it was not the execution timing.	
		105	The sequence was untimely executed in the dynamics calculation process although it was not the execution timing.	
		106	The sequence was untimely executed in the dynamics compensation process although it was not the execution timing.	
		107	The sequence was untimely executed in the servo communications CERF sending process although it was not the execution timing.	
		108	The sequence was untimely executed in the servo communications CERF receiving process although it was not the execution timing.	
		109	The sequence was untimely executed in the segment_R process although it was not the execution timing.	
		111	The sequence was untimely executed in the segment_E process although it was not the execution timing.	
		112	The sequence was untimely executed in the segment_OPT1 process although it was not the execution timing.	
		113	The sequence was untimely executed in the segment_OPT2 process although it was not the execution timing.	
		114	The sequence was untimely executed in the segment_OPT3 process although it was not the execution timing.	
		120	A general-purpose 10ms process did not complete within the time set on the scheduling table.	
		121	The segment_G process did not complete within the time set on the scheduling table.	
		122	The general-purpose 4ms process did not complete within the time set on the scheduling table. (Emergency stop detected.)	
		123	The general-purpose 2ms process did not complete within the time set on the scheduling table.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1105	SYSTEM ERROR (SERVO)	124	The general-purpose 4ms process did not complete within the time set on the scheduling table.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		125	The dynamics calculation process did not complete within the time set on the scheduling table.	
		126	The dynamics compensation process did not complete within the time set on the scheduling table.	
		127	The CERF transmission process did not complete within the time set on the scheduling table.	
		128	The dynamics calculation process did not complete within the time set on the scheduling table.	
		129	The CERF receiving process did not complete within the time set on the scheduling table.	
		130	The segment_R process did not complete within the time set on the scheduling table.	
		131	The segment_E process did not complete within the time set on the scheduling table.	
		132	The segment_OPT1 process did not complete within the time set on the scheduling table.	
		133	The segment_OPT2 process did not complete within the time set on the scheduling table.	
		134	The segment_OPT3 process did not complete within the time set on the scheduling table.	
		150	The segment clock in the ROM for spot welding is different from the specified value.	
		151	The averaging time is not an even number. (times)	
		152	An attempt to use a function that is not allowed in the current ROM was made.	
		154	An error occurred in real-time data transmission of SVSPOT Executing bit sent from MOTION.	
		16*	The illegal data are stored in the averaging buffer. (*: axis No.)	
		17*	The sum value in the averaging buffer is incorrect. (*: axis No.)	
		18*	The "empty" status of averaging buffer is incorrect. (*: axis No.)	
		201	The transfer of servo float condition file was not successfully completed.	
		202	The transfer of gun condition file was not successfully completed.	
		203	The transfer of gun pressure file was not successfully completed.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1105	SYSTEM ERROR (SERVO)	204	The transfer of dry-spotting gun pressure file was not successfully completed.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		205	The transfer of servo hand characteristics file was not successfully completed.	
		206	The transfer of collision detecting sensitivity setting file was not successfully completed.	
		207	The tool file transfer was not successfully completed.	
		208	The transfer of linear servo float condition file was not successfully completed.	
		209	The transfer of gun condition auxiliary file was not successfully completed.	
		300	A logical error occurred in the parameter for modification of resolution which was calculated by the parameter specified by CMOS.	
		302	A logical error occurred in the parameter.	
		500	Inconsistency of FP register.	
		600	An uncontrolled axis was specified when the instruction for group change was executed.	
		602	The PG power supply of the axis for group change is ON.	
		603	The servo power supply of the axis for group change is ON.	
		700	An error occurred in motor control mode switching process.	
		800	The observer and collision detection function are set disabled although the broken belt detection function is set enabled.	
		90*	Vibration was detected in the serial encoder. (*: axis No.)	
		1000	The check item number of SVD parameter is unmatched.	
		1001	The check item number of SV parameter is unmatched.	
		1002	The check item number of SVM parameter is unmatched.	
		1003	The check item number of SVP parameter is unmatched.	
		1004	The check item number of AMC parameter is unmatched.	
		1005	The check item number of MFG parameter is unmatched.	
		1006	The check item number of MFA parameter is unmatched.	
		1007	The check item number of SVC parameter is unmatched.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1105	SYSTEM ERROR (SERVO)	1008	The check item number of SVS parameter is unmatched.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		200*	The status setting to base block is different from that of base block signal reading from JL056. (*: axis No.)	
		201*	The status setting to base block is different from that of base block signal writing to JL056. (*: axis No.)	
		202*	The status setting to base block is different from that of base block signal reading from micro program. (*: axis No.)	
		203*	The mechanical brake remains locked although the base block is released. (*: axis No.)	
		204*	The mechanical brake is not locked although the base block turns ON. (*: axis No.)	
		2100	The operating software is not used in the targeted board.	
		2101	The requested function cannot be performed.	
		32807	An error occurred in the first encoder communications.	<ul style="list-style-type: none"> <li>• Confirm the communication data line and motor specification. If the error occurs again, contact your Yaskawa representative.</li> </ul>
1200	HIGH TEMPERATURE	---	Temperature sensor in the CPS power unit is activated. The internal temperature of the controller is abnormally increased.	<ul style="list-style-type: none"> <li>• Check for temperature rise in the controller, and check if in-panel cooling fan is rotating. Cycle the power when the power supply unit is cooled off.</li> </ul>
1204	COMMUNICATION ERROR (IO MODULE)	0000_0000_0000_0001	Communications and power supply error occurred in the I/O circuit board. (standard I/O of NIF unit)	<ul style="list-style-type: none"> <li>• Check the noise source and take counter-measures to reduce the noise.</li> <li>• Reset the I/O module in maintenance mode.</li> <li>• Replace the NIF circuit board.</li> </ul>
		****_****_****_***0	Communications and power supply error occurred in the I/O circuit board. (standard I/O of NIF unit) *: 0 is correct. 1 is incorrect. Bit position of 1 shows the station number of incorrect I/O circuit board.	<ul style="list-style-type: none"> <li>• Check the I/O signal line (NIF-I/O circuit board) connectors and cables.</li> <li>• Check the connection of the I/O circuit board and the external device.</li> <li>• Check the noise source and take counter-measures to reduce the noise.</li> <li>• Reset the I/O module in maintenance mode.</li> <li>• Replace the NIF circuit board.</li> </ul>
1205	CONTROLNET ERROR	---	A communication error or power supply error occurred on the CONTROLNET board.	<ul style="list-style-type: none"> <li>• Check the noise source and take counter-measures to reduce the noise.</li> <li>• Reset the I/O module in maintenance mode.</li> <li>• Replace the CONTROLNET board,</li> </ul>
1207	BROKEN B_ON RELAY FUSE (NIF01)	---	The brake relay fuse was blown.	Replace the NIF circuit board.
1208	BROKEN S_ON RELAY FUSE (NIF01)	---	The servo-ON relay fuse was blown.	Replace the NIF circuit board.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1209	EXTERNAL WDT BROKEN (NIF01)	0000_00**	Defective watchdog timer circuit that checks the safety circuit 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD1) error	Replace the NIF circuit board.
1210	SERIAL COMMUNICATION TOGGLE CHECK ERROR (NIF01)	0000_00**	Checking error of toggle that switches double checking safety circuits in cycle of 1 ms 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD1) error	Replace the NIF circuit board.
1211	INPUT COMPARISON ERROR (NIF)	****_****_****_****_	The signal does not have a match signal as a result the mutual check of a dual signal. 0000_0000_0000_0001: Panel signal emergency stop signal (PBESP) unmatched error 0000_0000_0000_0010: Programming pendant emergency stop signal (PPESP) unmatched error 0000_0000_0000_0100: External emergency stop signal (EXESP) unmatched error 0000_0000_0000_1000: System CPU error (ERRCPU) unmatched error 0000_0000_0001_0000: Servo ON condition signal (SYSRDY) unmatched error 0000_0000_0010_0000: Safety plug signal (SAF) unmatched error 0000_0000_0100_0000: Servo ON signal (SVON) unmatched error 0000_0000_1000_0000: External servo ON signal (EXSVON) unmatched error 0000_0001_0000_0000: Unused 0000_0010_0000_0000: Maintenance signal (MAINT) unmatched error 0000_0100_0000_0001: Enable switch signal (DSW) unmatched error 0000_1000_0000_0001: Unused 0001_0000_0000_0000: External enable switch (EXDSW) unmatched error 0010_0000_0000_0000: Unused 0100_0000_0000_0000: Safety speed mode selection (SSP) unmatched error 1000_0000_0000_0000: Full speed test (FST) unmatched error	Check the signal.
1212	PLD MUTUAL MONITOR ERROR (NIF01)	0000_00**	The input comparison error occurred. 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD2) error	Check the one of PPESP, PBESP, EXESP, and SAF signals.
1213	MUTUAL WDT ERROR (NIF01)	0000_00**	The input comparison error occurred. 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD2) error	Check the one of PPESP, PBESP, EXESP, and SAF signals.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1214	PBESP RELAY STICKING	0000_00**	The emergency stop button PBESP of the NX100 front door is melted and stuck. 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD2) error	<ul style="list-style-type: none"> <li>• Confirm that the cable is not short-circuited.</li> <li>• Replace if necessary.</li> </ul>
1215	PPESP RELAY STICKING	0000_00**	The emergency stop button of programming pendant PPESP is melted and stuck. 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD2) error	<ul style="list-style-type: none"> <li>• Confirm that the cable is not short-circuited.</li> <li>• Replace if necessary.</li> </ul>
1216	EXESP RELAY STICKING	0000_00**	The external emergency stop button EXESP is melted and stuck. 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD2) error	<ul style="list-style-type: none"> <li>• Confirm that the cable is not short-circuited.</li> <li>• Replace if necessary.</li> </ul>
1217	S_ON RELAY STICKING	0000_00**	The servo-ON relay is melted and stuck. 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD2) error	Replace the servo-ON relay.
1218	B_ON RELAY STICKING	0000_00**	The brake relay is melted and stuck. 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD2) error	Replace the brake relay.
1219	ANOTHER PLD EXT WDT ERROR (NIF BOARD)	0000_00**	The watchdog timer checking the safety circuit is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the NIF unit.
1220	LAN COMMUNICATION PARAMETER ERROR	1	Incorrect setting of the IP address which is used in the Ethernet function.	Set the correct IP address.
		2	Incorrect setting of the subnet mask which is used in the Ethernet function.	Set the correct subnet mask.
		3	Incorrect setting of the default gateway which is used in the Ethernet function.	Set the correct default gateway.
		4	Incorrect setting of the host address which is used in the Ethernet function.	Set the correct host address.
		30	Incorrect setting of the parameter which is used for the SNTP of the Ethernet function.	Set the network SNTP in maintenance mode.
		31	Incorrect setting of the IP address of the SNTP server which is used in the Ethernet function of the SNTP.	Set the correct network SNTP server address in maintenance mode.
		32	Incorrect setting of the host name of the SNTP server which is used in the Ethernet function of the SNTP.	Set the correct network SNTP server host name in maintenance mode.
		33	Incorrect setting of the parameter of the DFCP which is used in the Ethernet function of the SNTP.	Set the network SNTP in maintenance mode.
		70	Incorrect setting of the host name which is used in the Ethernet function.	Set the correct network SNTP server host name.
		71	Incorrect setting of the IP address of the DNS server which is used in the Ethernet function of the DNS.	Set the correct DNS server IP address.
		73	Incorrect setting of the parameter of the DHCP which is used in the Ethernet function of the DNS.	Set the network DNS in maintenance mode.
		74		



## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1220	LAN COMMUNICATION PARAMETER ERROR	75	Incorrect setting of the domain which is used in the Ethernet function.	Set the correct domain.
1221	ETHERNET RESET ERROR	1	An error occurred in the device initialization process of the Ethernet function.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		2	An error occurred in the IP address setting process of the Ethernet function.	
		3	An error occurred in the subnet mask setting process of the Ethernet function.	
		4	An error occurred in the default gateway setting process of the Ethernet function.	
		5	An error occurred in the host name setting process of the Ethernet function.	
		6	An error occurred in the MAC address acquisition process of the Ethernet function.	
		20	An error occurred in the Web server task creating process of the Ethernet function.	
		21	An error occurred in the FTP server task creating process of the Ethernet function.	
		22	An error occurred in the FTP client task creating process of the Ethernet function.	
		30	An error occurred in the semaphore generation process for access exclusion of the Ethernet function.	
		50	An error occurred in the Web server task management ID getting process of the Ethernet function.	
		51	An error occurred in the FTP server task management ID getting process of the Ethernet function.	
		59	An error occurred in the DHCP acquisition item setting process of the Ethernet function.	
		60	An error occurred in the DHCP initialization process of the Ethernet function.	
		61	An error occurred in the DHCP interface of the Ethernet function.	
1221	ETHERNET RESET ERROR	62	The data acquisition process from the server did not complete within regulated time.	Verify the DHCP server operation and the network status.
		63	The data acquired from the server were found illegal in the DHCP of the Ethernet function.	
		64	An error occurred in the subnet mask acquisition process in the DHCP of the Ethernet function.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1221	ETHERNET RESET ERROR	65	An error occurred in the DNS server address acquisition process in the DHCP of the Ethernet function.	<ul style="list-style-type: none"> <li>• Verify the DHCP server operation and the network status.</li> </ul>
		66	An error occurred in the Ethernet function DNS domain acquisition process in the DHCP of the Ethernet function.	
		67	An error occurred in the SNTP server address acquisition process in the DHCP of the Ethernet function.	
		68	An error occurred in the IP address acquisition process in the DHCP of the Ethernet function.	
		69	An error occurred in the DHCP Interface structure mapping process of the Ethernet function.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		70	An error occurred in the DNS resolver initialization process of the Ethernet function.	
		71	An error occurred in the DNS resolver setting of the Ethernet function.	<ul style="list-style-type: none"> <li>• Verify the domain name and the DNS-related settings.</li> <li>• When the DHCP is used, verify the DHCP server operation and the network status.</li> </ul>
		72	The parameter setting error occurred in the DNS resolver setting of the Ethernet function.	
		73	The mode error occurred in the DNS resolver setting of the Ethernet function.	<ul style="list-style-type: none"> <li>• Verify the domain name and the DNS-related settings.</li> <li>• When the DHCP is used, verify the DHCP server operation and the network status.</li> </ul>
		80	An error occurred in the basic library initialization process of the Ethernet function.	
		81	An error occurred in the initialization process other than basic library of the Ethernet function.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		100	An error occurred in the IP address acquisition process in the DHCP of the Ethernet function.	
		240	An error occurred in the start process of the Ethernet function Telnet (for onboard).	
		241	An error occurred in the start process of the Ethernet function Telnet (for expand).	
1222	IP ADDRESS SET FAIL(DHCP)	----	The IP address acquired by the DHCP of Ethernet function is invalid.	<ul style="list-style-type: none"> <li>• Verify the DHCP server operation and the network status.</li> </ul>
1223	PLD MONITOR1 ERROR (HIF01)	0000_00**	The watchdog timer circuit which checks the safety circuit is damaged. 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD2) error	<ul style="list-style-type: none"> <li>• Replace the NIF circuit board.</li> </ul>
1224	PLD MONITOR2 ERROR (HIF01)	0000_00**	An error occurred in the watchdog timer which checks the safety circuit.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, replace the NIF unit.</li> </ul>

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1225	PLD MONITOR3 ERROR (HIF01)	0000_00**	An error occurred due to the occurrence of input comparison error. 0000_0001: 1 signal (PLD1) error 0000_0010: 2 signal (PLD2) error	Check the one of PPESP, PBESP, EXESP, and SAF signals.
1300	SERVO CPU SYNCHRONIZING ERROR	---	A synchronization error occurred between CPUs. • Erroneous communications occurred between the main CPU board and the servo control circuit board due to: - Defective board - Incorrect connection	<ul style="list-style-type: none"> <li>• Correct the cable connection or replace the cable.</li> <li>• Replace the main CPU board and/or servo control board.</li> </ul>
1301	COMMUNICATION ERROR (SERVO)	Erroneous communications occurred between main CPU board and servo control circuit board due to the defective board or the incorrect connection.		<ul style="list-style-type: none"> <li>• Correct the cable connection or replace the cable.</li> <li>• Replace the main CPU board and/or servo control board.</li> </ul>
		0	Communication status error	
		1	Watchdog timer error	
		2	JL040 alarm	
		3	Communication status error	
		4	Data consistency error	
1302	COMMUNICATION ERROR (SERVO I/O)	Erroneous communications occurred between the contactor unit (for I/Os, manipulators, and external axes) and servo control circuit board due to the defective board or the incorrect connection.		<ul style="list-style-type: none"> <li>• Correct the cable connection or replace the cable.</li> <li>• Replace the contactor unit and/or servo control circuit board.</li> </ul>
		1	No interrupt from servo I/O communications (JL080) occurred. (Communication loop back)	
		2	The servo I/O communications (JL080) received status is incorrect. (No interrupt)	
		4	The servo I/O communications (JL080) buffer switch status is incorrect. (Watchdog timer error)	
		5	The servo I/O communications (JL080) receiving status is incorrect. (Command timeout)	
		**10	The communications loop back value of servo I/O communications (JL080) is incorrect. (Communication loop back) (**: station number of the connected unit)	
1302	COMMUNICATION ERROR (SERVO I/O)	**11	The received address of JL080 is unmatched with the sent address. (**: station number of the connected unit)	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON after cooling the power supply unit. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		**12	The received buffer of JL080 is incorrect. (**: station number of the connected unit)	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1303	ARITHMETIC ERROR (SERVO)	XYYY Z	An error occurred in control arithmetic process or parameter arithmetic process. The data [X____] indicates the generation process. 10000: Observer control 20000: High-precision path control 30000: Dynamics 40000: Disturbance observer control The data [_YYY_] indicates the alarm contents. The data [____Z] indicates the physical axis number.	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
1304	EX-AXIS BOARD NOT INSTALLED	---	<ul style="list-style-type: none"> <li>The external board is not mounted although an external axis is specified.</li> <li>"With external axes" is specified for the system without external axes.</li> </ul>	Mount an external board or correct the external axis selection parameter.
1306	AMPLIFIER TYPE MISMATCH	Physical axis bit	The amplifier type setting is incorrect.	Set the installed amplifier type in the system configuration.
1307	ENCODER TYPE MISMATCH	Physical axis bit	The encoder type (motor model) setting is incorrect.	Set the installed motor type in the system configuration.
1308	CONVERTER TYPE MISMATCH	---	The converter model set in the system configuration is different from that of the one mounted.	Set the mounted converter model in system configuration.
1309	HARDWARE ERROR (CONVERTER)	---	Converter hardware is incorrect.	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the converter.
1310	CHARGE ERROR (CONVERTER)	---	Charge error is sent from the converter.	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the converter.
1311	A/D DETECTION ERROR (CONVERTER)	---	A/D detection error is sent from the converter.	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the converter.
1312	ID ERROR (CONVERTER)	---	ID error is sent from the converter.	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the converter.
1316	BROKEN PG LINE	---	This error occurs in the motor that is not a serial encoder (motor gun axis). There might be a failure on the AXB01 board, the AXI01 board, the connection cable between them, and the XIU unit.	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the board, connection cable and unit.
1321	BRAKE BOARD ERROR	---	Brake signal is incorrect.	<ul style="list-style-type: none"> <li>Check the wiring around the brake circuit board.</li> </ul> If the error occurs again, replace the brake circuit board.
1322	BRAKE BOARD STICKING	---	The cutout relay for the brake board main circuit is melted and stuck.	<ul style="list-style-type: none"> <li>Check and replace the cutout relay for the brake board main circuit.</li> </ul>

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1325	COMMUNICATION ERROR (ENCODER)	---	Communication error occurred between the encoder and the servo control circuit board due to: - Misconnection of encoder - Noise from external devices - Incorrect motor type - Defective servo control circuit board or encoder	<ul style="list-style-type: none"> <li>• Correct the encoder connection.</li> <li>• Check for noise.</li> <li>• Confirm the motor type.</li> </ul> If the error occurs again, replace the servo control circuit board.
1326	DEFECTIVE ENCODER ABSOLUTE DATA	---	An error occurred in the encoder position detecting circuit.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the motor of the corresponding axis.
1327	ENCODER OVER SPEED	---	The control power supply turned ON while the encoder was rotating (at more than 400min <sup>-1</sup> ). - The axis was in free-fall state. - Defective encoder	<ul style="list-style-type: none"> <li>• Stop the manipulator motion and then turn ON the control power supply to check if the error occurs.</li> </ul> If the error occurs, the encoder is defective. Replace the motor for the axis.
1328	DEFECTIVE SERIAL ENCODER	---	Internal parameter error of the serial encoder • The encoder fault may be the cause.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the motor of the corresponding axis.
1329	DEFECTIVE SERIAL ENCODER COMMAND	---	No response of encoder reset completion at the occurrence of encoder backup error. The encoder fault may be the cause.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the motor (encoder) of the corresponding axis.
1330	MICRO PROGRAM TRANSMIT ERROR	---	Defective servo control circuit board (Occurred only when the control power supply turned ON.)	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the servo control circuit board.
1331	CONVERTER CHARGE ERR(CONVERTER)	---	Charge error is sent from the converter.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the converter.
1332	POSITION ERROR	---	The number of pulses generated by one motor rotation does not agree with the specified value due to: - Noise from external devices - Defective board - Motor failure	<ul style="list-style-type: none"> <li>• Check for the external noise.</li> <li>• Provide noise protection such as installing a ferrite core if required.</li> </ul> If the error occurs again, replace the servo control circuit board, external axis servo control circuit board, and/or motor.
1333	POSITION ERROR (SERIAL ENCODER)	---	The number of pulses generated by one motor rotation does not agree with the specified value due to: - Noise from external devices - Defective board - Motor failure	<ul style="list-style-type: none"> <li>• Check for the external noise.</li> <li>• Provide noise protection such as installing a ferrite core if required.</li> </ul> If the error occurs again, replace the servo control circuit board, external servo control circuit board, and/or motor.
1335	INCOMPLETE ENCODER RESET	---	The encoder resetting did not complete. No battery may be connected.	<ul style="list-style-type: none"> <li>• Connect a battery to the encoder.</li> </ul> If the error still occurs after having connected a battery, the encoder fault may be the cause.
1343	COMMUNICATION ERROR (CONVERTER)		No response from the converter.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON after cooling the power supply unit.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		*01	Communications status error (*: converter No.)	
		*02	Command timeout (*: converter No.)	
		*03	Sent buffer FULL (*: converter No.)	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1343	COMMUNICATION ERROR (CONVERTER)		No response from the converter.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON after cooling the power supply unit.</li> <li>If the error occurs again, contact your Yaskawa representative.</li> </ul>
		*04	CRC-16 error (*: converter No.)	
		*05	Error code received (*: converter No.)	
		*06	Received command error (*: converter No.)	
1345	SAFETY CIRCUIT SIGNAL UNMATCH (SERVO)	XY	<p>Unmatched signal was detected in the double-check of the receive data to the power-ON unit.</p> <p>The data show the No. of power-ON unit and the unmatched signal.</p> <p>X...Power-ON unit            0: Power-ON unit1 (TU#1)            1: Power-ON unit2 (TU#2)            2: Power-ON unit3 (TU#3)            3: Power-ON unit4 (TU#4)            4: Power-ON unit5 (TU#5)            5: Power-ON unit6 (TU#6)</p> <p>YY...Unmatched signal            01: KMMA signal unmatched error            02: SVMAIN signal unmatched error            03: SVMAIN1*2 signal unmatched error            04: IORDY signal unmatched error            05: ONEN signal unmatched error            06: FUCUT signal unmatched error            07: SHOCK1 signal unmatched error            08: EXOT signal unmatched error            09: OT signal unmatched error            10: TUSONER signal unmatched error            11: SVCMPER signal unmatched error            12: TCER signal unmatched error            13: SON_OUT signal unmatched error            14: BRRVER signal unmatched error</p> <p>60: Error due to unmatched output signal for servo board failure            61: Error due to unmatched signal for the main contactor state (closed contact)            62: Error due to unmatched signal for the main contactor state (open contact)            63: Error due to unmatched input signal for the main contractor control relay            64: Error due to unmatched input signal for the OT recovery            65: Error due to unmatched input signal for the external WDT            66: Error due to unmatched 1FB input signal: the brake release control signal</p> <p>E.g.)            Sub Code: 208            EXOT signal of the Power-ON unit2 (TU#2) is unmatched.</p>	<ul style="list-style-type: none"> <li>• Check the wiring of the unmatched signal.</li> <li>• Replace the power-ON unit circuit board.</li> <li>• Replace the servo circuit board.</li> </ul>
1349	POWER LOST DETECTION	---	The power to the motor became unstable.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>If the error occurs again, contact your Yaskawa representative.</li> </ul>

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1350	CONTACTOR UNIT TYPE UNMATCH	---	The mounted board type is unmatched. The safety settings have been set for a controller that does not meet the specifications outlined in the safety standards.	Check the board type and replace if necessary.
1352	SERIAL CORRECTION FAILED	---	An error was detected in bit shifting compensation.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
1355	SERIAL ENC MULTITURN LIMIT ERR	---	Encoder multi-turn limit quantity error	• Turn the power OFF then back ON. If the error occurs again, replace the motor (encode) for axis.
1356	INVALID AXIS SPECIFICATION ERROR	---	A task request was sent to an axis of the group that was disabled by the group separation function.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
1357	PRESS ERROR	---	The position or speed value exceeded the limit value during pressuring after gun electrode hit the welded target. The motion after gun electrode hits the welded target is incorrect.	Check the job.
1360	PA NOT INSTALLED	---	The prealigner is not mounted although use of the prealigner has been selected.	Check the prealigner connection.
1500	PLD INTERNAL MUTUAL MONITOR ERROR (SERVO I/O)	---	PLD internal mutual monitoring error is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.
1501	SVMX RELAY STICKING (SERVO I/O)	---	SVMX relay sticking is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.
1502	TACTOR STICKING (SERVO I/O)	---	Contactor sticking is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.
1503	INPUT COMPARISON ERROR (SERVO I/O)	---	Input comparison error is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.
1504	TUSON RELAY STICKING (SERVO I/O)	---	TUSON relay breakdown is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.
1505	B_ON RELAY FUSE BREAKDOWN (SERVO I/O)	---	B_ON relay fuse breakdown is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.
1506	MAIN TACTOR RELAY FUSE BREAKDOWN (SERVO I/O)	---	Main contactor relay fuse breakdown is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.
1507	S_ON RELAY FUSE BREAKDOWN (SERVO I/O)	---	S_ON relay fuse breakdown is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.
1508	MUTUAL WDT ERROR (SERVO I/O)	---	Mutual WDT error is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.
1509	EXTERNAL WDT OVER (SERVO I/O)	---	PLD internal mutual monitoring error is sent from the TU circuit board.	• Turn the power OFF then back ON. If the error occurs again, replace the TU circuit board.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1510	EXTERNAL WDT BREAKDOWN (SERVO I/O)	---	External WDT breakdown is sent from the TU circuit board.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the TU circuit board.
1511	SERIAL COMMUNICATION TOGGLE CHECK ERROR (SERVO I/O)	---	Serial communication toggle check error is sent from the TU circuit board.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the TU circuit board.
1512	POWER SUPPLY FAN ALARM (SERVO)	---	The rotation speed of in-panel cooling fan decreased.	<ul style="list-style-type: none"> <li>• Check if in-panel cooling fan is rotating.</li> </ul> If the fan is not working, verify its wiring. Should the error persist, replace the in-panel cooling fan (CPS power unit).
1513	POWER SUPPLY OVERHEAT (SERVO)	---	Temperature sensor in the CPS power unit is activated. The internal temperature of the controller is abnormally increased.	<ul style="list-style-type: none"> <li>• Check for temperature rise in the controller, and check if in-panel cooling fan is rotating.</li> </ul> Cycle the power when the power supply unit is cooled off.
1514	OVERHEAT (AMPLIFIER)	---	Amplifier overheated.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON after cooling the amplifier.</li> </ul> If the error occurs again, contact your Yaskawa representative.
1515	SON_OUT RELAY STICKING (SERVO)	---	SON_OUT relay sticking is sent from the TU circuit board.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the TU board.
1516	BRR CER RELAY STICKING (SERVO I/O)	---	BRR CER relay sticking is sent from the TU circuit board.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the TU board.
1530	ABSOLUTE DATA ERROR (SERVO 2)	---	Absolute data cannot be received from the encoder or the received absolute data is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the encoder connection.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1531	GATE ARRAY 1 ERROR (SERVO 1)	---	Reading error of command input.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1532	GATE ARRAY 2 ERROR (SERVO 2)	---	Reading error of command input.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1533	ABSOLUTE ENCODER ERROR (SERVO2)	---	The number of pulses per rotation of the absolute encoder is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the encoder connection.</li> <li>• Check for noise.</li> <li>• Replace the SERVOPACK.</li> </ul>
1534	EARTH FAULT (SERVO2)	---	A ground fault along the motor power line, motor error, or SERVOPACK error is suspected.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check if a ground fault or interphase short-circuiting has not occurred in the U-, V-, and W-phases of motor power line.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1535	WATCHDOG DETECTOR ERROR (SERVO2)	---	The SERVOPACK watch dog is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1536	CURRENT FB ERROR (U PHASE) (SERVO2)	---	Disconnection of motor power line or the SERVOPACK U-phase current detection circuit error is suspected.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check for motor power line.</li> <li>• Replace the SERVOPACK.</li> </ul>
1537	CURRENT FB ERROR (V PHASE) (SERVO2)	---	Disconnection of motor power line or the SERVOPACK V-phase current detection circuit error is suspected.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check for motor power line.</li> <li>• Replace the SERVOPACK.</li> </ul>



Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1538	INCR ENCODER INIT PULSE ERR (SV2)	---	Initial pulse of incremental encoders is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the encoder connection.</li> <li>• Check for noise.</li> <li>• Replace the SERVOPACK.</li> </ul>
1539	SERVO ON COMMAND INVALID	---	The servo on command was input when the servo on command invalid alarm was output.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul>
1540	VIBRATION DETECT(SERVO 2)	---	An abnormal vibration was detected during motor rotation.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> </ul>
1541	FULL CLOSE SERIAL ENCODER SUM CHECK ERROR (SV2)	---	The check sum result of the encoder memory is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the serial conversion unit.</li> <li>• Replace the SERVOPACK.</li> </ul>
1542	FULL CLOSE SERIAL ENCODER DATA ALARM (SERVO2)	---	Serial encoder internal parameter error occurred.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the serial conversion unit.</li> <li>• Replace the SERVOPACK.</li> </ul>
1544	FULL CLOSE SERIAL ENCODER SCALE ERROR (SERVO2)	---	The linear encoder or the serial converter unit is damaged.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the serial conversion unit.</li> <li>• Replace the linear encoder.</li> </ul>
1545	FULL CLOSE SERIAL CONVERTER UNIT COMMUNICATION ERROR	---	Full close serial converter unit communication error occurred.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check the wiring around the cable between the serial conversion unit and SERVOPACK.</li> <li>• Check for noise.</li> <li>• Review the cable between the serial conversion unit and SERVOPACK.</li> <li>• Replace the serial conversion unit.</li> <li>• Replace the SERVOPACK.</li> </ul>
1546	COMMUNICATION SET ERR(ML2)	---	An error was found in the MECHATROLINK communication transmission frequency.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Set an appropriate MECHATROLINK transmission frequency.</li> </ul>
1547	CURRENT FB ERROR	---	The motor current value displayed on the axis data is incorrect (*: axis).	<ul style="list-style-type: none"> <li>• Check if a short-circuiting or ground fault has not occurred in the power cables (U-, V-, and W-phases) or motor.</li> </ul>
1550	PALAMETER DAMAGED (SERVO2)	---	The SERVOPACK EEPROM data is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1551	PRIMARY CIRCUIT DETECT ERR (SERVO2)	---	The various detection data of the power circuit in the SERVOPACK is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> <li>•</li> </ul>
1552	PALAMETER SETTING ERROR (SERVO2)	---	The parameter setting error or a failure of SERVOPACK EEPROM or peripheral circuit is suspected.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the parameter settings.</li> <li>• Replace the SERVOPACK.</li> </ul>
1553	COMBINATION SETTING ERROR (SERVO2)	---	The SERVOPACK and motor capacity match or the SERVOPACK board is damaged.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the SERVOPACK and motor capacities.</li> <li>• Replace the SERVOPACK.</li> </ul>

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1554	OVER CURRENT (SERVO2)	---	A ground fault along the motor power line, interphase short-circuiting, motor error, or SERVOPACK error is suspected.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check if a ground fault has not occurred in the U-, V-, and W-phase of motor power line, or short circuit has not occurred between these phases.</li> <li>• Turn the power off and naturally cool down the manipulator. If the error does not occur again after natural cooling, review the manipulator motion conditions (such as influence by external force and load condition) and ambient operating temperature.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1555	ENCODER BACK-UP ERROR (SERVO2)	---	The voltage drop of encoder backup battery is suspected.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check the connection and voltage of the encoder backup battery.</li> <li>• Correct the encoder connection.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1556	ENCODER INTERNAL DATA ERROR (SERVO2)	---	Serial encoder memory error occurred.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1557	ENCODER ABSOLUTE ERROR (SERVO2)	---	Serial encoder internal parameter error occurred.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the encoder connection.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1558	ENCODER SPEED ERROR (SERVO2)	---	When the power turned ON, the motor speed may have exceeded the threshold speed.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1559	COMMUNICATION GATE ARRAY ERROR (SERVO2)	---	The MECHATROLINK communication ASIC error occurred.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1560	SYSTEM ERROR (SERVO2)	---	The internal program error occurred in the SERVOPACK.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1561	BROKEN PG LINE(A-, B-PHASE) (SERVO2)	---	The A-phase or B-phase of encoder is disconnected.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the encoder connection.</li> <li>• Check for noise.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1562	BROKEN PG LINE(C-PHASE) (SERVO2)	---	The C-phase of encoder is disconnected.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the encoder connection.</li> <li>• Check for noise.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1563	ENCODER MULTI-RETURN LIMIT SETTING ERROR (SERVO2)	---	A clearance or setup of the absolute encoder multi-turn quantity could not be performed correctly.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1564	COMMUNICATION ERROR (ENCODER) (SERVO2)	---	A communication error occurred between encoder and SERVOPACK.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the encoder connection.</li> <li>• Check for noise.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1565	ENCODER PARAMETER ERROR (SERVO2)	---	The encoder parameter error occurred.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1566	ENCODER ECHO BACK ERROR (SERVO2)	---	Communication with the encoder is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the encoder connection.</li> <li>• Check for noise.</li> <li>• Check for FG.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1567	ENCODER MULTI-RETURN LIMIT UNMATCH (SERVO2)	---	The multi-turn limit value is different between the encoder and the SERVOPACK.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1568	NO OPTION (SERVO2)	---	A COMI error occurred in the SERVOPACK.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1571	COMMUNICATION WATCH DOG ERROR (SERVO2)	---	WDT data updates is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1572	COMMUNICATION ERROR (SERVO2)	---	The MECHATROLINK communication error occurred.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check the wiring around the MECHATROLINK communication cable.</li> <li>• Take some action against noises from the MECHATROLINK communication cable.</li> <li>• Replace the SERVOPACK.</li> </ul>
1573	SERVO PACK FAILURE (SERVO2)	---	A failure of the SERVOPACK.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1576	COMMAND EXECUTE NOT READY (SERVO2)	---	A error occurred in the SERVOPACK.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
1578	MOTOR LINE DISCONNECTION ALARM (SERVO2)	---	The motor power line disconnection may be the cause.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check for motor power line.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1579	MOTOR LINE DISCONNECTION ALARM (SERVO2)	---	The motor power line disconnected may be the cause.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check for motor power line.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1582	CURRENT DETECTOR ERROR (SERVO2)	---	The motor power cable is disconnected. Or the current detector of the SERVOPACK error.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check for motor power line.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1583	PHASE DETECTION ERROR (SERVO2)	---	The encoder's A, B, C phase output phases are incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Correct the encoder connection.</li> <li>• Check for noise.</li> <li>• Replace the motor and SERVOPACK.</li> </ul>
1585	MOTOR LOAD POSITION ERROR(SV2)	---	The motor load position deviation exceeded the limit.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check the connection of mechanical combination.</li> </ul>
1590	MC POWER SUPPLY WIRING ERR(SV2)	---	The method of the power supply to a main circuit is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> <li>• Check the connection of power supply of AC/DC.</li> <li>• Check the regenerative resistor.</li> <li>• Replace the SERVOPACK.</li> </ul>
1592	MONITOR PLD ERROR 1 (SERVO I/O)	---	External WDT failure was detected in TU.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, replace the TU circuit board.</p>
1593	MONITOR PLD ERROR 2 (SERVO I/O)	---	External WDT timeout was detected in TU.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, replace the TU circuit board.</p>

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
1594	MONITOR PLD ERROR 3 (SERVO I/O)	---	Error between WDTs was detected in TU.	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the TU circuit board.
4000	MEMORY ERROR (TOOL FILE)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the tool file is damaged.</li> </ul>	Initialize the tool file in maintenance mode, and then load the tool file saved in the external memory device.
4001	MEMORY ERROR (USER COORD FILE)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the user coordinates file is damaged.</li> </ul>	Initialize the user coordinates file in maintenance mode, and then load the user coordinates file saved in the external memory device.
4002	MEMORY ERROR (SV MON SIGNAL FILE)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the servo monitor signal file is damaged.</li> </ul>	Initialize the servo monitor signal file in maintenance mode, and then load the servo monitor signal file saved in the external memory device.
4003	MEMORY ERROR (WEAVING FILE)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the weaving condition file is damaged.</li> </ul>	Initialize the weaving condition file in maintenance mode, and then load the weaving condition file saved in the external memory device.
4004	MEMORY ERROR (HOME POS FILE)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the home positioning file is damaged.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and set the home positioning data (absolute data) again.</li> <li>Load the home positioning file saved in the external memory device.</li> </ul>
4005	MEMORY ERROR (SECOND HOME POS)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the second home position file is damaged.</li> </ul>	Load the second home position file saved in the external memory device.
4006	MEMORY ERROR (POWER SOURCE COND)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the arc welding Power Source condition file is damaged.</li> </ul>	Initialize the arc welding Power Source condition file in the maintenance mode, and then load the arc welding Power Source condition file saved in the external memory device.
4007	MEMORY ERROR (ARC START COND FILE)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the arc start condition file is damaged.</li> </ul>	Initialize the arc start condition file in the maintenance mode, and then load the arc start condition file saved in the external memory device.
4008	MEMORY ERROR (ARC END COND FILE)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the arc end condition file is damaged.</li> </ul>	Initialize the arc end condition file in the maintenance mode, and then load the arc end condition file saved in the external memory device.
4009	MEMORY ERROR (ARC AUX COND FILE)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the arc auxiliary condition file is damaged.</li> </ul>	Initialize the arc auxiliary condition file in the maintenance mode, and then load the arc auxiliary condition file saved in the external memory device.
4010	MEMORY ERROR (COM-ARC COND FILE)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the COM-ARC condition file is damaged.</li> </ul>	Initialize the COM-ARC condition file in the maintenance mode, and then load the COM-ARC condition file saved in the external memory device.
4012	MEMORY ERROR (LINK SERVOFLOAT)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the link servo float condition file is damaged.</li> </ul>	Initialize the link servo float condition file in the maintenance mode, and then load the link servo float condition file saved in the external memory device.
4013	MEMORY ERROR (LINEAR SERVOFLOAT)	---	An error was detected at memory check. <ul style="list-style-type: none"> <li>The memory for the linear servo float condition file is damaged.</li> </ul>	Initialize the linear servo float condition file in the maintenance mode, and then load the linear servo float condition file saved in the external memory device.

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4014	MEMORY ERROR (ROBOT CARIB FILE)	---	An error was detected at memory check. • The memory for the file for calibration between manipulators is damaged.	Initialize the file for calibration between manipulators in the maintenance mode, and then load the file for calibration between manipulators saved in the external memory device.
4017	MEMORY ERROR (POWER SRC USER DEF)	---	An error was detected at memory check. • The memory for the Power Source characteristics user definition file is damaged.	Initialize the Power Source characteristics user definition file in the maintenance mode, and then load the Power Source characteristics user definition file saved in the external memory device.
4018	MEMORY ERROR (LADDER PRG FILE)	---	An error was detected at memory check. • The memory for the ladder program file is damaged.	Initialize the ladder program file in the maintenance mode, and then load the ladder program file saved in the external memory device.
4019	MEMORY ERROR (CUTTING COND FILE)	---	An error was detected at memory check. • The memory for the user coordinates file is damaged.	Initialize the user coordinates file in the maintenance mode, and then load the user coordinates file saved in the external memory device.
4020	MEMORY ERROR (WORK HOME POS FILE)	---	An error was detected at memory check. • The memory for the work home position file is damaged.	Initialize the work home position file.
4021	MEMORY ERROR (CONVEYOR COND FILE)	---	An error was detected at memory check. • The memory for the conveyor condition file is damaged.	Initialize the conveyor condition file in the maintenance mode, and then load the conveyor condition file saved in the external memory device.
4024	MEMORY ERROR (WRIST WEAV AMP FILE IS DAMAGED)	---	The error was detected at the memory check. • The wrist weav amp file is damaged.	Initialize the wrist weaving amplitude interruption job file in maintenance mode, and then load the wrist weaving amplitude file saved in the external memory device.
4025	MEMORY ERROR (INTERRUPT JOB FILE)	---	An error was detected at memory check. • The memory for the interrupt job file is damaged.	Initialize the interrupt job file in the maintenance mode, and then load the interrupt job file saved in the external memory device.
4028	MEMORY ERROR (SENSOR MON COND FILE)	---	An error was detected at memory check. • The memory for the sensor monitoring condition file is damaged.	Initialize the sensor monitoring condition file in the maintenance mode, and then load the sensor monitoring condition file saved in the external memory device.
4031	MEMORY ERROR (GUN COND FILE)	---	An error was detected at memory check. • The memory for the spot welding gun condition file is damaged.	Initialize the spot welding gun condition file in the maintenance mode, and then load the spot welding gun condition file saved in the external memory device.
4032	MEMORY ERROR (SPOT WELD COND)	---	An error was detected at memory check. • The memory for the spot welding Power Source condition file is damaged.	Initialize the spot welding SPOT WELD condition file in the maintenance mode, and then load the spot welding Power Source condition file saved in the external memory device.
4033	MEMORY ERROR (GUN PRES-SURE FILE)	---	An error was detected at memory check. • The memory for the gun pressure file is damaged.	Initialize the gun pressure file in the maintenance mode, and then load the gun pressure file saved in the external memory device.
4034	MEMORY ERROR (ANTICIPATION OT FILE)	---	An error was detected at memory check. • The memory for the anticipation outputs (OT) file is damaged.	Initialize the anticipation outputs file in the maintenance mode, and then load the anticipation outputs file saved in the external memory device.
4035	MEMORY ERROR (ANTICIPATION OG FILE)	---	An error was detected at memory check. • The memory for the anticipation outputs (OG) file is damaged.	Initialize the anticipation outputs file in the maintenance mode, and then load the anticipation outputs file saved in the external memory device.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4036	MEMORY ERROR (WEARING FILE)	---	An error was detected at memory check. • The memory for the wear amount file is damaged.	Initialize the wear amount file in the maintenance mode, and then load the wear amount file saved in the external memory device.
4037	MEMORY ERROR (STROKE POSITION)	---	An error was detected at memory check. • The memory for the FULL/SHORT OPEN position setting file is damaged.	Initialize the FULL/SHORT OPEN position setting file in the maintenance mode, and then load the FULL/SHORT OPEN position setting file saved in the external memory device.
4038	MEMORY ERROR (PRESSURE FILE)	---	An error was detected at memory check. • The memory for the dry-spotting pressure file is damaged.	Initialize the dry-spotting pressure file in the maintenance mode, and then load the dry-spotting pressure file saved in the external memory device.
4039	MEMORY ERROR (FORM CUT FILE)	---	An error was detected at memory check. • The memory for the form cut file is damaged.	Initialize the form cut file in the maintenance mode, and then load the form cut file saved in the external memory device.
4040	MEMORY ERROR (SHOCK LEVEL FILE)	---	An error was detected at memory check. • The memory for the shock level file is damaged.	Initialize the shock level file in the maintenance mode, and then load the shock level file saved in the external memory device.
4041	MEMORY ERROR (SPOT I/O ALLOCATE FL)	---	An error was detected at memory check. • The memory for the spot I/O allocation file is damaged.	Initialize the spot I/O allocation file in the maintenance mode, and then load the spot I/O allocation file saved in the external memory device.
4042	MEMORY ERROR (VISION FILE)	---	An error was detected at memory check. • The memory for the vision condition file is damaged.	Initialize the vision condition file in the maintenance mode, and then load the vision condition file saved in the external memory device.
4043	MEMORY ERROR (VISION CALIBRATION)	---	An error was detected at memory check. • The memory for the vision calibration file is damaged.	Initialize the vision calibration file in the maintenance mode, and then load the vision calibration file saved in the external memory device.
4044	MEMORY ERROR (WELDING PULSE COND FILE)	---	An error was detected at memory check. • The memory for the welding pulse condition file is damaged.	Initialize the welding pulse condition file in the maintenance mode, and then load the welding pulse condition file saved in the external memory device.
4045	MEMORY ERROR (WELDING PULSE SELECTION FILE)	---	An error was detected at memory check. • The memory for the welding pulse selection file is damaged.	Initialize the welding pulse selection file in the maintenance mode, and then load the welding pulse selection file saved in the external memory device.
4046	MEMORY ERROR (CONVEYOR CALIBRATION)	---	An error was detected at memory check. • The memory for the conveyor calibration file is damaged.	Initialize the conveyor calibration file in the maintenance mode, and then load the conveyor calibration file saved in the external memory device.
4047	MEMORY ERROR (MACRO DEFINITION FILE)	---	An error was detected at memory check. • The memory for the macro definition file is damaged.	Initialize the macro definition file in the maintenance mode, and then load the macro definition file saved in the external memory device.
4048	MEMORY ERROR (SERVO S-GUN FILE)	---	An error was detected at memory check. • The memory for the sealer gun characteristics file is damaged.	Initialize the sealer gun characteristics file in the maintenance mode, and then load the sealer gun characteristics file saved in the external memory device.



Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4049	MEMORY ERROR (PASTE QUAN COMPENSATION FILE)	---	An error was detected at memory check. • The memory for the painting amount correction file is damaged.	Initialize the painting amount correction file in the maintenance mode, and then load the painting amount correction file saved in the external memory device.
4050	MEMORY ERROR (AXIS I/O ALLOCATION FILE)	---	An error was detected at memory check. • The memory for the axis motion I/O allocation file is damaged.	Initialize the axis motion I/O allocation file in the maintenance mode, and then load the axis motion I/O allocation file saved in the external memory device.
4051	MEMORY ERROR (GUN COND AUX FILE)	---	An error was detected at memory check. • The memory for the gun characteristics auxiliary file is damaged.	Initialize the gun characteristics auxiliary file in the maintenance mode, and then load the gun characteristics auxiliary file saved in the external memory device.
4052	MEMORY ERROR (TOOL INTERFERENCE FILE)	---	An error was detected at memory check. • The memory for the tool interference file is damaged.	Initialize the tool interference file in the maintenance mode, and then load the tool interference file saved in the external memory device.
4053	MEMORY ERROR (PAINTING SYSTEM CONFIGURATION)	---	An error was detected at memory check. • The memory for the painting system setting file is damaged.	Initialize the painting system setting file in the maintenance mode, and then load the painting system setting file saved in the external memory device.
4054	MEMORY ERROR (PAINTING SPECIAL)	---	An error was detected at memory check. • The memory for the painting device characteristics file is damaged.	Initialize the painting device characteristics file in the maintenance mode, and then load the painting device characteristics file saved in the external memory device.
4055	MEMORY ERROR (CCV-PAINT TABLE)	---	An error was detected at memory check. • The memory for the painting CCV file is damaged.	Initialize the painting CCV file in the maintenance mode, and then load the painting CCV file saved in the external memory device.
4056	MEMORY ERROR (PLUG VOLUME FILE)	---	An error was detected at memory check. • The memory for the paint filling file is damaged.	Initialize the paint filling file in the maintenance mode, and then load the paint filling file saved in the external memory device.
4057	MEMORY ERROR (EVB GUN COND)	---	An error was detected at memory check. • The memory for the EVB gun file is damaged.	Initialize the EVB gun file in the maintenance mode, and then load the EVB gun file saved in the external memory device.
4058	MEMORY ERROR (EVB TURBINE COND)	---	An error was detected at memory check. • The memory for the EVB turbine file is damaged.	Initialize the EVB turbine file in the maintenance mode, and then load the EVB turbine file saved in the external memory device.
4059	MEMORY ERROR (EVB PAINT COND)	---	An error was detected at memory check. • The memory for the EVB paint file is damaged.	Initialize the EVB paint file in the maintenance mode, and then load the EVB paint file saved in the external memory device.
4060	MEMORY ERROR (CLEARANCE FILE)	---	An error was detected at memory check. • The memory for the clearance file is damaged.	Initialize the clearance file in the maintenance mode, and then load the clearance file saved in the external memory device.
4061	MEMORY ERROR (GAGING SENSOR FILE)	---	An error was detected at memory check. • The memory for the gaging sensor file is damaged.	Initialize the gaging sensor file in the maintenance mode, and then load the gaging sensor file saved in the external memory device.
4062	MEMORY ERROR (LINEAR SCALE FILE)	---	An error was detected at memory check. • The memory for the linear scale condition file is damaged.	Initialize the linear scale condition file in the maintenance mode, and then load the linear scale condition file saved in the external memory device.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4063	MEMORY ERROR (CONVEYOR COND SUPP.)	---	An error was detected at memory check. • The memory for the conveyor condition auxiliary file is damaged.	Initialize the conveyor condition auxiliary file in the maintenance mode, and then load the conveyor condition auxiliary file saved in the external memory device.
4064	MEMORY ERROR (WEAVING SYNCHRONIZING WELD FILE)	---	An error was detected at memory check. • The memory for the weaving synchronizing welding condition file is damaged.	Initialize the weaving synchronizing welding condition file in the maintenance mode, and then load the weaving synchronizing welding condition file saved in the external memory device.
4065	MEMORY ERROR (I/F PANEL FILE)	---	An error was detected at memory check. • The memory for the I/F panel file is damaged.	Initialize the I/F panel file in the maintenance mode, and then load the I/F panel file saved in the external memory device.
4069	MEMORY ERROR (PALLETIZING COND FILE)	---	An error was detected at memory check. • The memory for the palletizing condition file is damaged.	Initialize the palletizing condition file in the maintenance mode, and then load the palletizing condition file saved in the external memory device.
4100	OVERRUN (ROBOT AXIS)	---	One of the manipulator overrun limit switches activated.	Move back the manipulator out of the overrun limit switch range. (Refer to the INSTRUCTIONS.)
4101	OVERRUN (EXTERNAL AXIS)	---	One of the external-axis overrun limit switches activated.	Move back the external axis out of the overrun limit switch range. (Refer to the INSTRUCTIONS.)
4102	SYSTEM DATA HAS BEEN CHANGED	1	The system parameters are modified. • An attempt was made to turn ON the servo power supply after having modified the system parameters. The data indicates the cause of alarm. 1: System parameter modified	Turn the power OFF then back ON.
4103	PARALLEL START INSTRUCTION ERROR		An error occurred in the independent control startup operation.	
		1	• Sub task being executed: Although a job is being executed by instructed sub task, an attempt was made to execute another job by the sub task.	Complete the sub task by PWAIT command.
		2	• Group axis being used: The job operated by another sub task uses the same group axis.	Check the job to be started and the execution timing for start command again.
		3	• Multiple start of same job: The job that was tried to be started was executed by another sub task.	
		4	• Unregistered master job: Although the master job was not registered, an attempt was made to execute PSTART SUB (job name omitted).	Register the master job for sub task.
		5	• Synchronization instruction error: When restarted by PSTART, synchronization instruction status of the sub task under interruption was different from the status to restart.	Check the job to be started and the execution timing for start command again.



## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4103	PARALLEL START INSTRUCTION ERROR	An error occurred in the independent control startup operation.		Reset the alarm, and then start the sub task.
		6	<ul style="list-style-type: none"> <li>Stopped by an alarm: An attempt was made to start the sub task which is stopped by an alarm.</li> </ul>	
4104	WRONG EXECUTION OF LOAD INST	---	An error occurred when an instruction was executed by the data transmission DCI function. The data indicates the cause of alarm. (Refer to the manual for Data Transmission Function for details.)	Reset the alarm, and then remove the cause according to the alarm data.
4105	WRONG EXECUTION OF SAVE INST	---	An error occurred when an instruction was executed by the data transmission DCI function. The data indicates the cause of alarm. (Refer to the manual for Data Transmission Function for details.)	Reset the alarm, and then remove the cause according to the alarm data.
4106	WRONG EXECUTION OF DELETE INST	---	An error occurred when an instruction was executed by the data transmission DCI function. The data indicates the cause of alarm. (Refer to the manual for Data Transmission Function for details.)	Reset the alarm, and then remove the cause according to the alarm data.
4107	OUT OF RANGE (ABSO DATA)	---	The position difference between when the power was turned OFF and when the power was turned ON again exceeded the tolerance for the manipulator or a station.	<ul style="list-style-type: none"> <li>Move the manipulator or station to the zero position by the axis operation and check the home position alignment marks (the arrow).</li> <li>If the zero position does not match the home position, check if there is no error in the PG system of the axis for which the alarm occurred.</li> </ul>
4109	DC24V POWER SUPPLY FAILURE (I/O)	0000_00**	The external 24V power for I/Os is not output. 0000_0001: Fuse blown (NIF01 unit) 0000_0011: External 24 V power supply error	<ul style="list-style-type: none"> <li>Check if the fuse of robot I/F unit (NIF) is not blown.</li> <li>Check the 24V external power supply.</li> <li>Check the communications cable for the I/O module</li> </ul> If the error occurs again, contact your Yaskawa representative.
4110	SHOCK SENSOR ACTIVATION	---	The shock sensor activated.	Remove the cause of shock sensor activation.
4111	BRAKE FUSE BREAKDOWN	---	The brake fuse blew out.	Replace the fuse.
4112	DATA SENDING ERROR	An error occurred during data transmission.		Reset the alarm, and then remove the cause.
		1	<ul style="list-style-type: none"> <li>Retry over of NAK</li> </ul>	
		2	<ul style="list-style-type: none"> <li>Retry over for timeout in timer A</li> </ul>	
		3	<ul style="list-style-type: none"> <li>Retry over for mutual response error</li> </ul>	
4113	DATA RECEIVING ERROR	An error occurred during data transmission.		Reset the alarm, and then remove the cause.
		1	<ul style="list-style-type: none"> <li>Reception timeout (timer A)</li> </ul>	
		2	<ul style="list-style-type: none"> <li>Reception timeout (timer B)</li> </ul>	
		3	<ul style="list-style-type: none"> <li>Heading length is too short.</li> </ul>	
		4	<ul style="list-style-type: none"> <li>Heading length is too long.</li> </ul>	
		5	<ul style="list-style-type: none"> <li>The header No. error</li> </ul>	
		6	<ul style="list-style-type: none"> <li>The text length exceeded 256 characters.</li> </ul>	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4113	DATA RECEIVING ERROR		An error occurred during data transmission.	Reset the alarm, and then remove the cause.
		7	• An unexpected control code was received.	
4114	TRANSMISSION HARDWARE ERROR		An error occurred during data transmission.	Reset the alarm, and then remove the cause.
		1	• Overrun error	
		2	• Parity error	
		3	• Framing error	
		4	• Transmission timeout (timer A)	
		5	• Transmission timeout (timer B)	
4115	TRANSMISSION SYSTEM BLOCK		An error occurred during data transmission. (This alarm occurs when received data cause inconsistency on the system although the transmission protocol is correct. Mainly, this alarm occurs due to an illegal transmission or erroneous report at the data sending side.)	Reset the alarm, and then remove the cause.
		1	• Received EOT while waiting ACK.	
		2	• Received EOT while waiting ENQ.	
		3	• Received EOT before last block reception.	
		4	• Received codes other than EOT after last block reception.	
4116	TRANSMISSION SYSTEM ERROR	---	An error occurred during data transmission.	If the error occurs again, contact your Yaskawa representative.
4117	BRAKE POWER ERROR	---	The power for brake is not output. An error occurred due to ground fault or short circuit of the brake wiring. Or the fuse of optional unit (NBP□□) or brake release unit (NBU□□) is blown.	• Verify the brake wiring. If the fuse is blown, check the wiring, then replace the fuse. If the error occurs again, contact your Yaskawa representative.
4118	TRIPPED CIRCUIT PROTECTOR OF IN-PANEL FAN	XY	The circuit protector of the in-panel cooling fan is tripped due to ground fault or short circuit or the in-panel cooling fan, or defective fan. Note: This alarm is displayed approximately one minute after the detection. X...Servo board 1: Servo board1 (SV#1) 2: Servo board2 (SV#2) 3: Servo board3 (SV#3) 4: Servo board4 (SV#4) Y...Power-ON unit 1: Power-ON unit1 (TU#1) 2: Power-ON unit2 (TU#2) 3: Power-ON unit3 (TU#3) 4: Power-ON unit4 (TU#4) 5: Power-ON unit5 (TU#5) 6: Power-ON unit6 (TU#6)	• Verify the wiring of in-panel cooling fan. If there is no defect in the wiring, replace the cooling fan since the fan may be defective.
4119	FAN ERROR (IN CONTROL BOX)	X	The rotation speed of in-panel cooling fan decreased. X...CPS unit number 1: CPS unit 1(Detected with SV#1) 2: CPS unit 2(Detected with SV#2) 3: CPS unit 3(Detected with SV#3) 4: CPS unit 4(Detected with SV#4)	• Reset the alarm, and then move the manipulator to the safe position in the teach mode. • Check if in-panel cooling fan is rotating. If the fan is not working, verify its wiring. Should the error persist, replace the in-panel cooling fan (CPS power unit).

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4121	COOLING FAN 1 ERROR	XY	The rotation speed of the cooling fan 1 with alarm sensor connected to the contactor unit decreased. X...Servo board 1: Servo board1 (SV#1) 2: Servo board2 (SV#2) 3: Servo board3 (SV#3) 4: Servo board4 (SV#4) Y...Power-ON unit 1: Power-ON unit1 (TU#1) 2: Power-ON unit2 (TU#2) 3: Power-ON unit3 (TU#3) 4: Power-ON unit4 (TU#4) 5: Power-ON unit5 (TU#5) 6: Power-ON unit6 (TU#6)	<ul style="list-style-type: none"> <li>Reset the alarm, and then move the manipulator to the safe position in the teach mode.</li> <li>The cooling fan 1 needs to be replaced. Contact your Yaskawa representative.</li> </ul>
4122	COOLING FAN 2 ERROR	XY	The rotation speed of the cooling fan 2 with alarm sensor connected to the contactor unit decreased. X...Servo board 1: Servo board1 (SV#1) 2: Servo board2 (SV#2) 3: Servo board3 (SV#3) 4: Servo board4 (SV#4) Y...Power-ON unit 1: Power-ON unit1 (TU#1) 2: Power-ON unit2 (TU#2) 3: Power-ON unit3 (TU#3) 4: Power-ON unit4 (TU#4) 5: Power-ON unit5 (TU#5) 6: Power-ON unit6 (TU#6)	<ul style="list-style-type: none"> <li>Reset the alarm, and then move the manipulator to the safe position in the teach mode.</li> <li>The cooling fan 2 needs to be replaced. Contact your Yaskawa representative.</li> </ul>
4123	COOLING FAN 3 ERROR	XY	The rotation speed of the cooling fan 3 with alarm sensor connected to the contactor unit decreased. X...Servo board 1: Servo board1 (SV#1) 2: Servo board2 (SV#2) 3: Servo board3 (SV#3) 4: Servo board4 (SV#4) Y...Power-ON unit 1: Power-ON unit1 (TU#1) 2: Power-ON unit2 (TU#2) 3: Power-ON unit3 (TU#3) 4: Power-ON unit4 (TU#4) 5: Power-ON unit5 (TU#5) 6: Power-ON unit6 (TU#6)	<ul style="list-style-type: none"> <li>Reset the alarm, and then move the manipulator to the safe position in the teach mode.</li> <li>The cooling fan 3 needs to be replaced. Contact your Yaskawa representative.</li> </ul>
4130	NETWORK APPLICATION ERROR	1	An error occurred when the notification of the APP task re-initialization was processed in the Ethernet function.	<ul style="list-style-type: none"> <li>Rotate the mode selector switch on the programming pendant to release the mode setting which has been set to "REMOTE", then rotate the switch again to set back to "REMOTE".</li> <li>If the error occurs again after releasing the mode setting of the switch and setting back to "REMOTE", turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
		2	An error occurred when the re-initialization response was received in the Ethernet function.	
		3	The incomplete task of re-initialization was unsuccessfully completed in the Ethernet function.	
		4	An error occurred when the semaphore for re-initialization was received in the Ethernet function.	
		5	An error occurred when the re-initialization mail was sent in the Ethernet function.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4130	NETWORK APPLICATION ERROR	6	An error occurred in the exclusive process of the storage area control table of the Ethernet function.	<ul style="list-style-type: none"> <li>• Rotate the mode selector switch on the programming pendant to release the mode setting which has been set to "REMOTE", then rotate the switch again to set back to "REMOTE".</li> <li>• If the error occurs again after releasing the mode setting of the switch and setting back to "REMOTE", turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
		7	Time-out occurred in the re-initialization response receiving process of the Ethernet function.	
		8	An error occurred in the re-initialization response receiving process of the Ethernet function.	
		9	Receiving data size error occurred in the re-initialization response receiving process of the Ethernet function.	
		30	An error occurred in the Web server task mail receiving process of the Ethernet function.	
		31	An error occurred in the FTP server task mail receiving process of the Ethernet function.	
		32	An error occurred in the FTP client task mail receiving process of the Ethernet function.	
		40	Illegal e-mail data were received in the Web server task of the Ethernet function.	
		41	Illegal e-mail data were received in the FTP server task of the Ethernet function.	
		42	Illegal e-mail data were received in the FTP client task of the Ethernet function.	
		50	An error occurred in the data size written to PCI of the Ethernet function.	
		51	An error occurred when the request to write PCI data was received in the Ethernet function.	
		52	The request of the undefined transmission was received in the Ethernet function.	
		53	An error occurred in the transmission request of the Ethernet function.	
		54	The transmission request without data was received in the Ethernet function.	
		55	The transmission request of illegal data length was received in the Ethernet function.	
		60	Illegal mail data were received in the DNS task of the Ethernet function.	
		61	Illegal mail data was transmitted in the DNS task of the Ethernet function.	
		100	An error occurred in storing process of memory which is used in the Ethernet function.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4130	NETWORK APPLICATION ERROR	101	An error occurred in the buffer for request to write PCI getting process of the Ethernet function.	<ul style="list-style-type: none"> <li>• Rotate the mode selector switch on the programming pendant to release the mode setting which has been set to "REMOTE", then rotate the switch again to set back to "REMOTE".</li> <li>• If the error occurs again after releasing the mode setting of the switch and setting back to "REMOTE", turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
		200	The socket of the Ethernet function was full and was not able to create a socket.	
		201	An error occurred in the semaphore of socket control table of the Ethernet function.	
4131	UDP COMMUNICATION ERROR	1	An error occurred in the creation of receiving socket during the UDP process of the Ethernet function.	<ul style="list-style-type: none"> <li>• Rotate the mode selector switch on the programming pendant to release the mode setting which has been set to "REMOTE", then rotate the switch again to set back to "REMOTE".</li> <li>• If the error occurs again after releasing the mode setting of the switch and setting back to "REMOTE", turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
		2	An error occurred in the creation of transmission socket during the UDP process of the Ethernet function.	
		3	Illegal data were received in the UDP process of the Ethernet function.	
		4	Transmission error occurred in the UDP process of the Ethernet function.	
		5	The SELECT operation was not successfully completed in the UDP process of the Ethernet function.	
		100	The re-initialization notification of illegal data length was received in the UDP process of the Ethernet function.	
		101	The re-initialization notification of illegal data was received in the UDP process of the Ethernet function.	
		102	The PCI write process was not successfully completed in the UDP process of the Ethernet function.	
		103	The transmission request of illegal data length was received in the UDP process of the Ethernet function.	
		104	The transmission request of illegal data was received in the UDP process of the Ethernet function.	
4132	TCP COMMUNICATION ERROR	1	The socket table was not successfully created in the TCP process of the Ethernet function.	<ul style="list-style-type: none"> <li>• Rotate the mode selector switch on the programming pendant to release the mode setting which has been set to "REMOTE", then rotate the switch again to set back to "REMOTE".</li> <li>• If the error occurs again after releasing the mode setting of the switch and setting back to "REMOTE", turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
		2	An error occurred in the process of the TCP server initialization of the Ethernet function.	
		3	An error occurred in connection detecting process of TCP server of the Ethernet function.	
		4	An error occurred in the connection detection checking process of TCP server of the Ethernet function.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4135	TOYOPUC RUN STOP	0	TOYOPUC is in stopped state.	Use the PCwin, etc. to run the TOYOPUC, then reset the alarm for the NX100, or turn ON the power supply again.
4136	TOYOPUC MAJOR ERROR	0	The PCI bus state of the TOYO-PUC turns to "ER". An error occurred in the processing on the TOYOPUC side.	<ul style="list-style-type: none"> <li>Rotate the mode selector switch on the programming pendant to release the mode setting which has been set to "REMOTE", then rotate the switch again to set back to "REMOTE".</li> <li>If the error occurs again after releasing the mode setting of the switch and setting back to "REMOTE", turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		1	INTRB time-out error An error occurred in the PCI bus communication processing of the TOYOPUC.	
		2	The INTPC does not turn to "1" five seconds after the PCI command is issued. An error occurred in the PCI bus communication processing of the TOYOPUC.	
		3	Error in the state of interrupt register1 An error occurred in the PCI bus communication processing of the TOYOPUC	
4137	SETUALM ERROR	1	An error occurred at SETUALM instruction execution. Alarm code specification error	Specify the alarm in the range 8000 to 8999.
		2	An error occurred at SETUALM instruction execution. Task specification error	Specify the task in the range 0 to 4 (7 at expansion).
		3	An error occurred at SETUALM instruction execution. Motion mode specification error	Set the motion mode to 0 or 1.
4138	SVON ERROR	---	An error occurred at SVON instruction execution. SVON is disabled.	<ul style="list-style-type: none"> <li>Verify that the external servo ON (EXSVON) is short-circuited.</li> <li>Verify that the concurrent I/O signal #80031 (servo ON condition1) and #80033 (servo ON condition2) are turned ON.</li> </ul>
4139	PRINT ERROR	---	An error occurred at PRINT instruction execution. PRINT output conversion spec (character string specification) error	Review the PRINT output conversion spec (character string specification).
4140	DIALOG ERROR	An error occurred at execution of the DIALOG instruction.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> <li>Turn the power OFF and back ON.</li> </ul>
		1	DIALOG instruction control error	
		2	Messages and buttons are not registered.	Review DIALOG instruction.
		3	Buttons are not registered.	
		4	The length of character string was exceeded.	
4141	SNTP ERROR	1	The error on setting of time difference value occurred in the SNTP process of the Ethernet function.	<ul style="list-style-type: none"> <li>Turn the power OFF and back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		2	The error on setting of time-out value occurred in the SNTP process of the Ethernet function.	
		3	The error on setting of reference interval value occurred in the SNTP process of the Ethernet function.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4141	SNTP ERROR	4	The IP address error occurred in the SNTP process of the Ethernet function.	<ul style="list-style-type: none"><li>• Correctly set the IP address of the SNTP server.</li><li>• If the DHCP is used, verify the DHCP server operation and the network status.</li></ul>
		5	Time-out occurred in the SNTP process of the Ethernet function.	Verify the SNTP server operation and the network status.
		6	The server time is not synchronized in the SNTP process of the Ethernet function.	Verify the SNTP server operation.
		7	The SNTP process of the Ethernet function is not compliant with the version that the server sent.	Use the server compliant with the SNTP version 3.
		8	Illegal parameters were found in the SNTP process of the Ethernet function.	<ul style="list-style-type: none"><li>• Verify the SNTP related settings.</li></ul> If the error occurs again, contact your Yaskawa representative.
		9	The SNTP process of the Ethernet function was not successfully completed.	
		10	The name resolution error occurred in the SNTP process of the Ethernet function.	<ul style="list-style-type: none"><li>• Set a correct IP address for the SNTP server.</li><li>• When the DHCP is used, verify the DHCP server operation and the network status.</li></ul>
		11	The error on getting of server address occurred in the SNTP process of the Ethernet function.	<ul style="list-style-type: none"><li>• When the DHCP is used, verify the DHCP server operation.</li></ul>
		12	The server setting is incorrect in the SNTP process of the Ethernet function.	<ul style="list-style-type: none"><li>• Set a correct IP address for the SNTP server.</li></ul>
4200	SYSTEM ERROR (FILE DATA)	---	An error occurred during the access to file data (during file edition or external memory device operation).	<ul style="list-style-type: none"><li>• Reset the alarm, and then try again.</li><li>• Turn the power OFF then back ON.</li></ul> If the error occurs again, contact your Yaskawa representative.
4201	SYSTEM ERROR (JOB)	An error occurred when accessing to job data.		<ul style="list-style-type: none"><li>• Reset the alarm, and then try again.</li><li>• Turn the power OFF then back ON.</li></ul> If the error occurs again, contact your Yaskawa representative.
		-1	<ul style="list-style-type: none"><li>• An error occurred in parameter specification.</li></ul>	
		-2	<ul style="list-style-type: none"><li>• Access time exceeded the limit.</li></ul>	
		-3	<ul style="list-style-type: none"><li>• The access to a job could not be performed with the specified job name.</li></ul>	
		-4	<ul style="list-style-type: none"><li>• The character not allowed was used as a job name.</li></ul>	
		-5	<ul style="list-style-type: none"><li>• A job was newly created with the same name of the job already specified in the memory.</li></ul>	Delete unused jobs and/or expand CMOS.
		-6	<ul style="list-style-type: none"><li>• The allowable job registration area (memory) was exceeded.</li></ul>	
		-7	<ul style="list-style-type: none"><li>• A job that did not exist in the memory was specified.</li></ul>	
		-8	<ul style="list-style-type: none"><li>• An attempt was made to change the contents for the job prohibited from being edited.</li></ul>	<ul style="list-style-type: none"><li>• Reset the alarm, and then try again.</li><li>• Turn the power OFF then back ON.</li></ul> If the error occurs again, contact your Yaskawa representative.
		-9	<ul style="list-style-type: none"><li>• An error occurred in handle value.</li></ul>	<ul style="list-style-type: none"><li>• Reset the alarm, and then try again.</li><li>• Turn the power OFF then back ON.</li></ul> If the error occurs again, contact your Yaskawa representative.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4201	SYSTEM ERROR (JOB)	-10	• An error occurred in job data control system.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		-11	• An error occurred in sequence number of the accessed job.	
		-12	• An error occurred in step number of the accessed job.	
		-13	• A job specified at job search did not exist in the memory.	
		-14	• There was an instruction that did not exist in a job because of inconsistency of the system software.	Check the NCP01 and NCP02 software versions before/after updating.
		-16	• Unused handles were lacking when an attempt was made to open a job.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		-18	• The number of instructions added to a job exceeded 9999.	Delete unnecessary instructions and add new instructions.
		-19	• The number of steps added to a job exceeded 9999.	Delete unnecessary steps and add new steps.
		-20	• A job was newly created with the same name of the undefined job already specified in the memory.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		-99	• A job data in the memory was destroyed.	
4202	SYSTEM ERROR (JOB)	An error occurred when accessing to job data.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		1	• An error occurred in parameter specification.	
		2	• Access time exceeded the limit.	
		3	• The access to a job could not be performed with the specified job name.	
		4	• The character not allowed was used as a job name.	
		5	• A job was newly created with the same name of the job already specified in the memory.	
		6	• The allowable job registration area (memory) was exceeded.	Delete unused jobs and/or expand CMOS.
		7	• A job that did not exist in the memory was specified.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		8	• An attempt was made to change the contents for the job prohibited from being edited.	Release the prohibition and change it.
		9	• An error occurred in handle value.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		10	• An error occurred in job data control system.	
		11	• An error occurred in sequence number of the accessed job.	



## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4202	SYSTEM ERROR (JOB)	12	• An error occurred in step number of the accessed job.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		13	• A job specified at job search did not exist in the memory.	
		14	• There was an instruction that did not exist in a job because of inconsistency of the system software.	Check the NCP01 and NCP02 software versions before/after updating.
		16	• Unused handles were lacking when an attempt was made to open a job.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		18	• The number of instructions added to a job exceeded 9999.	Delete unnecessary instructions and add new instructions.
		19	• The number of steps added to a job exceeded 9999.	Delete unnecessary steps and add new steps.
		20	• A job was newly created with the same name of the undefined job already specified in the memory.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		99	• A job data in the memory was destroyed.	
4203	SYSTEM ERROR (POSITION DATA)	An error occurred in position data control process.		Initialize the job in the maintenance mode.
		-1	• The memory area for position data is lacking at the initialization of the position data control process.	
		-2	• The number of axes for all the control groups is zero at the initialization of the position data control process	
		-3	• The number of axes for position data is zero.	<ul style="list-style-type: none"> <li>• When the data is loaded from the external memory, the control axis for external memory is different from that for system. Initialize the job.</li> <li>• When a point is added, the job is not initialized after the control axis for system was changed to a different control group by system configuration. Initialize the job.</li> </ul>
		-4	• The number of stored position data exceeded the maximum stored data at the initialization of the position data control process.	Initialize the job in the maintenance mode.
		-5	• The memory size of the position data exceeded the maximum memory size at the initialization of the position data control process.	
		-6	• Unused position data file is destroyed.	
		-7	• Unused position data file does not exist.	Delete unnecessary steps (position data) and add position data.
		-8	• Position data file is destroyed.	Initialize the job in the maintenance mode.
		-9	• Position data control information is destroyed.	
		-10	• An error occurred in specified position data number.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4203	SYSTEM ERROR (POSITION DATA)	-11	• Position data is not registered.	If the error occurs again, contact your Yaskawa representative.
		-12	• An attempt was made to access the undefined position data.	
		-13	• An attempt was made to access the position data for the undefined control group.	
		-14	• Position data control is not initialized.	
		-15	• The number of axes for the control groups exceeded the limit.	
		-16	• An error occurred in exclusive control.	
		-17	• An error occurred in exceptional control.	
4204	SYSTEM ERROR (POSITION DATA)	An error occurred in position data control process.		Initialize the job in the maintenance mode.
		1	• The memory area for position data is lacking at the initialization of the position data control process.	
		2	• The number of axes for all the control groups is zero at the initialization of the position data control process	
		3	• The number of axes for position data is zero.	<ul style="list-style-type: none"> <li>• When the data is loaded from the external memory, the control axis for external memory is different from that for system. Initialize the job.</li> <li>• When a point is added, the job is not initialized after the control axis for system was changed to a different control group by system configuration. Initialize the job.</li> </ul>
		4	• The number of stored position data exceeded the maximum stored data at the initialization of the position data control process.	Initialize the job in the maintenance mode.
		5	• The memory size of the position data exceeded the maximum memory size at the initialization of the position data control process.	
		6	• Unused position data file is destroyed.	
		7	• Unused position data file does not exist.	Delete unnecessary steps (position data) and add position data.
		8	• Position data file is destroyed.	Initialize the job in the maintenance mode.
		9	• Position data control information is destroyed.	
		10	• An error occurred in specified position data number.	
		11	• Position data is not registered.	If the error occurs again, contact your Yaskawa representative.
		12	• An attempt was made to access the undefined position data.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4204	SYSTEM ERROR (POSITION DATA)	13	• An attempt was made to access the position data for the undefined control group.	If the error occurs again, contact your Yaskawa representative.
		14	• Position data control is not initialized.	
		15	• The number of axes for the control groups exceeded the limit.	
		16	• An error occurred in exclusive control.	
		17	• An error occurred in exceptional control.	
4206	SYSTEM ERROR (TRANSMISSION)	---	An error occurred in data transmission.	• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
4207	SYSTEM ERROR (MOTION)	A system error occurred in MOTION.		• Reset the alarm, and then try again. • Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.
		1	• An interrupt undefined in the main command from the system control section occurred.	
		2	• An interrupt undefined in the sub command from the system control section occurred.	
		3	• The interrupt command that was sent previously from the system control section is being processed.	
		4	• An error was detected in the interrupt command data from the system control section.	
		5	• An undefined command was detected in the sub segment task of MOTION.	
		6	• An undefined command was detected in the servo-related processing of MOTION.	
		7	• An undefined command was detected in the offline processing task of MOTION.	
		8	• An undefined command was detected in the utility task of MOTION.	
		10	• Task Token is not generated.	
		11	• Mail-box Token is not generated.	
		12	• Semaphore Token is not generated.	
		13	• Memory-pool Token is not generated.	
		14	• RMS receiving data error	
		15	• RMS sending data error	
		16	• RMS receiving unit error	
		17	• RMS sending unit error	
		18	• Task generation error	
		19	• Mail-box generation error	
		20	• Semaphore generation error	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4207	SYSTEM ERROR (MOTION)	A system error occurred in MOTION.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		21	• Token pointer error	
		22	• TCB area overflow	
		23	• Stack area overflow	
		24	• Mail-box area overflow	
		25	• Semaphore area overflow	
		30	• Main command error	
		31	• MSS system - ID number error	
		32	• HA-MSS system number error	
		33	• Incorrect control group designation	
		34	• Offline bank semaphore reception error	
		35	• m_gen_area semaphore reception error	
		36	• Offline HA processing timeout	
		37	• DM_BANK flag error (DM_BANK conversion processing)	
		38	• S → M offline processing command type error	
		39	• SL data transmission request function error	
		40	• Error in designation of application in the request of general-purpose data preset for each application.	
		41	• Error in the parameter to prepare the speed data table	
		42	• Error in the parameter to prepare the global-variable control table	
		43	• Error in the parameter to prepare the axis control table	
		44	• Error in the parameter to prepare the online servo-constant modification table	
		45	• Mail-box of sequence task is not ready.	
		46	• Control-group usage undefined	
		47	• Segment task polling command error	
		48	• Physical axis number error	
		49	• The control group impossible to release the brake	
		50	• Sub-segment request FULL	
		51	• Sub-segment process timeout	
		52	• Data latch request FULL	
		53	• Data latch process timeout	
		54	• AXIS command request FULL	
		55	• AXIS command process timeout	
		56	• Positioning monitor request FULL	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4207	SYSTEM ERROR (MOTION)	A system error occurred in MOTION.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		57	• Positioning monitor process time-out	
		58	• Failed AXIS servo OFF command request during emergency stop	
		60	• Memory pool area overflow	
		61	• Conversion primary expression for Power Source command ↔ EW command not prepared	
		62	• Duplicated request error during master control-group tracking	
		63	• GVM shared resource semaphore error	
		64	• Job queue DEQUE error	
		65	• Conversion primary expression for painting device command ↔ EW command not prepared	
		66	• Execution system decision table not set	
		67	• Unknown mode data (Without TEACH/PLAY mode data)	
		68	• Shift-value output timeout of the general-purpose sensor	
		69	• Interrupt main status set	
		71	• System number error at the master side in twin synchronous system	
		72	• No data link added to the command	
		73	• Setting status error of the user coordinates file	
		75	• Previous path data reference error	
		76	• Target position preparation error in arc-retry shift motion mode	
		77	• Request to compensate position error of the axis that is not endless axis	
		79	• Inner track zone status error	
		80	• Instruction queue and instruction system data area overflow	
		81	• Offline answer bank flag error	
		82	• Path and trace queue ENQUE BANK error	
		83	• Pending and block end request FULL	
		84	• Base axis file type error	
		85	• Output buffer SYSCON for automatic test data in use	
		86	• Conversion completion status for AXIS section feedback latch data not established	
		87	• Sensor number (SL#) error	
		88	• File C1 through C3 for calibration between manipulators not set	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4207	SYSTEM ERROR (MOTION)	A system error occurred in MOTION.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		89	• File C1 through C3 for conveyor calibration not set	
		90	• HA function error (conv_pos_data())	
		91	• HA function error (conv_shift_data())	
		92	• HA function error (trans_angle_to_pulse())	
		93	• HA function error (trans_pulse_to_angle())	
		94	• HA function error (conv_pulse_to_angle())	
		95	• HA function error (pr_atinf_pos_make())	
		96	• HA function error (make_pos_data())	
		100	• Control-group axis configuration information parameter error	
		101	• Error in the parameter for the table for physical axes	
		102	• Error in the parameter for the table for physical TU	
		103	• Excessive number of control group axes in use	
		104	• JOG and PLAY maximum speed setting parameter error	
		120	• Job argument over	
		121	• Job argument stack overflow	
		122	• Job argument stack underflow	
		123	• Designation error of the fetched feedback pulse area at preparation of current value	
		128	• Timeout for waiting permission to modify the number of averaging times	
		129	• Object undefined for CLEAR instruction	
		130	• No space in RT_BANK setting area for correction-amount data	
		131	• Queue operation error for variable write-in history at prereading (at ENQUEUE)	
		132	• Queue operation error for variable write-in history at prereading (at DEQUEUE)	
		133	• Queue operation error for variable write-in history at prereading (undefined operation)	
		134	• Queue operation error for variable write-in history at prereading (data length too long)	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4207	SYSTEM ERROR (MOTION)	A system error occurred in MOTION.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		135	• Queue operation error for score-board setting history (at ENQUE)	
		136	• Queue operation error for score-board setting history (at DEQUE)	
		137	• Queue operation error for score-board setting history (undefined operation)	
		138	• Queue operation error for score-board setting history (data length too long)	
		139	• Queue operation error for instruction execution (at ENQUE)	
		140	• Queue operation error for instruction execution (at DEQUE)	
		141	• Queue operation error for instruction execution (undefined operation)	
		142	• Queue operation error for instruction execution (data length too long)	
		143	• Queue operation error for WORK ID conveyor (at ENQUE)	
		144	• Queue operation error for WORK ID conveyor (at DEQUE)	
		145	• Queue operation error for WORK ID conveyor (undefined operation)	
		146	• Queue operation error for WORK ID conveyor (data length too long)	
		147	• Queue operation error for WORK IN/OUT checking conveyor (at ENQUE)	
		148	• Queue operation error for WORK IN/OUT checking conveyor (at DEQUE)	
		149	• Queue operation error for WORK IN/OUT checking conveyor (undefined operation)	
		150	• Queue operation error for WORK IN/OUT checking conveyor (data length too long)	
		151	• Queue operation error for waiting for semaphore for LOCK instruction (at ENQUE)	
		152	• Queue operation error for waiting for semaphore for LOCK instruction (at DEQUE)	
		153	• Queue operation error for waiting for semaphore for LOCK instruction (undefined operation)	
		154	• Queue operation error for waiting for semaphore for LOCK instruction (data length too long)	
		222	• Impossible to execute system exclusive for system job	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4207	SYSTEM ERROR (MOTION)	A system error occurred in MOTION.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		223	• Event queue number range exceeded	
		224	• No motor-gun control group for ESRCH instruction	
		225	• The number of WORK ID data and the MAX. WORK FIND COUNT unmatched (MOTION $\neq$ CV)	
		226	• The number of WORK IN/OUT data and the MAX. WORK FIND COUNT unmatched (MOTION $\neq$ CV)	
		227	• Excessive number of schedulings for execution of instructions	
		228	• Instruction execution scheduling impossible	
		229	• Illegal 1st-line move instruction at execution of +SMOV instruction	
		230	• Impossible to execute the slave circular interpolation and the master circular interpolation at the same time	
		231	• Impossible to execute the slave spline interpolation and the master spline interpolation at the same time	
		232	• Illegal index value for a +MOVx instruction	
		233	• No xth-line move instruction exists where the master control group belongs.	
		234	• Marking error for WORK ID conveyor queue (empty queue)	
		235	• Marking error for WORK IN/OUT conveyor queue (empty queue)	
		236	• Data error 1 at restarting after an emergency stop (actual status and the data status unmatched)	
		237	• Data error 2 at restarting after an emergency stop (actual status and the data status unmatched)	
		238	• Data error 3 at restarting after an emergency stop (actual status and the data status unmatched)	
		239	• Timeout for receiving segment data output request	
		240	• The number which designates the setting area of correction amount in RT_BANK exceeded the limit value.	
		241	• Task error of the function calling source (cv_sync_intr ( ))	
		242	• No control group for motor gun for clearance move instruction	



## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4207	SYSTEM ERROR (MOTION)	A system error occurred in MOTION.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		243	• Motor gun condition file number error (including gun pressure file)	
		244	• GETTOOLW manipulator designation error	
		245	• Overflow of entry number for instruction execution	
		246	• Data latch processing (function number overflow)	
		247	• Data latch processing (real-time status number overflow)	
		248	• Failed to set a timer unit. (No allocation space for timer unit setting)	
		249	• Segment data missing (seg_t_req was not received in time.)	
		250	• GETS instruction internal error	
		251	• SETFILE undefined file	
		252	• GETFILE undefined file	
		253	• The parameter was destroyed when a GETPRM instruction was executed.	
		254	• Null pointer assignment detected	
		255	• Function or other processing parameter error	
		1000	• System clock (RTC) setting error	
		1001	• System task priority arrangement error	
		1002	• VxWorks primitive error (msgQCreate)	
		1003	• VxWorks primitive error (msgQSend)	
		1004	• VxWorks primitive error (msgQReceive)	
		1005	• VxWorks primitive error (semBCreate)	
		1006	• VxWorks primitive error (semGive)	
		1007	• VxWorks primitive error (semTake)	
		2000	• Failed system job environment configuration	
4208	SYSTEM ERROR (ARITH)	A system error occurred in the path control section.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		1	• Prereading task is not completed.	
		2	• The answer bank flag is already set.	
		3	• Inner path motion is impossible.	
		4	• Error in the number of position data	
		5	• The averaging buffer in the arithmetic section is destroyed.	
		6	• No previous bank exists.	
		7	• The answer bank flag is ON.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4208	SYSTEM ERROR (ARITH)		A system error occurred in the path control section.	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		8	• An error occurred in preparation of current position.	
		9	• Mails could not correctly be received in the current task.	
		10	• Spline-curve path designation error	
		11	• The previous bank's prereading conversion could not correctly be completed.	
		12	• A manipulator designation error occurred at JOG operation using the external reference point.	
		13	• Designation error of cubic interference coordinates	
		14	• Path control position data error of prereading bank	
		15	• Weaving control position data error of prereading bank	
		16	• Station/base axis motion command error	
		18	• User coordinates number error	
		19	• Processing error in re-preparation of segment control data	
		20	• Prereading task not completed at master in twin synchronous system	
		21	• Zero division occurred at observer operation.	
		22	• Processing error in optimized acceleration/deceleration control	
		23	• Dynamic model arithmetic error	
		24	• Speed limit control error (excessive moment of gravity)	
		25	• Square root of a negative number	
		26	• The system number is not set at master in twin synchronous system.	
		27	• Designation error of control group for servo sealer gun	
		28	• Designation error of control condition for servo sealer gun	
		29	• FORMCUT internal control error	
		30	• Arm interference check error (radius data referencing mistake)	
		31	• Arm interference check error (miscalculation using direct kinematics)	
		32	• Arm interference check error (L-axis expansion flag setting error)	
		33	• Arm interference check error (check-point re-setting error)	
		34	• Impossible to edit the averaging buffer (zero division)	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4208	SYSTEM ERROR (ARITH)	A system error occurred in the path control section.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		35	<ul style="list-style-type: none"> <li>No master-group is designated at preparation of master-tool user coordinates.</li> </ul>	
		37	<ul style="list-style-type: none"> <li>Gauging function error (command designation error)</li> </ul>	
		38	<ul style="list-style-type: none"> <li>A coordinated motion was attempted using the Following function.</li> </ul>	The coordinated motion cannot be performed by the Following function. Change the setting so that only the manipulator moves.
		39	<ul style="list-style-type: none"> <li>Zero or a negative value is set for the bending speed of the Following function.</li> </ul>	Set a positive value for the bending speed.
		40	<ul style="list-style-type: none"> <li>Zero or a negative value is set for the bending stroke of the Following function.</li> </ul>	Set a positive value for the bending stroke.
		41	<ul style="list-style-type: none"> <li>Pulse linked JOG function error</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		42	<ul style="list-style-type: none"> <li>Special JOG operation error</li> </ul>	
		43	<ul style="list-style-type: none"> <li>Following function error (The used manipulator model does not support 7-axis Following Control.)</li> </ul>	
4209	OFFLINE SYSTEM ERROR (ARITH)	A system error occurred in the offline position-data preparation section.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		100	<ul style="list-style-type: none"> <li>Data setting error in offline data bank</li> </ul>	
		101	<ul style="list-style-type: none"> <li>Data setting error in offline answer bank</li> </ul>	
		102	<ul style="list-style-type: none"> <li>OFF_USER_POS occupation control error</li> </ul>	
		103	<ul style="list-style-type: none"> <li>OFF_USER_POS valid control error</li> </ul>	
		104	<ul style="list-style-type: none"> <li>Mail-receiving error of offline task</li> </ul>	
		105	<ul style="list-style-type: none"> <li>Offline occupation control error</li> </ul>	
		106	<ul style="list-style-type: none"> <li>Designation error for offline cubic interference coordinates</li> </ul>	
		107	<ul style="list-style-type: none"> <li>OFF_USER_ROT_POS occupation control error</li> </ul>	
		108	<ul style="list-style-type: none"> <li>OFF_USER_ROT_POS valid control error</li> </ul>	
		109	<ul style="list-style-type: none"> <li>OFF_CV_CALIB_POS occupation control error</li> </ul>	
		110	<ul style="list-style-type: none"> <li>OFF_CV_CALIB_POS valid control error</li> </ul>	
		111	<ul style="list-style-type: none"> <li>Incorrect teaching for offline conveyor tracking turntable function</li> </ul>	
		112	<ul style="list-style-type: none"> <li>No manipulator is designated for offline conveyor tracking turntable function.</li> </ul>	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4210	SYSTEM ERROR (Local variable)	An error occurred in local variable control process.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		-1	• Local variable is not used.	
		-2	• Memory area for local variable could not be obtained.	
		-3	• No unused handle value exists when local variable area is created.	
		-4	• An error occurred in exclusive control.	
		-5	• Handle value is invalid for specified local variable.	
		-6	• Handle value is incorrect for specified local variable.	
		-7	• An error occurred when memory area for local variable was released.	
		-8	• An error occurred when memory area for local variable was registered.	
		-9	• Local variable control process is not initialized.	
		-10	• Local variable area shared heap area.	
		-11	• An error occurred in exclusive control.	
4215	SYSTEM ERROR (API)	---	An error occurred during API processing.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF and back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4220	SERVO POWER OFF FOR JOB	---	The servo power is not supplied to the job control group axis (control group for subcode) to be operated.	Turn OFF the servo power supply, and then turn ON the servo power supply for the group axis to be operated.
4221	SERVO POWER OFF FOR JOB	---	The servo power is not supplied to the job control group axis (control group for subcode) to be operated.	Turn OFF the servo power supply, and then turn ON the servo power supply for the group axis to be operated.
4222	INPUT COMPARISON ERROR (DSW)	0000_00**	A dual signal is mutually checking with the result that Enable switch (DSW and EXDSW) I/O signal does not have a match signal as a result the mutual check of a dual signal. 0000_0001: DSW 0000_0010: EXDSW	Check the enable switch (DSW and EXDSW) I/O signal.
4223	SAFE CIRCUIT SIGNAL DIS-AGREEMENT (SERVO)	1	A safety circuit signal error occurred in I/O unit.	Check the wiring of the safety circuit signal cables connected to the I/O contactor unit.
		2	A safety circuit signal error occurred in I/O unit.	
		3	A safety circuit signal error occurred in I/O unit.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4224	MEMORY PLAY FILE ERROR		An error occurred in memory play file.	Needs investigation. Contact your Yaskawa representative.
		-1	• An error occurred in control process.	
		-2	• The arrangement address information is destroyed for memory play file system.	
		-3	• The fixed control information is destroyed for memory play file system.	
		-4	• The memory play file number is incorrect.	
		-5	• An attempt was made to newly register the memory play file under use.	
		-6	• An error occurred in checking written sampling data when the data was written to CMOS.	
		-7	• An attempt was made to access an unused memory play file data.	
		-8	• The memory play file is destroyed.	
		-9	• The memory area for sampling data is full.	
		-10	• The sampling data is destroyed.	
		-11	• Data in control process is incorrect.	
		-12	• The sampling data is scanned only at top or end position.	
		-13	• The memory play file system is not initialized.	
		-14	• The offset value is out of range at sampling data scanning.	
4225	SPEED ERROR (NCP01)	---	The speed exceeded the limit. Suspected causes include: - Motor cable disconnection - Incorrect motor type - Motor failure - Defective board due to an external force applied to manipulator	Check the motor, board, manipulator motion (influence by external force), and taught orientation.
4228	WRONG DATA	---	Chain inconsistency between the Job instruction file and position file due to following factors: ① Overlapped chain with the same position data ② Unregistered position data is chained with the Job instruction file. ③ Registered position data is not chained.  For details, refer to "NX100 OPTIONS INSTRUCTIONS FOR JOB DATA SIMPLIFIED RESTORATION FUNCTION (HW0483260)".	<ul style="list-style-type: none"> <li>Reset the alarm, and then select WRONG DATA LOG under SETUP in maintenance mode to check the factor of the inconsistency.</li> <li>Select RESTORE under the pull-down menu UTILITY to restore the system. If it succeeds in restoration, the indication in the screen changes from "OCCURRED ON" to "RESTORED ON". Then, turn the control power ON.</li> </ul> <p>For the factor ①, check the position of the corresponding file, then correct the position. For the factor ②, register the position of the corresponding file again.</p> <ul style="list-style-type: none"> <li>If it fails in restoration, refer to "NX100 OPTIONS INSTRUCTIONS FOR JOB DATA SIMPLIFIED RESTORATION FUNCTION (HW0483260)", and restore the file system.</li> </ul>

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4229	ETHERNET ERROR	1	An error occurred in the acquisition process of the IP address during the IP address monitoring process of the Ethernet function.	<ul style="list-style-type: none"> <li>When the DHCP is used, verify the DHCP server operation and the network status. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		2	An error occurred in the acquisition process of subnet mask during the network service data creation process of the Ethernet function.	
		3	An error occurred in the acquisition process of gateway during the network service data creation process of the Ethernet function.	
		4	An error occurred in the conversion process of gateway address during the network service data creation process of the Ethernet function.	
		5	An error occurred in the conversion process of DNS server address during the network service data creation process of the Ethernet function.	
		6	An error occurred in the acquisition process of domain during the network service data creation process of the Ethernet function.	
		7	An error occurred in the acquisition process of SNTP server during the network service data creation process of the Ethernet function.	
		8	An error occurred in the acquisition process of host name during the network service data creation process of the Ethernet function.	
4229	ETHERNET ERROR	9	An error occurred in the newest DNS information getting process from DHCP server in the DNS process of the Ethernet function.	<ul style="list-style-type: none"> <li>When the DHCP is used, verify the DHCP server operation and the network status. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		10	An error occurred in the setting process to update DNS information in the DNS process of the Ethernet function.	
		11	An error occurred in the setting clearing process to update DNS information in the DNS process of the Ethernet function.	
		20	The subnet mask was not able to be acquired in the DHCP information update process of the Ethernet function.	
		21	Subnet mask update error occurred in the DHCP information update process of the Ethernet function.	
		25	Gateway update error occurred in the DHCP information update process of the Ethernet function.	
		26	Gateway clear error occurred in the DHCP information update process of the Ethernet function.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4230	REDUCER MONITOR OVER	---	Failed to stop the operation under the HOLD STOP command.	<ul style="list-style-type: none"> <li>Reset the alarm, and then turn ON the servo again.</li> <li>Check the HOLD STOP.</li> </ul> If the error occurs again, replace the servo control circuit board.
4300	SERVO PARAMETER ERROR	---	The parameter input value is out of the allowable range.	Reset the value within the allowable range.
4301	CONTACTOR ERROR	---	An error occurred in the contactor due to a defective contactor unit or circuit board. <ul style="list-style-type: none"> <li>The contactor of contactor unit did not turn ON at servo ON.</li> <li>The signal from the contactor turned OFF while the servo was ON.</li> <li>The signal from the contactor remains ON when the servo turned OFF at emergency stop.</li> <li>The contactor turned ON while the servo was OFF for emergency stop.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then turn ON the servo again.</li> <li>Check the 24-V power supply for I/O.</li> </ul> If the error occurs again, replace the contactor unit or servo control circuit board or both.
4302	BRAKE CIRCUIT ERROR	---	<ul style="list-style-type: none"> <li>The brake relay signal did not turn ON when the servo turned ON.</li> <li>The brake relay signal turned OFF while the servo was ON.</li> <li>The brake signal remains ON when the servo turned OFF at emergency stop.</li> <li>The brake signal turned ON while the servo was OFF for emergency stop.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then turn ON the servo again.</li> </ul> If the error occurs again, replace the contactor unit and/or servo control circuit board.
4303	CONVERTER READY SIGNAL ERROR	---	<ul style="list-style-type: none"> <li>No response of charge completion was sent from the converter when the servo turned ON.</li> <li>The SERVO READY signal turned OFF while the servo was ON.</li> <li>The SERVO READY signal remains ON when the servo turned OFF at emergency stop.</li> <li>The SERVO READY signal turned ON while the servo was OFF for emergency stop.</li> <li>The primary power supply voltage is too low.</li> <li>The voltage dropped.</li> <li>Defective servo control and/or converter</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then turn ON the servo again.</li> <li>Check the primary power supply voltage.</li> </ul> If the error occurs again, replace the servo control circuit board and/or converter.
4304	CONVERTER INPUT POWER ERROR	---	<ul style="list-style-type: none"> <li>No response of primary power supply input was sent from the converter when the servo turned ON.</li> <li>The READY 1 signal remains ON when the servo turned OFF at emergency stop.</li> <li>The READY 1 signal turned ON while the servo was OFF for emergency stop.</li> <li>Incorrect wiring or voltage drop of primary power supply</li> <li>Defective servo control and/or converter</li> </ul>	<ul style="list-style-type: none"> <li>Check the wiring for the primary power supply of the SERVOPACK.</li> <li>Confirm that the power supply voltage is 170V or more.</li> </ul> If the error occurs again, replace the servo control circuit board and/or converter.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4305	CONVERTER CIRCUIT CHARGE ERROR	---	<ul style="list-style-type: none"> <li>• No response (READY 2 signal) of charge completion was sent from the converter when the servo turned ON.</li> <li>• The READY 2 signal turned OFF while the servo was ON.</li> <li>• The READY 2 signal remains ON when the servo turned OFF at emergency stop.</li> <li>• The READY 2 signal turned ON while the servo was OFF for emergency stop.</li> <li>• Incorrect wiring and/or voltage drop of primary power supply</li> <li>• Defective servo control circuit board, converter, and/or amplifier</li> </ul>	<ul style="list-style-type: none"> <li>• Check the wiring for the primary power supply of the SERVOPACK.</li> <li>• Confirm that the power supply voltage is 170V or more.</li> </ul> <p>If the error occurs again, replace the servo control circuit board and/or converter.</p>
4306	AMPLIFIER READY SIGNAL ERROR	---	<ul style="list-style-type: none"> <li>• No response "Power ON" was sent from the amplifier when the servo turned ON.</li> <li>• The amplifier READY signal turned OFF while the servo was ON.</li> <li>• The amplifier READY signal remains ON when the servo turned OFF at emergency stop.</li> <li>• The amplifier READY signal turned ON while the servo was OFF for emergency stop.</li> <li>• Defective servo control circuit board, converter, and/or amplifier</li> </ul>	<ul style="list-style-type: none"> <li>• Check the wiring for the primary power supply of the SERVOPACK.</li> <li>• Confirm that the power supply voltage is 170V or more.</li> </ul> <p>If the error occurs again, replace the WRCA01 circuit board, servo control circuit board, converter, and/or amplifier.</p>
4307	SERVO ON SPEED ERROR	---	<p>The motion speed of the encoder before the dynamic brake turns OFF in servo ON sequence exceeded the threshold for a certain period.</p> <ul style="list-style-type: none"> <li>• The servo power supply turned ON while the manipulator (motor and encoder) was moving.</li> </ul>	<p>The control power supply cannot be turned ON while the manipulator is moving. Stop the manipulator motion, and then turn ON the servo power supply.</p>
4308	VOLTAGE DROP (CONVERTER)	---	<p>The DC power voltage supplied to the SERVOPACK amplifier dropped below 143V due to:</p> <ul style="list-style-type: none"> <li>- Low voltage of the primary power supply</li> <li>- Open phase</li> <li>- Defective converter</li> <li>- Defective servo control circuit board</li> </ul>	<ul style="list-style-type: none"> <li>• Check the wiring for the primary power supply of the SERVOPACK.</li> <li>• Confirm that the power supply voltage is 170V or more.</li> </ul> <p>If the error occurs again, replace the servo control circuit board, servo control circuit board, and/or converter.</p>
4309	DEFECTIVE ENCODER INTERNAL DATA	---	<p>Serial encoder internal parameter error occurred.</p>	<ul style="list-style-type: none"> <li>• Reset the alarm, and then perform the home positioning again. Turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, replace the motor of the corresponding axis.</p>
4310	ENCODER OVERHEAT	---	<p>The temperature of the encoder exceeded 100 °C.</p> <ul style="list-style-type: none"> <li>• Encoder thermistor failure</li> </ul>	<ul style="list-style-type: none"> <li>• Review the load condition and ambient operating temperature.</li> <li>• Confirm that the primary power supply voltage is 200V + 10%.</li> </ul> <p>If the error occurs again, replace the servo control circuit board or the motor.</p>



Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4311	ENCODER BACK-UP ERROR	---	<ul style="list-style-type: none"> <li>Encoder resetting (initialization) not completed</li> <li>The position data in the encoder was lost due to the voltage drop of encoder backup battery.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then perform the home positioning again. Confirm that the encoder backup battery voltage is 2.8V or more.</li> </ul> <p>If the error occurs again, replace the encoder (motor).</p>
4312	ENCODER BATTERY ERROR	---	<p>Encoder backup battery voltage is too low.</p> <ul style="list-style-type: none"> <li>The voltage of the encoder backup battery is below 2.8V.</li> </ul> <p>The position data may be lost.</p>	<p>Confirm that the encoder backup battery voltage is 2.8V or more. If not, replace the battery.</p>
4313	SERIAL ENCODER OVER HEAT	---	<p>The temperature of the encoder exceeded 100 °C.</p> <ul style="list-style-type: none"> <li>Encoder thermistor failure</li> </ul>	<ul style="list-style-type: none"> <li>Review the load condition and ambient operating temperature.</li> <li>Confirm that the primary power supply voltage is 200V + 10%.</li> </ul> <p>If the error occurs again, replace the servo control circuit board or the motor.</p>
4314	SERIAL ENCODER BATTERY ERROR	---	<p>Encoder backup battery voltage is too low.</p> <ul style="list-style-type: none"> <li>The voltage of the encoder backup battery is below 2.8V.</li> </ul> <p>The position data may be lost.</p>	<p>Confirm that the encoder backup battery voltage is 2.8V or more. If not, replace the battery.</p>
4315	COLLISION DETECT	---	<ul style="list-style-type: none"> <li>A collision was detected because of the interference between the manipulator and a peripheral device.</li> <li>The external force applied to the robot exceeded the threshold.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then remove the object or move the manipulator back to a safe position.</li> </ul> <p>If the alarm cannot be reset, invalidate the collision detection level setting file or set the detection level higher.</p>
4316	PRESSURE DATA LIMIT	---	<p>The pressure set in the gun pressure file or dry spotting pressure file exceeded the maximum pressure set in the gun condition file.</p>	<p>Reset the pressure value in the gun pressure file or dry spotting pressure file below the maximum pressure value.</p>
4317	PRE-LOAD ERROR	---	<p>The motor does not operate in the pre-load process.</p>	<p>Adjust the gun opening.</p>
4318	SERIAL ENCODER CORRECT LIMITATION OVER	---	<p>The speed feedback value of the serial encoder exceeded the allowable limit.</p>	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
4320	OVER LOAD (CONTINUE)	---	<p>The motor torque continuously exceeded the rated torque for a certain period due to:</p> <ul style="list-style-type: none"> <li>- Motor cable disconnection</li> <li>- Incorrect motor type</li> <li>- Motor failure</li> <li>- Defective board</li> <li>- External force applied to manipulator, etc.</li> </ul>	<p>Check the motor, board, manipulator motion (influence by external force), and taught orientation.</p>
4321	OVER LOAD (INSTANT)	---	<p>The torque a several times as much as the rated torque has been applied to the motor due to:</p> <ul style="list-style-type: none"> <li>- Motor cable disconnection</li> <li>- Incorrect motor type</li> <li>- Motor failure</li> <li>- Defective board</li> <li>- External force applied to manipulator, etc.</li> </ul>	<p>Check the motor, board, manipulator motion (influence by external force), and taught orientation.</p>
4322	AMPLIFIER OVER LOAD (CONTINUE)	---	<p>The current a several times as much as the rated current has continuously flown in the amplifier for a certain period.</p>	<ul style="list-style-type: none"> <li>Check the wiring and connection for the motor power line, board, cable disconnection, motor type, manipulator interferences, SERVOPACK, and board, etc.</li> </ul> <p>Replace if necessary.</p>

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4323	AMPLIFIER OVER LOAD (INSTANT)	---	The torque a several times as much as the motor rated torque has continuously been applied for a certain period.	<ul style="list-style-type: none"> <li>Check the wiring and connection for the motor power line, motor type, manipulator interference, SERVOPACK, and circuit boards.</li> </ul> Replace if necessary.
4324	CONVERTER OVER LOAD	---	The total load value of all the motors connected to the converter exceeded the converter rating.	Review the manipulator operating condition such as reducing the teaching speed, etc.
4326	SPEED ERROR	---	The speed exceeded the limit due to: <ul style="list-style-type: none"> <li>- Motor cable disconnection</li> <li>- Incorrect motor type</li> <li>- Motor failure</li> <li>- Defective board</li> <li>- External force applied to manipulator, etc.</li> </ul>	Check the motor, board, manipulator motion (influence by external force), and taught orientation.
4327	MOTOR ROTATION ERROR	---	While the motor is accelerating, the direction of the torque and the speed was detected as being the opposite of what it was supposed to be.	Check the wiring and connection for the encoder and the motor power line.
4328	SERVO TRACKING ERROR	---	The axis deviated from the specified position and motion path beyond the allowable range.	<ul style="list-style-type: none"> <li>Check the manipulator interferences and motor power line.</li> </ul> If the error occurs again, replace the servo control circuit board, and/or the amplifier or motor of the corresponding axis.
4329	POSITION ERROR	---	The number of pulses generated by one motor rotation does not agree with the specified value due to: <ul style="list-style-type: none"> <li>- Noise from external devices</li> <li>- Defective board</li> <li>- Motor failure</li> </ul>	<ul style="list-style-type: none"> <li>Check for the external noise.</li> <li>Provide noise protection such as installing a ferrite core if required.</li> </ul> If the error occurs again, replace the servo control circuit board, external axis servo control circuit board, and/or motor.
4330	SPEED MONITORING INSTRUCTION CABLE DISCONNECTION	---	The read speed monitoring level signal is disconnected.	Check the connection cables for speed monitoring unit.
4331	SPEED MONITORING LEVEL ERROR	---	Illegal speed monitoring level	<ul style="list-style-type: none"> <li>Turn the power OFF and back ON.</li> </ul> If the error occurs again, replace the AXA01 circuit board.
4332	POSITION ERROR (SERIAL ENCODER)	---	The number of pulses generated by one motor rotation does not agree with the specified value due to: <ul style="list-style-type: none"> <li>- Noise from external devices</li> <li>- Defective board</li> <li>- Motor failure</li> </ul>	<ul style="list-style-type: none"> <li>Check for the external noise.</li> <li>Provide noise protection such as installing a ferrite core if required.</li> </ul> If the error occurs again, replace the servo control circuit board, external servo control circuit board, and/or motor.
4334	OVER VOLTAGE (CONVERTER)	---	The DC voltage supplied to the amplifier exceeded 420V due to: <ul style="list-style-type: none"> <li>- Overloaded</li> <li>- Converter failure</li> <li>- Defective servo control circuit board</li> </ul>	<ul style="list-style-type: none"> <li>Check the primary power supply voltage.</li> <li>Reduce the teaching speed and check if the error occurs. If the error does not occur with the reduced speed, review the load condition.</li> </ul> If the error occurs again, replace the servo control circuit board and/or the converter.

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4335	EARTH FAULT	---	Ground fault of the motor power line occurred due to: - Motor failure - Ground fault of motor line or lead cables - Defective servo control circuit board - Defective SERVOPACK	<ul style="list-style-type: none"> <li>• Check the motion connection.</li> <li>• Remove the motor connector to check the conduction.</li> </ul> <p>If there is conduction, replace the lead cable; if there is no conduction, replace the servo control circuit board.</p>
4336	OPEN PHASE (Converter)	---	The SERVOPACK primary power supply is open-phase due to: - Misconnection of primary power supply - Lowered primary power supply voltage - Defective servo control circuit board - Defective converter	<ul style="list-style-type: none"> <li>• Correct the SERVOPACK primary power supply connection,</li> <li>• Confirm that the power supply voltage is more than 170V.</li> </ul> <p>If the error occurs again, replace the servo control circuit board.</p>
4337	OVER CURRENT (AMPLIFIER)	---	Ground fault of the motor power line occurred due to: - Motor failure - Ground fault of motor line or lead cables - Defective servo control circuit board - Defective amplifier	<ul style="list-style-type: none"> <li>• Check the motion connection.</li> <li>• Remove the motor connector to check the conduction. If there is conduction, replace the lead cable; if there is no conduction, replace the servo control circuit board.</li> <li>• If no fault is found, turn OFF the power supply to cool down the motor. If this natural cooling solves the problem, the load condition and ambient operating temperature must be reviewed and corrected.</li> </ul>
4338	REGENERATION ERROR (CONVERTER)	---	The regenerative energy at motor deceleration is too large. - The primary power supply voltage is too high (above 242V) - Converter failure - Defective servo control circuit board	<ul style="list-style-type: none"> <li>• Review the load condition and teaching speed.</li> <li>• Confirm that the power supply voltage is <math>220V \pm 10\%</math>.</li> </ul> <p>If the error occurs again, replace the servo control circuit board.</p>
4339	INPUT POWER OVER VOLTAGE (CONV)	---	The SERVOPACK primary power supply voltage exceeded 242V.	<ul style="list-style-type: none"> <li>• Confirm that the power supply voltage is <math>220V \pm 10\%</math>.</li> </ul> <p>If the error occurs again, replace the servo control circuit board or the converter.</p>
4340	TEMPERATURE ERROR (CONVERTER)	---	SERVOPACK (converter) overheat	<ul style="list-style-type: none"> <li>• Confirm that the power supply voltage is <math>220V \pm 10\%</math>.</li> </ul> <p>If the error occurs again, replace the servo control circuit board or the converter.</p>
4344	LINEAR SERVO FLOAT TRACKING ERROR	---	The deviation of X, Y, and Z-axis exceeded the allowable limit while the linear servo float was in execution.	Check the job.
4345	LINK SERVO FLOAT ERROR	---	The link servo float can not be executed while the linear servo float is in execution.	Check the job.
4346	LINK SERVO FLOAT LIMITATION TORQUE RANGE ERROR	---	The limit torque of the link servo float condition file is outside the specified range.	Set the limit torque of the link servo float condition file again.
4347	LINEAR SERVO FLOAT LIMITATION TORQUE RANGE ERROR	---	The limit torque of the linear servo float condition file is outside the specified range.	Set the limit torque of the linear servo float condition file again.
4348	LINEAR SERVO FLOAT COORDINATES TYPE UNMATCH	---	While the linear servo float was in execution, another request of linear servo float execution was sent with a different coordinates specified.	Check the job.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4349	LINEAR SERVO FLOAT TOOL POSE CONTROL SPECIFICATION ERROR	---	A logical error occurred in the designation for tool orientation control of the linear servo float.	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4350	LINEAR SERVO FLOAT EXECU- TION ERROR	---	While the servo float was in execution, the linear servo float can not be executed.	Check the job.
4351	BELT DISCON- NECTION DETECTION	---	The driving belt may be disconnected because the torque decreased below the normal value.	Check the belt, and replace it if necessary.
4352	TWIN DRIVE OVER DEVIATION	---	The deviation of the position error pulse from the twin drive axis exceeded the allowable limit with twin drive function.	Check the load.
4353	DEFECTIVE TAUGHT POINT (ENDLESS)	---	Endless motion impossible <ul style="list-style-type: none"> <li>The feedback pulse value exceeded the maximum value (maximum number of pulses <math>\pm 536870912</math>)</li> </ul>	Reset the alarm.
4354	FILE NO. ERROR (SHOCK LEVEL)	---	The collision detection file for exclusive use for the SVSPOT is used with the SHCKSET instruction.	Do not use the collision detection file for exclusive use for the SVSPOT with the SHCKSET instruction.
4355	EXTERNAL PRES DETECT (SERVOFLOAT)	---	An external force above the threshold was detected on the servo-float executing axis.	Check the job.
4356	ARM CTRL PARAMETER ERR (OBSERVER)	---	The search of motor-gun equalizing function cannot be executed because no observer (including collision detection) is specified.	If the error occurs again, contact your Yaskawa representative.
4357	IMPOSSIBLE SRCH (EQUALIZE TEACH)	---	The manipulator orientation at the execution of search of the motor-gun equalizing function is the orientation for the singular point.	Check the job.
4358	DUPLICATE PRESS ERROR	---	The pressuring instruction was executed with manual pressurization during pressuring.	Do not execute the pressuring instruction with manual pressurization during pressuring.
4359	CONVERTER ERROR	---	An error occurred in the converter.	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, replace the servo control circuit board or the converter.
4360	WAFER ALIGN- MENT ERROR (SERVO)	Decimal data	An error occurred in communications with the prealigner.	Check the connection of prealigner.
4364	GUN SOFT LIMIT	---	The gun axis exceeded the software limit during pressuring operation.	<ul style="list-style-type: none"> <li>The error could occur due to the tip removed or the tip mis-installation. Verify the pressuring status.</li> <li>Set the pulse software limit again considering the wearing of chip and the deflection of gun arm.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4365	EXCESSIVE DETECTION RANGE (GUN ELEC- TRODE HIT POINT)	Physical axis bit	In comparison to the position, where the gun electrode hits the welded target, at the previous wear detection, the position during pressuring exceeded the allowable limit which had been set in the motion limit for which the fixed (movable) gun electrode hits the welded target.	<ul style="list-style-type: none"> <li>The error could occur due to the tip removed or the tip mis-installation. Verify the pressuring status.</li> <li>Adjust the set value of the gun condition file.</li> </ul>

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4366	GUN BENDING CORRECTION ERROR	Cntrl grp bit designation	The function of gun bending correction was performed to the model which was not supported for the function.	<ul style="list-style-type: none"> <li>• Invalidate the bending correction function.</li> <li>• Contact your Yaskawa representative.</li> </ul>
4367	ROBOT POSITION ERROR	Cntrl grp bit designation	The manipulator orientation at pressuring is the orientation for the singular point.	Check the job.
4371	SYSTEM ERROR (SERVO)	Decimal data	The independent brake control was performed in TU which was not supported for the control.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
4372	SERVO ON SIGNAL ERROR	---	The servo OFF status is sent from TU.	<ul style="list-style-type: none"> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
4400	NOT READY (ARITH)	The arithmetic process for motion control did not complete within regulated time.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	• No motion command was prepared.	
		2	• The arithmetic processing section is not ready for JOG operation.	
		3	• The arithmetic processing section is not ready for the playback operation.	
		4	• The prereading processing in the arithmetic processing section has not completed.	
		5	• The arithmetic processing section is not ready for the timer follow-up of the conveyor tracking function.	
		6	• The prereading processing in the arithmetic processing section has not completed when specifying the target position.	
4401	SEQUENCE TASK CONTROL ERROR	An error occurred in job execution process.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	• Unused A_BANK does not exist in the prereading processing of move instruction.	
		2	• Unused bank priority does not exist in the prereading processing of move instruction.	
		5	• A_BANK pointer is not set.	
		6	• A_BANK conversion could not be performed.	
		7	• The specified A_BANK number does not exist.	
		20	• An error occurred when system number (MSS) was obtained.	
		21	• An error occurred in RMS960 system call.	
		22	• Undefined interrupt command was received.	
		23	• Job start condition is not defined.	
		24	• An error occurred in instruction prefetch queue operation.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4401	SEQUENCE TASK CONTROL ERROR		An error occurred in job execution process.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		26	• Intermediate code is not defined.	
		29	• Instruction prereading processing has not been completed normally.	
		30	• An error occurred in job data change.	
		31	• The specified sequence number at job execution start is incorrect.	
		32	• The added area for interruption command is incorrect.	
		33	• System number (MSS) for interruption command is incorrect.	
		38	• An error occurred at start of twin synchronous operation.	
		39	• An error occurred when SYNC specification was reset.	
		41	• An error occurred in occupation control group setting in MOTION.	
		45	• An error occurred in path/trace control.	
		47	• An error occurred when waiting for a completion of main system task (job) in SYNC specification.	
		48	• An attempt was made to execute an instruction that could not be executed at line sequence execution.	
		80	• An exceptional error occurred in job execution process.	
		100	• Main processing command is incorrect in prereading processing.	
		101	• Subprocessing command is incorrect in prereading processing.	
		102	• Prereading processing has not been completed at job execution.	
		103	• A_BANK conversion has not been completed.	
		104	• System number (MSS) is incorrect in prereading processing.	
		105	• An error occurred in instruction prefetch queue operation in prereading processing.	
		106	• An error occurred at IES switching in prereading processing.	
4402	UNDEFINED COMMAND (ARITH)		An undefined command was issued to the path control section.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4404	ARITHMETIC ERROR		An error occurred in the arithmetic process for coordinates.	<ul style="list-style-type: none"> <li>• Change the positions so that two arms are not aligned in a straight line.</li> <li>• Change the step (move instruction), where the alarm occurred, to MOVJ.</li> </ul>
		1	<ul style="list-style-type: none"> <li>• The S-arm and L-arm of a scalar type manipulator are aligned in a straight line. Interpolation such as linear and circular interpolation is impossible in such orientation.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>• When a vertically-articulated manipulator was moved by a special linear interpolation, the R-axis angle could not correctly be calculated.</li> </ul>	Change the position in the step (move instruction) where the alarm occurred.
		3	<ul style="list-style-type: none"> <li>• When a vertically-articulated manipulator was moved by a special linear interpolation, the L-axis angle could not correctly be calculated.</li> </ul>	
		4	<ul style="list-style-type: none"> <li>• The L-arm and U-arm of a vertically-articulated manipulator are aligned in a straight line. Interpolation such as linear and circular interpolation is impossible in such orientation.</li> </ul>	<ul style="list-style-type: none"> <li>• Change the positions so that two arms are not aligned in a straight line.</li> <li>• Change the step (move instruction), where the alarm occurred, to MOVJ.</li> </ul>
		6	<ul style="list-style-type: none"> <li>• The L-arm and U-arm of a vertically-articulated manipulator are aligned in a straight line. Interpolation such as linear and circular interpolation is impossible in such orientation.</li> </ul>	
		7	<ul style="list-style-type: none"> <li>• The TCP of the manipulator is out of working envelope.</li> </ul>	<ul style="list-style-type: none"> <li>• Perform the teaching again so that the TCP of the manipulator is always within the working envelope.</li> <li>• Change the shift value so that the TCP of the manipulator is always within the working envelope.</li> </ul>
		8	<ul style="list-style-type: none"> <li>• Interpolation such as linear and circular interpolation cannot be performed with this manipulator.</li> </ul>	Change the step (move instruction), where the alarm occurred, to MOVJ.
		9	<ul style="list-style-type: none"> <li>• Specified motion cannot be performed with this manipulator.</li> </ul>	Correct the taught point.
4405	SELECT ERROR (PARAMETER)	1	<ul style="list-style-type: none"> <li>• A parameter error occurred in the path control section.</li> <li>• Selection error of motion system parameter</li> </ul>	<ul style="list-style-type: none"> <li>• Reset the alarm, and turn the power OFF then back ON.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
4406	GROUP AXIS CONTROL ERROR		An internal control error occurred in a coordinated motion.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
		1	<ul style="list-style-type: none"> <li>• Designation error for master and slave</li> </ul>	
		2	<ul style="list-style-type: none"> <li>• Slave designation error</li> </ul>	
		3	<ul style="list-style-type: none"> <li>• Slave interpolation error</li> </ul>	
		4	<ul style="list-style-type: none"> <li>• No designation of master axis</li> </ul>	
		5	<ul style="list-style-type: none"> <li>• No designation of slave axis</li> </ul>	
		6	<ul style="list-style-type: none"> <li>• Master-axis designation error for JOG motion</li> </ul>	
		7	<ul style="list-style-type: none"> <li>• Slave-axis designation error for JOG motion</li> </ul>	
		8	<ul style="list-style-type: none"> <li>• Occupation control error</li> </ul>	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4406	GROUP AXIS CONTROL ERROR	An internal control error occurred in a coordinated motion.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> <li>If the error occurs again, contact your Yaskawa representative.</li> </ul>
		9	<ul style="list-style-type: none"> <li>Designation error of occupation control for JOG motion</li> </ul>	
		10	<ul style="list-style-type: none"> <li>Designation error of occupation control for Bank position</li> </ul>	
		11	<ul style="list-style-type: none"> <li>Designation error of occupation control group for tracking motion</li> </ul>	
		12	<ul style="list-style-type: none"> <li>No master and slave designated for tracking motion</li> </ul>	
4407	TWO STEPS SAME POSITION (CIRC)	---	Among three taught points in a circular interpolation step, two or three points are on the same point.	Teach the different 3 points again.
4408	TWO STEPS SAME POSITION (SPLINE)	---	Among three taught points in a spline interpolation step, two or three points are on the same point.	Teach the different 3 points again.
4409	TWO STEPS SAME POSITION (3 POINTS)	---	Among three taught points to create an user coordinate system, two or three points are on the same point.	Teach the different 3 points again.
4410	TWO STEPS SAME POSITION (WEAV)	---	Among three taught points (start, end, and reference points) to create a weaving coordinate system, two or three points are on the same point.	Teach the different 3 points again.
4411	TEACH ERROR (SPLINE)	---	<p>The spline interpolation could not correctly be performed.</p> <ul style="list-style-type: none"> <li>The distance between the teaching points in the spline interpolation section is not equidistant.</li> </ul>	Teach the positions so that the distance between the teaching points is even.
4412	IMPOSSIBLE LINEAR MOTION (L/U)	---	<p>Interpolation motion could not be performed because of different form of L- and U-axes.</p> <ul style="list-style-type: none"> <li>In case the form (folded direction) of L- and U-axes at start point and end point are different except for MOVJ instructions, the manipulator cannot move.</li> </ul>	<ul style="list-style-type: none"> <li>Perform the teaching again to make the form of L- and U-axes same at start point and end point.</li> <li>Use a MOVJ instruction.</li> </ul>
4413	IMPOSSIBLE LINEAR MOTION (S/L)	---	<p>Interpolation motion could not be performed because of different form of S- and L-axes.</p> <ul style="list-style-type: none"> <li>In case the form (folded direction) of S- and L-axes at start point and end point are different except for MOVJ instructions, the manipulator cannot move.</li> </ul>	<ul style="list-style-type: none"> <li>Perform the teaching again to make the form of S- and L-axes same at start point and end point.</li> <li>Use a MOVJ instruction.</li> </ul>
4414	EXCESSIVE SEGMENT (LOW SPEED)	---	The manipulator motion speed exceeded the limit (LOW level).	<ul style="list-style-type: none"> <li>Reduce the speed in the step (move instruction) where the alarm occurred.</li> <li>The manipulator may be near the singular point. Change the position and orientation of the manipulator.</li> </ul>
4415	EXCESSIVE SEGMENT (HIGH SPEED)	---	The manipulator motion speed exceeded the limit (HIGH level).	<ul style="list-style-type: none"> <li>Reduce the speed in the step (move instruction) where the alarm occurred.</li> <li>The manipulator may be near the singular point. Change the position and orientation of the manipulator.</li> </ul>
4416	PULSE LIMIT (MIN.)	---	The manipulator exceeded its motion limit (pulse limit) in the negative (–) direction.	Change the manipulator position in the step (move instruction) where the alarm occurred.



## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4417	PULSE LIMIT (MAX.)	---	The manipulator exceeded its motion limit (pulse limit) in the positive (+) direction.	Change the manipulator position in the step (move instruction) where the alarm occurred.
4418	CUBE LIMIT (MIN.)	---	The manipulator TCP exceeded its motion limit (cube limit) in the negative (–) direction.	Change the position in the step (move instruction) where the alarm occurred.
4419	CUBE LIMIT (MAX.)	---	The manipulator TCP exceeded its motion limit (cube limit) in the positive (+) direction.	Change the position in the step (move instruction) where the alarm occurred.
4420	SPECIAL SOFT-LIMIT (MIN.)	0	The manipulator exceeded its motion limit (special software limit) in the negative (–) direction.	Change the position in the step (move instruction) where the alarm occurred.
4421	SPECIAL SOFT-LIMIT (MAX.)	0	The manipulator exceeded its motion limit (special software limit) in the positive (+) direction.	Change the position in the step (move instruction) where the alarm occurred.
4422	MECHANICAL INTERFERENCE (MIN.)	0	The manipulator exceeded its minimum-angle motion limit. (Mechanical interference)	Change the position in the step (move instruction) where the alarm occurred.
4423	MECHANICAL INTERFERENCE (MAX.)	0	The manipulator exceeded its maximum-angle motion limit. (Mechanical interference)	Change the position in the step (move instruction) where the alarm occurred.
4424	SPECIAL MECHANICAL INTRF (MIN.)	0	The manipulator exceeded its minimum-angle motion limit. (Special mechanical interference)	Change the position in the step (move instruction) where the alarm occurred.
4425	SPECIAL MECHANICAL INTRF (MAX.)	0	The manipulator exceeded its maximum-angle motion limit. (Special mechanical interference)	Change the position in the step (move instruction) where the alarm occurred.
4426	PULSE MECHANICAL LIMIT (MIN.)	---	The manipulator exceeded its motion limit (mechanical limit) in the negative (–) direction.	Change the position in the step (move instruction) where the alarm occurred.
4427	PULSE MECHANICAL LIMIT (MAX.)	---	The manipulator exceeded its motion limit (mechanical limit) in the positive (+) direction.	Change the position in the step (move instruction) where the alarm occurred.
4428	SEGMENT CONTROL ERROR	An error occurred in the real-time processing section that controls the arithmetic section.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		1	• RT-buffer control command error	
		2	• Segment-receiving control command error	
		3	• No bank priority	
		4	• Answer error at MOVE simulating	
		5	• The value of bank_refresh_flag(x) exceeded its limit.	
		6	• Bank refreshing timing error	
		7	• RT-buffer setting timing error	
		8	• RT-buffer tracking option error	
4429	WRONG SPECIFIED CONTROL GROUP	An error occurred in the manipulator information at job execution.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		1	• Control group not designated	
		2	• Slave control-group error	
		3	• Master control-group error	
		4	• Master and Slave control-group error	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4429	WRONG SPECIFIED CONTROL GROUP		An error occurred in the manipulator information at job execution.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		5	• Control-group error for a job file	
		6	• Control-group error for a user coordinate file	
		7	• Control-group error for a calibration file between manipulators	
		8	• Control-group error for a tool calibration file	
		9	• Control-group error for a reference point	
		10	• Control-group error for prereading-calculation start point (for adv_st_pos)	
		11	• Control-group error for the current-value preset position	
		12	• Control-group error for the conveyor prereading-calculation start point	
		13	• Occupation control-group error	
		14	• Control-group error for multi-layer sampling	
		15	• Control-group error for servo hand	
		16	• MRESET control-group error	
		17	• Control-group error for general-purpose area of path correction amount	
		18	• Control-group error for a conveyor calibration file	
		19	• Control-group error for the pre-reading-calculation start point (for dm_st_pos)	
4430	CPU COMMUNICATION ERROR		An error occurred in interrupt process between CPUs.	<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		1	• Interrupt processing error between MOTION and system control section	
		2	• Interrupt processing error between MOTION and SL#1	
		3	• Interrupt processing error between MOTION and SL#2	
		4	• Interrupt processing error between MOTION and SL#3	
		5	• Interrupt processing error between MOTION and SL#4	
		6	• Interrupt processing error between MOTION and CV#1	
		7	• Interrupt processing error between MOTION and CV#2	
		8	• Interrupt processing error between MOTION and PS#1	
		9	• Interrupt processing error between MOTION and PS#2	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4431	JHM ERROR	Data error occurred in job control process.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>• Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		1	• An error occurred in JMS system call when an attempt was made to open a job.	
		2	• No space was found in job handle value storage area when an attempt was made to open a job.	
		3	• No job handle was found.	
		4	• Job control proprietary is incorrect.	
		5	• Job control proprietary could not be changed.	
		6	• An error occurred in exclusive control.	
4432	INSTRUCTION INTERPRETER ERROR	An error occurred in instruction interpretation/execution process.		<ul style="list-style-type: none"> <li>• Reset the alarm, reselect the job, and then try again.</li> <li>• Delete the instruction where an alarm occurred, and then reregister and execute the instruction.</li> <li>• Delete the job where an alarm occurred, and then reregister and execute the job.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		1	• The intermediate code of the instruction that is to be executed is incorrect.	
		3	• Destination (variable) tag arrangement is incorrect.	
		4	• Tag data type is incorrect.	
		5	• Box number is incorrect.	
		6	• An error occurred in block separation processing of intermediate code.	
		8	• Box number definition is duplicated.	
		9	• Undefined instruction was found at block separation of intermediate code.	
		10	• IPRM is not set.	
		11	• An error occurred in tag data search process.	
		12	• An error occurred move instruction search process.	
		13	• An error occurred reference point search process.	
		14	• Variable information does not exist.	
		16	• An error occurred at position file data reading.	
		17	• Variable data type is not defined.	
		18	• An instruction is included with incorrect intermediate code in expression instruction.	
		19	• The syntax in expression instruction is incorrect.	
		20	• The tag data length is zero when tag data is read.	
		21	• The necessary tag data is not set.	
		22	• The object to be processed was secret variable in position file control process, so it could not be processed.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4432	INSTRUCTION INTERPRETER ERROR	An error occurred in instruction interpretation/execution process.		<ul style="list-style-type: none"> <li>• Reset the alarm, reselect the job, and then try again.</li> <li>• Delete the instruction where an alarm occurred, and then reregister and execute the instruction.</li> <li>• Delete the job where an alarm occurred, and then reregister and execute the job.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		23	• The object to be processed was position type variable in position file control process, so it could not be processed.	
		24	• Job argument settings do not match when a variable is given and/or taken between jobs.	
		25	• An attempt was made to perform undefined operation at four-rule operation instruction.	
		26	• Arithmetic stack used for expression operation exceeded.	
		27	• Arithmetic stack used for expression operation is empty.	
		28	• Operation items are lacking in expression operation and operation processing cannot be performed.	
		254	• Access mechanism for old parameters is used.	
		255	• An exceptional error occurred.	
4433	UNDEFINED GLOBAL VARIABLE	The global variable is not defined.		Needs investigation. Contact your Yaskawa representative.
		0	• The set data for byte type variable (S1D parameter) area is incorrect.	
		1	• The set data for integer type variable (S1D parameter) area is incorrect.	
		2	• The set data for double-precision integer-type variable (S1D parameter) area is incorrect.	
		3	• The set data for real type variable (S1D parameter) area is incorrect.	
		4	• The set data for character-string type variable (S1D parameter) area is incorrect.	
		5	• The set data for robot-axis position-type variable (S1D parameter) area is incorrect.	
		6	• The set data for base-axis position-type variable (S1D parameter) area is incorrect.	
		7	• The set data for station-axis position-type variable (S1D parameter) area is incorrect.	
4435	UNDEFINED LOCAL VARIABLE	The local variable is not defined.		Set the number of local variables to be used in the job header.
		0	• The byte type variable is not defined.	
		1	• The integer type variable is not defined.	
		2	• The double-precision integer-type variable is not defined.	
		3	• The real-number type variable is not defined.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4435	UNDEFINED LOCAL VARIABLE	The local variable is not defined.		Set the number of local variables to be used in the job header.
		4	• The character-string type variable is not defined.	
		5	• The robot-axis position-type variable is not defined.	
		6	• The base-axis position-type variable is not defined.	
		7	• The station-axis position-type variable is not defined.	
4436	LESS THAN 3 STEP (CIRCULAR)	---	An error occurred in circular interpolation instruction execution. • There is no continuous three points or more for circular interpolation step.	Reset the alarm, and then perform teaching so that circulation interpolation steps are continuous three points or more.
4437	LESS THAN 3 STEP (SPLINE)	---	An error occurred in spline interpolation instruction execution. • There is no continuous three points or more for spline interpolation step.	Reset the alarm, and then perform teaching so that spline interpolation steps are continuous three points or more.
4438	UNDEFINED JOB	---	The job to be executed is not registered in the memory.	• Reset the alarm, and then register the job. • Delete the CALL/JUMP instruction where an alarm occurred.
4439	UNDEFINED LABEL	---	An error occurred in label jump execution. • The label for jump destination does not exist in the job.	• Reset the alarm, and then register the label. • Delete the JUMP instruction where an alarm occurred.
4440	UNDEFINED RETURN JOB	---	Call source job does not exist in the job call stack.	• Reset the alarm, and then execute the master (start) job. • Delete the RET instruction.
4441	LACK OF LOCAL VARIABLE AREA	---	An error occurred when memory area for local variable was obtained. • Memory area is lacking because too many local variables in the job are used.	Reset the alarm, and then reduce the number of local variables to be used.
4444	UNSUCCESSFUL FINE POSITIONING	---	When PL = 0 or an external servo turned OFF, the number of the servo error pulses did not fall in the limit range that had been set in a parameter, within the specified time.	• Reset the alarm, and then check if external force is applied to the manipulator. If external force is applied to the manipulator, move the manipulator by the axis operation, etc. to remove the external force. Then, try again. • If the error occurs again although no external force is applied to the manipulator, re-insert the system CPU board correctly. If the error occurs again, contact your Yaskawa representative.
4445	DATA PRESET ERROR	Data error occurred at job prereading reinterpretation.		• Reset the alarm, reselect the job, and then try again. If the error occurs again, contact your Yaskawa representative.
		1	• The token for prereading processing could not be obtained.	
		2	• The prereading processing has not been completed within the time, and the waiting time for completion exceeded the limit.	
		3	• The prereading operation processing has not been completed within the time, and the waiting time for completion exceeded the limit.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4445	DATA PRESET ERROR		Data error occurred at job prereading reinterpretation.	<ul style="list-style-type: none"> <li>Reset the alarm, reselect the job, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		4	<ul style="list-style-type: none"> <li>An error occurred in prereading operation process.</li> </ul>	
		5	<ul style="list-style-type: none"> <li>A_BANK conversion has not been completed.</li> </ul>	
		255	<ul style="list-style-type: none"> <li>An exceptional error occurred in job execution process.</li> </ul>	
4446	OVER VARIABLE LIMIT		The variable value exceeded the limit.	Change the variable data type for storage or correct the job, so that the variable value is within the limit.
		0	The variable value exceeded the limit.	
		1	The value for the binary (0/1) data type variable exceeded the limit.	
		2	The value for the signed 1-byte data type variable is less than the minimum value.	
		4	The value for the signed 2-byte data type variable is less than the minimum value.	
		6	The value for the signed 4-byte data type variable is less than the minimum value.	
		8	The value for the real-number 4-byte data type variable is less than the minimum value.	
		32770	The value for the signed 1-byte data type variable exceeded the maximum value.	
		32771	The value for the unsigned 1-byte data type variable exceeded the maximum value.	
		32772	The value for the signed 2-byte data type variable exceeded the maximum value.	
		32773	The value for the unsigned 2-byte data type variable exceeded the maximum value.	
		32774	The value for the signed 4-byte data type variable exceeded the maximum value.	
		32775	The value for the unsigned 4-byte data type variable exceeded the maximum value.	
		32776	The value for the real-number 4-byte data type variable exceeded the maximum value.	
		32780	The value for the label-name type variable exceeded the maximum value.	
		32781	The value for the job-name type variable exceeded the maximum value.	
		32782	The value for the character-string type variable exceeded the maximum value.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4446	OVER VARIABLE LIMIT		The variable value exceeded the limit.	Change the variable data type for storage or correct the job, so that the variable value is within the limit.
		32783	The value for comment type variable exceeded the maximum value.	
4447	DEFECTIVE TAUGHT POINT (CIRC)	0	Incorrect teaching of circular interpolation steps • The three points taught for the circular interpolation step lie in a straight line.	Teach the 3 points again so that they do not lie in a straight line.
4448	WEAVING CONTROL ERROR		An error occurred in weaving control.	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		1	• Weaving control-group designation error	
		4	• When the speed is specified by weaving time in the weaving file, zero or the negative value is set for the weaving time.	Reset the value 0.1 seconds or more.
		5	• When the speed is specified by frequency in the weaving file, zero or the negative value is set for the frequency.	Reset the value 0.1 Hz or more.
		6	• When the timer mode is specified in the weaving file, a negative value is set for the timer value.	Set a positive value for the timer value.
		7	• For triangle or L-type weaving, zero is set for the vertical or horizontal distance.	Set a positive value for the vertical and horizontal distance.
		8	• The coordinate control axis designation for the reference point is different from actual control axis.	Internal control error. If the error occurs again, contact your Yaskawa representative.
		9	• The distance between the point P and the TCP could not be calculated in wrist weaving.	Set the correct dimensions in the tool data.
		10	• The distance between the point P and the TCP could not be calculated in circular wrist weaving.	
		11	• The Y-direction element of circular coordinate system for circular wrist weaving could not be calculated.	Contact your Yaskawa representative.
		12	• The X-direction element of circular coordinate system for circular wrist weaving could not be calculated.	
		14	• Weaving basic-orientation calculation error	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		15	• Calculation error of horizontal- and wall-direction vector for weaving	
4449	UNMATCHED POSNVAR DATA ERROR	---	The storage destination data (pulse/Cartesian) is different from the storage source data.	Match the position type variable data type for the storage source/destination.
4450	FILE NO. ERROR		An error occurred in tool file number check.	• Reset the alarm, reselect the job, and then try again. If the error occurs again, contact your Yaskawa representative.
		1	An error occurred in tool file number check.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4450	FILE NO. ERROR		An error occurred in tool file number check.	<ul style="list-style-type: none"> <li>Reset the alarm, reselect the job, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		2	An error occurred in user coordinate file number check.	
		3	An error occurred in calibration file number check between the manipulators.	
		4	An error occurred in tool calibration file number check.	
		5	An error occurred in reference point number check.	
		6	An error occurred in weaving file number check.	
		7	An error occurred in check for welding start condition file number.	
		8	An error occurred in check for welding end condition file number.	
		9	An error occurred in conveyor characteristic file number check.	
		10	An error occurred in press characteristic file number check.	
		11	An error occurred in gun characteristic file number check.	
		12	An error occurred in conveyor calibration file number check.	
		13	An error occurred in argument number check.	
		14	An error occurred in check for motor gun characteristic file number.	
4451	UNDEFINED REFERENCE	---	The reference point (reference point number in binary for subcode) is not registered or is insufficient.	Register the reference point.
4452	STACK MORE THAN 8 (JOB CALL)	---	An attempt was made to add more than eight stacks in the job call stack.	Reset the alarm, and then correct the job so that the number of nests for CALL instruction is eight or less.
4453	OVER VARIABLE NO.	---	The variable number (the variable number which an attempt was made to use for subcode) is out of range.	Correct the job using the variable number within the range.
4454	UNDEFINED WELDER CONDITION FILE	---	The arc welding characteristic file cannot be accessed. <ul style="list-style-type: none"> <li>The arc welding characteristic file is not set.</li> </ul>	Complete the settings for the arc welding characteristic file.
4455	UNDEFINED ARC START COND FILE	---	The welding start condition file cannot be accessed. <ul style="list-style-type: none"> <li>The welding start condition file is not set.</li> </ul>	Complete the settings for the welding start condition file.
4456	UNDEFINED ARC END COND FILE	---	The welding end condition file cannot be accessed. <ul style="list-style-type: none"> <li>The welding end condition file is not set.</li> </ul>	Complete the settings for the welding end condition file.



Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4457	WRONG WELDER SELECTION	---	An error occurred in welder type check. • The reference unit for the welding voltage and the welder type (independent/unified) do not match.	Correct the reference unit for the welding voltage.
4459	EXCESSIVE INSTRUCTION EQUATION	---	An error occurred in expression operation. • The operation is impossible because the expression is too long.	Separate the operation expression, shorten the expression, and then register it to a job.
4460	ZERO DEVIDED OCCURRENCE	---	An error occurred in operation instruction. • Zero division occurred.	Do not divide by zero.
4461	UNDEFINED AUTO WELD RELEASE COND	---	An error occurred in automatic welding release conditions. • The number of welding release condition is zero for arc auxiliary file.	Set the number of times of welding release condition, and then try again.
4462	UNDEFINED POSITION FOR ARC RETRY	---	An error occurred at arc retry execution. • The arc retry has been set, but no move instruction exists following ARCON instruction.	Set the move instruction following ARCON instruction.
4463	PARITY ERROR	---	An error occurred in data for user I/O group. • The parity check for user I/O group detected the data error.	Check the parity data of the user I/O group.
4464	OVER BCD RANGE	---	The BCD value exceeded the limit. • An attempt was made to output a value above the maximum value that can be expressed in Binary Coded Decimal: 99 (decimal) when no parity check is specified, and 79 (decimal) when parity check is specified. • An attempt was made to read a data that cannot be expressed in Binary Coded Decimal (a data whose lower or upper 4 bits exceeded 9 in decimal) in the variable.	• Correct the data. • Correct the data designation (Binary or BCD) or parity check designation (with or without.)
4465	OVER BINARY RANGE (PARITY)	---	The binary data exceeded the limit. • An attempt was made to output a value that exceeded 127 (decimal) to the user I/O when parity check was specified.	• Correct the data. • Correct the parity check designation.
4466	OFFLINE UNDEFINED COMMAND (ARITH)	0	An undefined command was issued to the offline position-data preparation section.	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
4467	USER COORDINATES GENERATION STEP SHORTAGE	0	An error occurred at user coordinate creation by a job. • The number of steps was lacking for a job for user coordinate creation.	Be sure that the number of steps will be three or more.
4468	ROBOT CALIBRATION DATA ERROR		The calibration data between manipulators could not correctly be prepared.	
		1	• The calibration between manipulators cannot be executed for this model.	The calibration function between manipulators cannot be used for this model.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4468	ROBOT CALIBRATION DATA ERROR		The calibration data between manipulators could not correctly be prepared.	Set the different groups for the master group and the slave group.
		2	• The master group and the slave group are set to the same group.	
		3	• Incorrect designation of the control group for master group	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		4	• Incorrect designation of the control group for slave group	
		5	• Incorrect designation of the occupation control group for calibration data	
		6	• Incorrect designation of the enabling control group for calibration data	
		7	• Among three points in the master-group's calibration data, two or three points are on the same point.	Teach the different 3 points again.
		8	• Among three points in the slave-group's calibration data, two or three points are on the same point.	
		9	• The number of the teaching points for calibration data is insufficient.	Teach the specified number of points for the calibration data.
4469	ROBOT CALIBRATION FRAME ERROR		The conversion coordinates for calibration between manipulators could not be prepared.	The calibration function between manipulators cannot be used for this model.
		1	• The calibration between manipulators cannot be executed for this model.	
		2	• The master group and the slave group are in the same group.	Separate the master group and slave group.
		3	• Incorrect designation of the control group for master group	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		4	• Incorrect designation of the control group for slave group	
		5	• Calibration data setting error	
4470	ROBOT CALIBRATION STEP SHORTAGE	0	An error occurred at calibration data creation between manipulators. • The number of steps was lacking for a job for calibration data creation between manipulators.	Correct the number of steps for a job.
4471	CALIBRATION DATA ERROR		The tool calibration data could not correctly be prepared.	Teach the specified number of points.
		1	• Incorrect number of teaching points for tool calibration	
		2	• Incorrect designation of the occupation control group for calibration data	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		3	• Incorrect designation of the enabling control group for calibration data	
		4	• Incorrect designation of the control group for calibration data	
		10	Calibration could not be executed.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4472	TOOL CALIBRATION DATA ERROR	0	The tool calibration data could not correctly be prepared. Calibration could not be executed.	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
4473	ARITHMETIC ALARM RESET ERROR	0	The alarm occurred in the calculation section could not be reset.	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
4474	WRONG CONTROL GROUP AXIS	---	The CALL/JUMP destination job could not be executed. <ul style="list-style-type: none"> <li>An attempt was made to call or jump to a job whose control group cannot be controlled. (Sub code: The related control-group)</li> </ul>	<ul style="list-style-type: none"> <li>Make the setting in advance so that the control group of the CALL/JUMP designation job is included in that of the CALL/JUMP source job.</li> <li>Use a PSTART instruction when the independent control function is used.</li> </ul>
4475	CANNOT EXECUTE JOB (NO ROBOT)	0	An attempt was made to execute a job without robot axis. <ul style="list-style-type: none"> <li>The robot axis is not designated for the control-group of the job at execution of a work instruction that uses a manipulator.</li> </ul>	Add the robot axis to the control-group of the job.
4476	CANNOT EDIT (EDIT LOCKJOB)	An attempt was made to change the data for the job prohibited from being edited.		Release the prohibition.
		0	<ul style="list-style-type: none"> <li>An attempt was made to change the tag data.</li> </ul>	
		1	<ul style="list-style-type: none"> <li>An attempt was made to change the speed tag data.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>An attempt was made to change the board thickness tag data.</li> </ul>	
4477	SELECT ERROR (APPLICATION)	---	Incorrect selection of application <ul style="list-style-type: none"> <li>When executing a work instruction, the application selection parameter (parameter exclusive for manufacturer) is inconsistent with the application parameter (AP parameter). (Subcode: Application number)</li> </ul>	Needs investigation. Contact your Yaskawa representative.
4480	SELECT ERROR (SENSOR)	---	Incorrect selection of sensor function <ul style="list-style-type: none"> <li>When executing a work instruction, the sensor application selection parameter (parameter exclusive for manufacturer) is inconsistent with the sensor parameter (SE parameter). (Subcode: Sensor number)</li> </ul>	Needs investigation. Contact your Yaskawa representative.
4484	WRONG PORT NO. (ANALOG OUTPUT)	---	Incorrect analog output port selection parameter <ul style="list-style-type: none"> <li>The value of the parameter AxP010 indicating the leading number of analog output port used for arc welding or sealing application was incorrect. (Subcode: Application number)</li> </ul>	Correct the parameter value.
4485	WRONG SELECTION (SENSOR)	---	When executing a sensor instruction, the robot specified to use the sensor (system parameter) and the robot specified to use the application (system parameter) are unmatched.	Needs investigation. Contact your Yaskawa representative.
4486	PASS OVER	---	When executing COM-ARC function, the path was beyond the specified path-over monitor zone.	<ul style="list-style-type: none"> <li>Remove the cause of the path-over.</li> <li>Set the path over radius within the allowable range.</li> </ul>

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4487	WRONG MECH PARAMETER FILE	0	An error occurred in mechanical parameter for the path control section.	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
4488	PT frame not completed	---	PT frame not completed	• This alarm does not occur (No alarm data is used).
4489	DEFECTIVE TAUGHT POINT (CUTTING)		The CUT instruction could not be executed.	Set zero pulse for the C-and W-axis position at the cutting start position.
		1	• The C- and W-axis position at the cutting start position is not zero pulse.	
		2	• Zero is set for the cutting radius.	Set a value bigger than 0 for the radius.
		3	• The cutting machine axis is not mounted.	The CUT instruction can be used for the manipulator with small-circle cutting axis only.
		4	• This manipulator cannot perform a hexagonal cutting motion.	This robot cannot perform a hexagonal cutting motion. Select an other cutting form.
4490	DEFECTIVE TAUGHT POINT (ENDLESS)		The Endless motion could not be performed.	To perform an interpolation motion such as MOVL and MOVC after an Endless rotation, execute an MRESET instruction beforehand.
		1	• After the Endless rotation completed, an attempt was made to execute an interpolation instruction such as MOVL and MOVC before executing an MRESET instruction.	
		2	• The base axis is set as an Endless rotation axis. The Endless function cannot be used with the base axis.	Change the parameter setting that designates the Endless rotation axis.
		3	• An attempt was made to execute the Endless function although the endless axis was not designated.	
		4	• The Endless axis exceeded the maximum pulse value ( $\pm 536870911$ ).	Correct the rotation amount so that the Endless axis does not exceed the maximum pulse value.
4491	CORREC- TIONAL DIREC- TION ERROR		An error occurred in the calculation section for the correcting direction at path correcting motion.	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		1	• Control-group designation error for correcting-direction preparation	
		2	• Designation error for the correcting-direction coordinates	Teach the correcting direction with the reference point (REFP).
		3	• When "any direction" is set for the correcting direction, the correction coordinates is not prepared.	
		4	• When "any direction" is set for the correcting direction, the reference points (REFP) are taught on the same point.	Teach the reference points (REFP) so that each point is different.
		5	• Designation error for the coordinated motion control axis at the reference point	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4492	POSITION CORRECTION ERROR	An error occurred in the calculation section for the correcting direction at path correcting motion.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	<ul style="list-style-type: none"> <li>Data unmatched between the correction amount data and the job data: The information about the control groups designated for the series of jobs, which is added to the correction amount data, does not include the valid control-group for the job.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>Data unmatched between the correction amount data and the job data: The valid control-group information that is added to the correction amount data disagrees with the valid control-group for the job.</li> </ul>	
4493	OVER TOOL FILE NO.	---	<p>The tool file number exceeded the limit value.</p> <ul style="list-style-type: none"> <li>The tool number for internal control is 25 or more.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and turn the power OFF then back ON. If the error occurs again, contact your Yaskawa representative.</li> </ul>
4494	DEFECTIVE TAUGHT POINT (WEAV)	1	<p>Incorrect teaching of weaving motion positions</p> <ul style="list-style-type: none"> <li>The weaving start point and end point are on the same point.</li> </ul>	Change the positions so that the weaving start point and end point are different.
4494	DEFECTIVE TAUGHT POINT (WEAV)	2	<p>Incorrect teaching of weaving motion positions</p> <ul style="list-style-type: none"> <li>Among the weaving start point, end point, and reference point, two or three points are on the same point.</li> </ul>	Change the positions so that the weaving start point, end point, and reference point are different.
4495	UNDEFINED ROBOT CALIBRATION	---	<p>Calibration between manipulators has not executed.</p> <ul style="list-style-type: none"> <li>A coordinated motion is impossible because no calibration between manipulators has been made.</li> </ul>	Before using the coordinated motion, execute the calibration between manipulators.
4496	PARAMETER ERROR	Setting error of motion control parameter		<ul style="list-style-type: none"> <li>Set a correct value. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	<ul style="list-style-type: none"> <li>The setting of the manipulator number is incorrect.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>Zero is set for the resolution.</li> </ul>	
		3	<ul style="list-style-type: none"> <li>Zero is set in the feedback pulse parameter.</li> </ul>	
		4	<ul style="list-style-type: none"> <li>The setting of L-axis ball-screw data is incorrect.</li> </ul>	
		5	<ul style="list-style-type: none"> <li>The setting of U-axis ball-screw data is incorrect.</li> </ul>	
		6	<ul style="list-style-type: none"> <li>Zero or a negative value is set for MAXPPS.</li> </ul>	
		7	<ul style="list-style-type: none"> <li>Zero or a negative value is set for the maximum acceleration speed.</li> </ul>	
		8	<ul style="list-style-type: none"> <li>Zero or a negative value is set for the maximum deceleration speed.</li> </ul>	
		9	<ul style="list-style-type: none"> <li>Zero or a negative value is set for the play-mode servo averaging time.</li> </ul>	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4496	PARAMETER ERROR	Setting error of motion control parameter		<ul style="list-style-type: none"> <li>Set a correct value.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		10	<ul style="list-style-type: none"> <li>The setting of the manipulator number is incorrect. An undefined type is designated.</li> </ul>	
		11	<ul style="list-style-type: none"> <li>The incorrect coordinate system is designated for the cubic interference. An undefined coordinate system is set.</li> </ul>	
		12	<ul style="list-style-type: none"> <li>The designation of the user coordinates number is incorrect. A number out of the setting range is set.</li> </ul>	
		13	The reduction ratio $\leq 0$ is output.	<ul style="list-style-type: none"> <li>Set a correct value for the resolution.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		14	<ul style="list-style-type: none"> <li>Zero or a negative value is set for the spring constant.</li> </ul>	<ul style="list-style-type: none"> <li>Set a correct value for the spring constant.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		15	<ul style="list-style-type: none"> <li>Zero or a negative value is set for the motor inertia.</li> </ul>	<ul style="list-style-type: none"> <li>Set a correct value for the motor inertia.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		16	<ul style="list-style-type: none"> <li>Zero or a negative value is set for the speed calculation constant.</li> </ul>	<ul style="list-style-type: none"> <li>Set a correct value for the speed calculation constant.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		17	<ul style="list-style-type: none"> <li>Dividing number setting error</li> </ul>	If the error occurs again, contact your Yaskawa representative.
		18	<ul style="list-style-type: none"> <li>The setting of allowable torque for the speed reducer is incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Correct the parameter setting.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		19	<ul style="list-style-type: none"> <li>The setting of allowable torque for the motor is incorrect.</li> </ul>	
		20	<ul style="list-style-type: none"> <li>The manipulator type is not applicable for torque acceleration/deceleration.</li> </ul>	Do not use the torque acceleration/deceleration with this manipulator.
		21	<ul style="list-style-type: none"> <li>Zero or a negative value is set for the balancer.</li> </ul>	<ul style="list-style-type: none"> <li>Set a correct value for the balancer.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		22	<ul style="list-style-type: none"> <li>The angle of hexagon set for the CUT instruction is out of the range "0 degree &lt; angle &lt; 60 degrees."</li> </ul>	<ul style="list-style-type: none"> <li>Set a correct value for the angle of hexagon.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		23	<ul style="list-style-type: none"> <li>Encoder type designation error</li> </ul>	If the error occurs again, contact your Yaskawa representative.
		24	<ul style="list-style-type: none"> <li>Observer sampling time error</li> </ul>	
		25	<ul style="list-style-type: none"> <li>Two-degree-of-freedom system Kp value error</li> </ul>	
		26	<ul style="list-style-type: none"> <li>The setting of torque acceleration/deceleration designation parameter is incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Correct the parameter setting.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		27	<ul style="list-style-type: none"> <li>Observer polarity setting error</li> </ul>	If the error occurs again, contact your Yaskawa representative.
		28	<ul style="list-style-type: none"> <li>The inertia value error for the shift value calculation</li> </ul>	
		29	<ul style="list-style-type: none"> <li>Observer attenuation constant error</li> </ul>	
		30	<ul style="list-style-type: none"> <li>Torque estimation parameter error</li> </ul>	
		31	<ul style="list-style-type: none"> <li>The segment clock error occurred when the PV loop is 1 ms.</li> </ul>	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4496	PARAMETER ERROR	Setting error of motion control parameter		If the error occurs again, contact your Yaskawa representative.
		32	• Non-robot axis observer selection error	
		33	• Zero is set for the response time constant.	• Correct the parameter setting. If the error occurs again, contact your Yaskawa representative.
		34	• Efficiency data error	If the error occurs again, contact your Yaskawa representative.
		35	• Zero is set for the averaging time constant.	• The averaging time constant must be set for the optimized acceleration/deceleration control. • Correct the parameter setting. If the error occurs again, contact your Yaskawa representative.
		36	• Torque limit ratio data error	If the error occurs again, contact your Yaskawa representative.
		37	• Coulomb friction data error	
		38	• Kinematic friction coefficient data error	
		39	• The setting in the optimized acceleration/deceleration designation parameter is incorrect.	• Correct the parameter setting. If the error occurs again, contact your Yaskawa representative.
		40	• An uninstalled function is designated.	• Correct the parameter setting. If the error occurs again, contact your Yaskawa representative.
		41	• The dynamics-model calculation at the optimized acceleration/deceleration is invalid.	If the error occurs again, contact your Yaskawa representative.
		42	• Zero is set for the inertia of dynamics fixed model.	• Correct the parameter setting. If the error occurs again, contact your Yaskawa representative.
		43	• Designation error for dynamics-model calculation type	If the error occurs again, contact your Yaskawa representative.
		44	• The optimized acceleration/deceleration control of speed limit function is disabled.	
		45	• The axis designation parameter for the speed limit function is not set.	• Correct the parameter setting. If the error occurs again, contact your Yaskawa representative.
		46	• The setting in the mode designation parameter for the speed limit function is incorrect.	
		47	• Zero or negative value is set in the allowable braking torque parameter for the speed limit function.	
		48	• Zero or a negative value is set in the speed adjustment ratio parameter for the speed limit function.	
		49	• Zero or a negative value is set in the torque limit adjustment ratio parameter for the acceleration/deceleration tuning.	
		50	• Zero or a negative value is set in the parameter that sets the shortest acceleration/deceleration time for when the excessive torque is applied at the optimized acceleration/deceleration.	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4496	PARAMETER ERROR	Setting error of motion control parameter		Correct the parameter setting.
		51	• Zero is set for the dimension information "a3" for the SKR manipulator.	
		52	• The setting of sealer-gun control-group parameter for the servo sealer control is incorrect.	
		53	• The parameter setting for the Cartesian manipulator X-axis data is incorrect.	
		54	• The parameter setting for the Cartesian manipulator Y-axis data is incorrect.	
		55	• The setting for the Dual-arm manipulator is incorrect.	If the error occurs again, contact your Yaskawa representative.
		56	• Zero or a negative value is set in the FORMCUT maximum acceleration/deceleration time parameter.	Correct the parameter setting.
		57	• The setting of expanded check-point designating bits for the arm interference check is incorrect.	If the error occurs again, contact your Yaskawa representative.
		60	• Zero or a negative value is set for the sphere at the arm interference check point.	Correct the parameter setting.
		61	• Zero or a negative value is set for the cylinder at the arm interference check point.	
		62	• The number of designated check points for the arm interference check is insufficient.	
		70	• All of X, Y, and Z value of the expanded check-point 1 for the arm interference check are set to zero.	
		71	• All of X, Y, and Z value of the expanded check-point 2 for the arm interference check are set to zero.	
		85	• The setting of wrist axis angle for tube-incorporated wrist type manipulators or three-roll wrist type manipulators is incorrect.	Change the parameter setting to disable the special link JOG operation for this manipulator.
		86	• The special link JOG operation cannot be used with this manipulator.	
		87	• The setting in the parameter for special angle limit check designation is incorrect.	
		91	• The setting of the deceleration speed for the path-priority control is less than zero.	If the error occurs again, contact your Yaskawa representative.
		92	• A negative value is set in the roundness parameter for the path-priority control.	Correct the parameter setting.
		93	• The link parameter for the cutting device is not set.	



## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4496	PARAMETER ERROR	Setting error of motion control parameter		This function cannot be used for control groups other than the robot axis. Correct the parameter setting.
		95	<ul style="list-style-type: none"> <li>The real-time bending correction function is enabled for a control-group other than robot axis.</li> </ul>	
		96	<ul style="list-style-type: none"> <li>Zero is set for the dimension information "a2" for the Arc Cell Torch Arm type manipulators.</li> </ul>	Correct the parameter setting.
		97	<ul style="list-style-type: none"> <li>Zero is set for the deceleration ratio for double T-axis unit of the V-shaped double T-axis manipulator.</li> </ul>	Correct the parameter setting.
4497	DEFECTIVE TAUGHT POINT (CALIB)	Incorrect teaching points for calibration between manipulators		Perform the teaching again so that the teaching points are different from one another.
		1	<ul style="list-style-type: none"> <li>Some of the teaching points for master-group are on the same point.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>Some of the teaching points for slave-group are on the same point.</li> </ul>	
		3	<ul style="list-style-type: none"> <li>The 2nd-axis positions of C3, C4, and C5 of station axes are not the same.</li> </ul>	Perform the teaching again so that the 2nd-axis positions of C3, C4, and C5 of the station axes are the same.
		4	<ul style="list-style-type: none"> <li>The 1st-axis positions of C1, C2, and C3 of station axes are not the same.</li> </ul>	Perform the teaching again so that the 1st-axis positions of C1, C2, and C3 of station axes are the same.
		5	<ul style="list-style-type: none"> <li>The 2nd-axis positions of C1, C2, and C3 of station axes are the same.</li> </ul>	Perform the teaching again so that the 2nd-axis positions of C1, C2, and C3 of station axes are not the same.
		6	<ul style="list-style-type: none"> <li>The 1st-axis rotation direction of C3, C4, and C5 of station axes are not the same.</li> </ul>	Perform the teaching again so that the 1st-axis rotation direction of C3, C4, and C5 of station axes are the same.
		7	<ul style="list-style-type: none"> <li>The 1st-axis (elevation axis) positions of C1, C2, and C3 of station axes are not the same.</li> </ul>	Perform the teaching again so that the 1st-axis (elevation axis) positions of C1, C2, and C3 of station axes are the same.
		8	<ul style="list-style-type: none"> <li>The 1st-axis (elevation axis) positions of C3, C4, and C5 of station axes are not the same.</li> </ul>	Perform the teaching again so that the 1st-axis (elevation axis) positions of C3, C4, and C5 of station axes are the same.
4498	CANNOT EXECUTE JOB (NO GRP AXIS)	---	<ul style="list-style-type: none"> <li>An error occurred in a job without control group.</li> <li>An attempt was made to execute an instruction that could not be executed in a job without control group.</li> </ul>	Register the instruction in a job with control group.
4499	UNDEFINED POSITION VARIABLE	---	<ul style="list-style-type: none"> <li>The position type variable is not registered.</li> <li>An attempt was made to use the position type variable that was not set. (Subcode: The variable number)</li> </ul>	Set the position type variable.
4500	UNDEFINED USER FRAME	---	<ul style="list-style-type: none"> <li>The user coordinate is not registered.</li> <li>An attempt was made to use the user coordinate that was not set. (Subcode: User coordinate number)</li> </ul>	Set the user coordinate.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4501	OUT OF RANGE (PARALLEL PROCESS)	---	The number of tasks exceeded the limit. • An error occurred in the multi-task control process for the independent control function. (Sub code: Task number)	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
4502	SL BOARD ON-LINE ERROR	---	An error occurred in option board at power ON. The option board was detected not to operate normally at power ON.	• Remove the option board, and insert it properly again. If the error occurs again, contact your Yaskawa representative.
4505	UNDEFINED POSITION FOR ARC ON	---	Arc retry could not be executed because there was no step before the ARCON instruction.	Register a step before the ARCON instruction.
4506	UNDEFINED POS FOR RESTART RETURN	---	Arc-restart-return could not be executed because there was no restart-return step in the job. (Example: A retry request was made while executing a step of the called job.)	Reset the alarm, and then re-program the job.
4507	REFP POS ERROR (SEARCH MOTION)	---	Incorrect teaching point for search detection • The search start point and the motion target point are the same, or the distance between the two points is too short.	• Perform the teaching again so that the search start point and the motion target point are not the same. • Increase the distance between the search start point and the motion target point.
4508	SPECIFIED ERROR (COORDINATE)	An invalid coordinate system was specified.		Reset the alarm, and then specify a valid coordinate system.
		0	• The specified coordinate system does not exist.	
		1	• Designation error of the master tool coordinate system. This coordinate system cannot be used.	
		2	• Designation error of the tool coordinate system. This coordinate system cannot be used.	
		6	• Designation error of the conveyor coordinate system. This coordinate system cannot be used.	
		7	• Designation error of the weaving coordinate system. This coordinate system cannot be used.	
		8	• Designation error of the COMARC coordinate system. This coordinate system cannot be used.	
		10	• Designation error of the cylindrical coordinate system. This coordinate system cannot be used.	
		11	• Designation error of the coordinate system for the external reference point. This coordinate system cannot be used.	
		12	• Designation error of the coordinate system for 3D shifting. This coordinate system cannot be used.	
		15	• Designation error of the coordinate system at IMOV for 3D shifting. This coordinate system cannot be used.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4508	SPECIFIED ERROR (COORDINATE)	An invalid coordinate system was specified.		Reset the alarm, and then specify a valid coordinate system.
		16	<ul style="list-style-type: none"> <li>Designation error of the H-LINK type cylindrical coordinate system. This coordinate system cannot be used.</li> </ul>	
4509	MFRAME ERROR	1	An error occurred at MFRAME execution.	The master or slave control group is incorrect when the master tool user coordinate is specified.
4510	CANNOT EXECUTE INSTRUCTION (SQRT)	---	<p>The SQRT instruction could not be executed.</p> <ul style="list-style-type: none"> <li>An attempt was made to calculate the square root of negative value. (The second argument was negative.)</li> </ul>	Correct the job.
4511	OUT OF RANGE (DROP-VALUE)	---	<p>Incorrect robot position when the servo was turned ON</p> <p>The pulse difference of the robot position exceeded the allowable value between when the servo was OFF previously and when the servo was ON this time.</p> <p>The standard allowable number of pulses is 100. (Subcode: Control group exceeding the allowable value.)</p>	Reset the alarm, and then try again.
4512	TWO STEPS SAME LINE (3 STEPS)	---	<p>The teaching points are aligned in a straight line.</p> <ul style="list-style-type: none"> <li>In the user coordinates for calibration between manipulators, three or more teaching points are aligned in a straight line.</li> </ul>	Perform the teaching again so that the teaching points are not aligned in a straight line.
4513	EXCESSIVE SEGMENT (SAFETY: 1) : LOW	---	At the safety speed 1, the manipulator motion speed exceeded the speed limit value (LOW level).	<ul style="list-style-type: none"> <li>Reduce the speed of the step (move instruction) where the alarm occurred.</li> <li>The manipulator may be near the singular point. Change the position and orientation of the manipulator.</li> </ul>
4514	EXCESSIVE SEGMENT (SAFETY: 1) : HIGH	---	At the safety speed 1, the manipulator motion speed exceeded the speed limit value (HIGH level).	<ul style="list-style-type: none"> <li>Reduce the speed of the step (move instruction) where the alarm occurred.</li> <li>The manipulator may be near the singular point. Change the position and orientation of the manipulator.</li> </ul>
4515	EXCESSIVE SEGMENT (SAFETY: 2) : LOW	---	At the safety speed 2, the manipulator motion speed exceeded the speed limit value (LOW level).	<ul style="list-style-type: none"> <li>Reduce the speed of the step (move instruction) where the alarm occurred.</li> <li>The manipulator may be near the singular point. Change the position and orientation of the manipulator.</li> </ul>
4516	EXCESSIVE SEGMENT (SAFETY: 2) : HIGH	---	At the safety speed 2, the manipulator motion speed exceeded the speed limit value (HIGH level).	<ul style="list-style-type: none"> <li>Reduce the speed of the step (move instruction) where the alarm occurred.</li> <li>The manipulator may be near the singular point. Change the position and orientation of the manipulator.</li> </ul>
4517	SEARCH MONITOR SET ERROR (SERVO)	---	<p>An error occurred in search/monitoring mode settings in servo section.</p> <ul style="list-style-type: none"> <li>An error occurred in interface with servo section at search/monitoring mode. (Subcode: The related control-group)</li> </ul>	Check the system versions for XCP01 and AXA01.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4518	SEARCH MON RELEASE ERROR	---	An error occurred in search/monitoring mode releasing in servo section. • An error occurred in interface with servo section at search/monitoring mode. (Subcode: The related control-group)	Check the system versions for XCP01 and AXA01.
4519	SPHERE INTRF ERR (ROBOT) CALCULATION	1	An error occurred in sphere interference between manipulators. • No calibration between manipulators has been made.	Perform the calibration between manipulators.
4520	AXIS BLOCKING	---	A motion was commanded for the group axis during axis block at play mode. (Subcode: The related control-group)	Reset the alarm, and then try again. Turn ON the general-purpose input signal set in the parameter.
4521	WRONG JOB TYPE	Job type is inconsistent.		Check that what type of job will be started before starting.
		0000_0001	• A robot job was started from the concurrent job at CALL/JUMP instruction execution.	
		0000_1001	• A concurrent job was started from the robot job at CALL/JUMP instruction execution.	
		1000_0001	• A system job was started from the robot job at CALL/JUMP instruction execution.	
4522	TAG DATA CHANGE PROCESS ERROR	An error occurred at tag data change.		• Correct the job file. If the error occurs again, contact your Yaskawa representative.
		2	• An error occurred at instruction read-in.	
		3	• The tag is not registered.	
		7	An error occurred at tag data change.	
4524	CANNOT EXECUTE INST (CONCUR JOB)	---	An error occurred at concurrent job execution. • There was an unexecutable instruction such as move instruction in the concurrent job.	Correct the job.
4525	SPECIFIED JOB EXECUTION IMPOSSIBILITY	---	An error occurred at startup of multi-system job. • The specified job could not be executed.	Needs investigation. Contact your Yaskawa representative.
4527	UNDEFINED PORT NO. (AOUT)	---	Incorrect analog output port number • The specified analog output port number was not allowed.	Correct the specified analog output port number.
4528	SYNTAX ERROR	---	An error occurred in the instruction syntax. • The function and the corresponding instruction data is inconsistent in the system software. (Subcode: Box number)	• Needs investigation. Contact your Yaskawa representative. • If replacement of the system software is necessary, follow the instructions for replacement. After replacement, delete the corresponding instructions, and then re-register them.
4529	TWIN COORDINATED ERROR	An error occurred at twin synchronization execution.		Specify a R□+S□ job for the job started by SYNC instruction.
		1	• A job without control group was started by SYNC instruction.	
		2	• A job only with robot axes was started by SYNC instruction.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4529	TWIN COORDINATED ERROR	An error occurred at twin synchronization execution.		Specify a R□+S□ job for the job started by SYNC instruction.
		3	• A job only with master control group axes was started by SYNC instruction.	
		4	• At full synchronization, the completion timings of move instructions for the master and the slave disagreed.	• Correct the job. If the error occurs again, contact your Yaskawa representative.
		5	• At full synchronization, no operation request from the master was sent.	
		6	• At full synchronization, the execution timings of move instructions for the master and the slave disagreed.	• Correct the job. If the error occurs again, contact your Yaskawa representative.
4530	CONVEYOR SYNCHRONIZING ERROR	An error occurred in conveyor synchronization execution.		• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		1	• The base axis specification is other than 1 or 2 for conveyor characteristic file.	
		2	• No robot axis in the job for robot axis tracking	
		3	• No base axis in the job for base axis tracking	
		4	• The conveyor board number and conveyor characteristic file number used are incorrect.	
		5	• There was no conveyor start position data at prereading processing.	
		10	• No base axis in the job for arc tracking	
4531	CONVEYOR CHARACTERISTIC FILE UNSET	---	Conveyor characteristic file is not set. • "Use state" of the conveyor characteristic file set for the job is not set to "1: Use." (Subcode: Conveyor characteristic file number)	Set "Use state" of conveyor characteristic file set for the job to "1: Use."
4532	CONVEYOR SPEED DOWN	---	The conveyor speed decreased below the "Conveyor Lowest Speed" set in the conveyor characteristic file. (conveyor number for subcode.)	Correct the "Conveyor Lowest Speed" set in the conveyor characteristic file.
4533	CONVEYOR TRACKING CALCULATION ERROR	An internal control error occurred at conveyor tracking motion.		• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		1	• Designation error of the conveyor tracking control-group	
		2	• Designation error of the user coordinates for the conveyor tracking	
		3	• An attempt was made to use the conveyor tracking function with the slave manipulator at coordinate motion.	
		4	• Zero is set for the resolution for the turn-table synchronization.	Set a correct value for the resolution.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4534	TORQUE INTERFERENCE	---	Excessive interference torque • The load torque of an axis motor exceeded the allowable value when the manipulator is operating at the specified speed.	<ul style="list-style-type: none"> <li>• Check if the weight information in the tool file is correctly set.</li> <li>• Reduce the speed in the step where the alarm occurred.</li> <li>• Change the position and orientation in the step where the alarm occurred.</li> </ul>
4535	PSEND ERROR	An error occurred at PSEND instruction execution.		Check the destination address.
		1	• An attempt was made to send a mail to its own task.	
		3	• The mail box number is incorrect.	
4536	PRECV ERROR	An error occurred at PRECV instruction execution.		Check the destination address.
		1	• An attempt was made to receive a mail from its own task.	
		2	• The mail data type is inconsistent.	
		3	• The mail box number is incorrect.	
4537	OFFLINEMAIL BOX PROCESSING ERROR	An error occurred in mail box control in the offline processing section.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again.</li> <li>If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	• Mail box number error	
		2	• Undefined command for mail box operation	
		3	• OFF_MB_IFS pointer is incorrect.	
4538	ROBOT AXIS TRACKING IMPOSIBILITY	---	The robot axis tracking could not be executed. • An attempt was made to execute the SYMOVJ instruction at robot tracking.	Correct the job.
4539	CORNER R CONTROL ERROR	An internal control error occurred at the Corner-R motion.		Do not use the Corner-R motion for coordinated motion.
		1	• The Corner-R motion cannot be used for coordinated motion.	
		2	• An attempt was made to execute the Corner-R motion for the same point.	Perform the teaching again so that the start step and end step are not on the same point.
		3	• The Corner-R zone is taught on a straight line.	Perform the teaching again so that the Corner-R zone is not on a strait line.
		4	• The start position or end position for the Corner-R motion could not be calculated inside the start zone or the end zone.	<ul style="list-style-type: none"> <li>• Change the setting for the Corner-R radius.</li> <li>• Perform the teaching again for the start step or end step for Corner-R.</li> </ul>
		5	• The Corner-R motion cannot be used for coordinated motion (with master manipulators).	Do not use the Corner-R motion for master manipulators at coordinated motion.
		6	• The Corner-R motion cannot be used for MOVC, MOVs, and EIMOVc instructions.	Use a MOVL instruction when using the Corner-R motion.
		7	• The Corner-R motion is disabled during weaving.	Do not perform weaving when using the Corner-R motion.
		8	• Different tool numbers are set in a Corner-R zone (for the Corner-R middle step and end step).	Use the same tool number in a Corner-R zone.
		9	• The Corner-R motion is disabled when the higher-order acceleration/deceleration is specified.	Disable the higher-order acceleration/deceleration when using the Corner-R motion.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4539	CORNER R CONTROL ERROR	An internal control error occurred at the Corner-R motion.		Do not perform the conveyor tracking when using the Corner-R motion.
		17	<ul style="list-style-type: none"> <li>The Corner-R motion is disabled during conveyor tracking.</li> </ul>	
4540	JOB QUE EMPTY ERROR	---	No job queue data <ul style="list-style-type: none"> <li>"QUE" is used in CALL or JUMP instruction under the condition that no job queue is used.</li> </ul>	Set a data to a job queue, and then call "QUE."
4541	INVALID INPUT STRING (VAL)	---	An error occurred at VAL instruction execution. <ul style="list-style-type: none"> <li>An attempt was made to convert a character string that could not be converted to a numerical value.</li> </ul>	Check the data of character string of conversion source.
4542	MRESET ERROR	1	An error occurred at MRESET instruction execution. <ul style="list-style-type: none"> <li>An MRESET instruction was executed while no endless axis was designated.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4543	JOB CALL STACK ERROR	---	An error occurred at job return. <ul style="list-style-type: none"> <li>At job return, an attempt was made to fetch a data from an empty job call stack or to stack a data in the job call stack that is full.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4544	MID\$ ERROR	An error occurred at MID\$ instruction execution.		Check the data of the character string to be extracted.
		1	<ul style="list-style-type: none"> <li>The first character of character string to be extracted is null at MID\$ instruction execution.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>The extraction start position exceeds the character string length at MID\$ instruction execution.</li> </ul>	Check the extraction start position or the data of the character string to be extracted.
4545	COMMUNICATION SERVICE ERROR	---	An error occurred at OPEN/CLOSE instruction execution. <ul style="list-style-type: none"> <li>An error occurred in the communication service at OPEN/CLOSE instruction execution.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4546	CANNOT EXECUTE SYSTEM JOB	---	The system job could not be executed. <ul style="list-style-type: none"> <li>An error in the system number of system job. (Subcode: System number)</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4547	PRIMITIVE ERROR	---	A primitive error occurred in the system software. (Subcode: Error code)	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4548	CANNOT OPERATE SPECIFIED EVENT QUE	---	An error occurred at INIEVNT instruction execution. <ul style="list-style-type: none"> <li>The specified event could not be operated at INIEVNT instruction execution.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4549	INIEVNT NOT EXECUTED	---	An error occurred at INIEVNT instruction execution. <ul style="list-style-type: none"> <li>INIEVNT instruction was not executed before having executed the event related process. (Subcode: System number)</li> </ul>	Execute an INIEVNT instruction.

### 8.3 Alarm Message List

Alarm Message List				
Alarm Number	Message	Sub Code	Cause	Remedy
4550	CANNOT EXECUTE INST (USER JOB)	---	The specified instruction in the user job could not be executed. (Sub-code: System number)	Correct the job.
4551	CANNOT MEASURE TIP INSTALL COEF	---	The electrode installation correction value could not be measured on the moving side because that on the fixed side was not measured during execution of "SVGUNCL TWC=BE."	Execute "SVGUNCL TWC-AE" before executing "SVGUNCL TWC=BE."
4565	SOFTWARE UNMATCH		The used function and the system are inconsistent.	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	• The multi-layer welding function is not used.	
		2	• The observer function is not used.	
		3	• The TURBO function is not used.	
		4	• The COMARC function is not used.	
		5	• The conveyor/press synchronization function is not used.	
		6	• The shared motion function is not used.	
		7	• The layer motion function is not used.	
		8	• The general sensor function is not used.	
		9	• The servo float function is not used.	
		10	• The laser cutting function (with small circle cutter) is not used.	
		11	• The motor gun function (for spot welding application) is not used.	
		12	• The speed control function (VCON/VCOF) is not used.	
		13	• The servo hand function (for handling application) is not used.	
		14	• The laser cutting function (for form cutting operation) is not used.	
		15	• The series communication function between the systems (PSEND/PRECV) is not used.	
		16	• The motion extension function is not used.	
		17	• The bending function is not used.	
		18	• The ME-NET function is not used.	
		255	• An attempt was made to execute an undefined instruction.	
4566	USER COORDINATES GENERATION ERROR		An internal control error occurred at preparation of a user coordinates.	Perform the teaching again for the user coordinates.
		1	• The teaching points are incorrect.	
		2	• The teaching points for user-coordinate turning are incorrect.	



Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4566	USER COORDINATES GENERATION ERROR	3	An internal control error occurred at preparation of a user coordinates. • The robot axis is not specified for the control group of the job to prepare the user coordinates.	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		5	• Position data error	
		6	• Setting error of the slave group for user coordinate conversion	
4567	CANNOT MONITOR DISTANCE	---	The distance could not be monitored when executing a move instruction. • An attempt was made to execute MOVJ/MOVS instruction in arc retry or restart operation.	Do not perform the arc retry or restart operation, or change the interpolation instruction to MOVL/MOVC.
4568	UNDEFINED PRESS CHARACTERISTIC FILE	---	No press characteristic file is set. • An attempt was made to use the unused press characteristic file in a job. (Subcode: Press characteristic file number)	Set the status of press characteristic file to be used in the job to "Used State."
4569	PRESS RESOLUTION DATA UNSET	---	No press resolution data is set. • The status of press resolution data to be used in the job was set to "Incomplete." (Subcode: Press characteristic file)	Set the data, and then press "Data Set" button to set the status to "Completed."
4571	SERVO FLOAT MODE RELEASE ERROR	---	The servo float mode could not be reset when executing a FLOATOF instruction.	• Check the ROM version of servo board. • Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
4572	UNDEFINED MOTOR GUN CONTROL GRP	---	The control group for the motor gun is not set.	Restart the setting of configuration in maintenance mode, and correct the setting of motor gun axis.
4573	SPOT WELDER NUMBER ERROR	---	Incorrect spot welder number • The welder number set in the gun characteristic file is incorrect. (Subcode: Welder number)	Correct the welder number set in the gun characteristic file.
4574	SPOT WELD COMPLETE TIME LIMIT	---	The spot welding did not complete within the specified time. • Neither the welding completion signal nor the welding error signal was received from the timer conductor within the set time. (Subcode: Welder number)	• Remove the cause such as disconnection of power supply to the timer conductor, and then try again. • If the response from the timer takes too long time due to the system layout, increase the set time.
4575	ERROR IN WELD START TIMING SET	---	Incorrect setting of spot welding start timing • For motor gun, the welding timing was set to "After First Pressure" while no 2nd pressure was set.	Set the 2nd pressure, or change the start timing.
4576	ERR IN MOTOR GUN CONT MODE	---	An error occurred when setting the motor gun control mode. • Though a motor gun control mode setting command was sent to the servo section, no response was received.	• Check the ROM version of servo board. • Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
4577	ERR IN MOTOR GUN MODE RLSE	---	An error occurred when resetting the motor gun control mode. • Though a motor gun control mode resetting command was sent to the servo section, no response was received.	• Check the ROM version of servo board. • Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4578	SPOT WELD ERROR	---	An error occurred when executing spot welding. • An error occurred when executing welding using the specified system timer conductor. (Subcode: Welder number)	Reset the timer conductor where the welding error occurred, and then try again.
4579	ANTICIPATION CONTROL ERROR	An error occurred in the anticipation control processing.		Register a move instruction between work instructions.
		1	• No availability in anticipation control	
		2	• The anticipation data exceeded the maximum length.	
4580	ANTICIPATION DISTANCE SHORTAGE	---	Anticipation could not be executed at re-painting. • No return step in re-painting function after emergency stop	• Reset the alarm, and then try again. • Refer to <i>Painting System Additional Function Manual</i> for details.
4581	DEFECTIVE ANTICIPATION FILE	An error occurred in the anticipation output file.		Reset the alarm, and then correct the set number.
		1	• Incorrect setting of OT output number for anticipation output file	
		2	• Incorrect setting of OG output number for anticipation output file	
4583	CANNOT EXECUTE GUN TYPE	---	An invalid gun type is set. • The mode impossible to control is set for the gun.	Change the motion mode set to the gun.
4584	STRWAIT TIME OUT	---	An error occurred when executing a STRWAIT instruction. • No confirmation signal specified in the stroke change confirmation instruction was input within the set time.	• Remove the cause such as defective limit switch, and then try again. If the error occurs again, contact your Yaskawa representative.
4585	SERVO PART PG POWER ON ERROR	---	The PG power supply could not be turned ON. • The encoder power supply could not be turned ON when turning ON the control power supply.	Check the cable connection of motor gun encoder.
4587	MOTOR GUN CHANGE ERROR	An error occurred when changing the gun.		Check the cable connection of motor gun encoder.
		1	• A GUNCHG instruction was executed in the system configuration that did not allow the gun change function.	
		2	• A GUNCHG/PICK instruction was executed while the motor gun motor was servo ON.	Execute GUNCHG/PICK instruction when the motor gun motor is servo OFF.
		3	• A GUNCHG/PICK instruction was executed while the ATC was in unchuck status.	Execute GUNCHG/PICK instruction when the ATC is in chuck status.
		4	• A GUNCHG/PLACE instruction was executed while the ATC was in unchuck status.	
		5	• The encoder power supply could not be turned ON when executing a GUNCHG/PICK instruction.	Check the cable connection of motor gun encoder.
		6	• The encoder power supply could not be turned OFF when executing a GUNCHG/PLACE instruction.	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4587	MOTOR GUN CHANGE ERROR	7	<ul style="list-style-type: none"> <li>The gun number specified by the GUNCHG instruction did not agree with the gun identification signal.</li> </ul>	<ul style="list-style-type: none"> <li>Check the gun characteristic file number specified by GUNCHG instruction.</li> <li>Check the status of gun identification signal.</li> </ul>
		8	<ul style="list-style-type: none"> <li>The 1st gun axis selection signal is not set when executing the twin-wrist gun change.</li> </ul>	Check the 1st gun axis selection signal setting.
4587	MOTOR GUN CHANGE ERROR	An error occurred when changing the gun.		Check the setting for the gun axis selection signal.
		9	<ul style="list-style-type: none"> <li>The right and left gun axis selection signals were duplicated when executing the twin-wrist gun change.</li> </ul>	
4591	SERVO PART SPEED CONTROL MODE SETTING ERROR	---	<p>An error occurred at speed control mode setting.</p> <ul style="list-style-type: none"> <li>Though a speed control mode setting command was sent to the servo section, but no response was received.</li> </ul>	<ul style="list-style-type: none"> <li>Check the ROM version of servo board.</li> <li>Reset the alarm, and then try again.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
4592	SERVO PART SPEED CONTROL MODE RELEASE ERROR	---	<p>An error occurred at speed control mode release.</p> <ul style="list-style-type: none"> <li>Though a speed control mode release command was sent to the servo section, but no response was received.</li> </ul>	<ul style="list-style-type: none"> <li>Check the ROM version of servo board.</li> <li>Reset the alarm, and then try again.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
4593	SERVO HAND CONTROL MODE SETTING ERROR	---	<p>An error occurred at servo hand control mode setting.</p> <ul style="list-style-type: none"> <li>Though a servo hand control mode setting command was sent to the servo section, but no response was received.</li> </ul>	<ul style="list-style-type: none"> <li>Check the ROM version of servo board.</li> <li>Reset the alarm, and then try again.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
4594	SERVO HAND CONTROL MODE RELEASE ERROR	---	<p>An error occurred at servo hand control mode release.</p> <ul style="list-style-type: none"> <li>Though a servo hand control mode release command was sent to the servo section, but no response was received.</li> </ul>	<ul style="list-style-type: none"> <li>Check the ROM version of servo board.</li> <li>Reset the alarm, and then try again.</li> </ul> <p>If the error occurs again, contact your Yaskawa representative.</p>
4595	FORM CUTTING MOTION IMPOSSIBILITY	An internal control error occurred in the Form Cutting motion.		Correct the radius data.
		1	<p>The setting for radius is incorrect.</p> <ul style="list-style-type: none"> <li>For a circle, it is incorrectly set as: radius <math>\leq 0</math>, radius &lt; minimum radius value, or radius &gt; maximum radius value.</li> <li>For an ellipse, it is incorrectly set as: radius <math>\leq 0</math>, radius &lt; minimum radius value/2, or radius &gt; (maximum radius/2 – width/2).</li> </ul>	
		2	<p>The setting for width is incorrect.</p> <ul style="list-style-type: none"> <li>For a rectangle, it is incorrectly set as: width &lt; 1.0, width &gt; sqrt (maximum diameter<sup>2</sup> – height<sup>2</sup>), or width &gt; maximum diameter.</li> <li>It is incorrectly set as: width &lt; 0, width &gt; maximum diameter – 2 × radius.</li> </ul>	Correct the width data.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4595	FORM CUTTING MOTION IMPOSSIBILITY		An internal control error occurred in the Form Cutting motion.	Correct the height data.
		3	The setting for height is incorrect. • For a rectangle, it is incorrectly set as: height > maximum diameter, height < minimum diameter/2, or height > sqrt (maximum diameter <sup>2</sup> – width <sup>2</sup> ).	
		4	The setting for the corner radius is incorrect. • For a rectangle, it is incorrectly set as: corner radius > width/2 or corner radius > height/2.	Correct the corner radius data.
		5	The setting for overlap is incorrect. • For a rectangle, it is incorrectly set as overlap > width/2. • For a circle, it is incorrectly set as overlap > ABS (2π × radius). • For an ellipse, it is incorrectly set as overlap > π × radius +ABS (width/2).	Correct the overlap data.
		6	The setting for the cutting speed is incorrect. It is set as the cutting speed > maximum linear speed.	Correct the cutting speed data.
		7	• Coordinated motion cannot be used with the Form Cutting motion.	Do not use the coordinated motion.
		8	• Zero or a negative value is set in the minimum diameter parameter (S1CxG063) for the Form Cutting motion.	Correct the setting of the minimum diameter parameter (S1CxG063) for the Form Cutting motion.
		9	• Zero or a negative value is set in the maximum diameter parameter (S1CxG064) for the Form Cutting motion.	Correct the setting of the maximum diameter parameter (S1CxG064) for the Form Cutting motion.
		10	• Although "PLACEMENT" or "AUTO" is set for the start point designation on the FORM CUT SETTING window, the FORMAPR instruction was not executed.	Execute the FORMAPR instruction.
		11	• The Cut file setting of the FORMAPR instruction is different from that of the FORMCUT instruction.	The Cut file settings of FORMAPR and FORMCUT instructions must be same.
		12	• A FORMAPR instruction was used for the conventional FORMCUT instruction.	The FORMAPR instruction cannot be used for the conventional FORMCUT instruction. • Change the instruction. • Needs to validate the new FORMCUT instruction. Contact your Yaskawa representative.
		13	• A form other than a circle, rectangle, and ellipse was designated for the conventional FORMCUT instruction.	A form other than a circle, rectangle, and ellipse cannot be designated for the conventional FORMCUT instruction. • Designate a circle, rectangle, or ellipse. • Needs to validate the new FORMCUT instruction. Contact your Yaskawa representative.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4595	FORM CUTTING MOTION IMPOSSIBILITY	An internal control error occurred in the Form Cutting motion.		• Correct the radius data.
		90	• The radius data setting for special circular interpolation is incorrect. It is incorrectly set as the radius $\leq 0$ .	
		91	• The arc center coordinates could not be calculated at special circular interpolation. Incorrect teaching may be the cause.	Perform the teaching again.
		92	• The arc center coordinates could not be calculated at special circular interpolation. Incorrect teaching may be the cause.	
		93	• The averaging time at special circular interpolation motion is too short.	• Perform the teaching again so that the moving distance becomes longer. • Reduce the motion speed.
		94	• Because the designated plane included reference points at special circular interpolation motion, the arc center coordinates could not be calculated. Incorrect teaching of the reference point 2 may be the cause.	Perform the teaching again for the reference point 2.
		100	• The arc center position is not set for the special circular interpolation motion.	Perform the teaching for the reference point 1 as the arc center position.
4596	FORMCUT ERROR	1	An error occurred at FORMCUT instruction execution. An attempt was made to re-execute the FORMCUT instruction after interrupting it.	• Perform the teaching for the reference point 1 as the arc center position.
4597	OFFLINE POSITION DATA CONVERSION ERROR	An internal control error occurred at offline position data conversion.		• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		1	• Incorrect information of reference position data for offline position data conversion	
		2	• Incorrect user-coordinate number designation in the standard position data for offline position data conversion	
		3	• Incorrect reference-point data for offline position data conversion	
		4	• The standard position data for offline position data conversion could not correctly be calculated.	
		5	• Incorrect pulse incremental value for offline position data conversion	
		6	• The position data could not correctly be added by the pulse incremental value at the offline position data conversion.	
		7	• Incorrect Cartesian incremental value for offline position data conversion	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4597	OFFLINE POSITION DATA CONVERSION ERROR	An internal control error occurred at offline position data conversion.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		8	<ul style="list-style-type: none"> <li>The position data could not correctly be added by the Cartesian incremental value at the offline position data conversion.</li> </ul>	
		9	<ul style="list-style-type: none"> <li>The position conversion could not be done in the designated coordinate system at the offline position data conversion.</li> </ul>	
		10	<ul style="list-style-type: none"> <li>Incorrect incremental value of angle for offline position data conversion</li> </ul>	
		11	<ul style="list-style-type: none"> <li>The position data could not correctly be added by the incremental value of angle at the offline position data conversion.</li> </ul>	
		12	<ul style="list-style-type: none"> <li>The reverse shift value for 3D shifting could not correctly be calculated at the offline position data conversion.</li> </ul>	
		13	<ul style="list-style-type: none"> <li>The reverse shift value for 3D shifting could not correctly be added at the offline position data conversion.</li> </ul>	
		14	<ul style="list-style-type: none"> <li>The reverse shift value could not correctly be calculated at the offline position data conversion.</li> </ul>	
		15	<ul style="list-style-type: none"> <li>The reverse shift value could not correctly be calculated at the offline position data conversion.</li> </ul>	
		16	<ul style="list-style-type: none"> <li>The 3D shifting value could not correctly be added at the offline position data conversion.</li> </ul>	
		17	<ul style="list-style-type: none"> <li>The shift value could not correctly be added at the offline position data conversion.</li> </ul>	
		18	<ul style="list-style-type: none"> <li>No reference point is specified for the offline position data conversion.</li> </ul>	
		19	<ul style="list-style-type: none"> <li>The positions for the mirror shift function could not correctly be calculated at the offline position data conversion.</li> </ul>	
		20	<ul style="list-style-type: none"> <li>The positions could not correctly be converted for the mirror shift function at the offline position data conversion.</li> </ul>	
		21	<ul style="list-style-type: none"> <li>The expansion positions for the mirror shift function could not correctly be converted at the offline position data conversion.</li> </ul>	
		22	<ul style="list-style-type: none"> <li>Incorrect designation of coordinates for a new mirror-shift conversion function at the offline position data conversion</li> </ul>	

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4599	SERVO COMMAND ERROR	0	An abnormal response was returned from the servo control section. The servo control processing has not completed.	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4601	UNDEFINED GUN COND FILE	---	The motor gun characteristic file is not set. (Subcode: Motor gun characteristic file number)	Complete the settings for the motor gun characteristic file.
4603	WIRE STICKING	---	Wire stick occurred at spot welding. <ul style="list-style-type: none"> <li>Wire stick was detected at the welder. (Subcode: Welder number)</li> </ul>	Remove the cause of wire stick.
4604	DESIGNATED AXIS HOME POSITION CORRECTION DATA NON-EXISTING	---	No home position correction data of specified axis	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> </ul> If the error occurs again, contact your Yaskawa representative.
4605	SETTOOL ERROR	---	An error occurred when executing a SETTOOL instruction. <ul style="list-style-type: none"> <li>The difference between the current tool constant and a new set value exceeded the allowable range (parameter set value).</li> </ul>	<ul style="list-style-type: none"> <li>Check if the tag set value is correct.</li> <li>Check if the parameter is set correctly.</li> </ul>
4606	GLOBAL VARIABLE AREA OVERFLOW	---	The memory area of global variable exceeded the limit value. <ul style="list-style-type: none"> <li>An error occurred in the value of parameter that defines the number of global (user) variables.</li> </ul>	Correct the number of global (user) variables to be used, or correct the parameter value.
4607	MACRO COMMAND EXECUTION ERROR	An error occurred when executing a macro instruction.		Correct the registration of interrupt macro job.
		1	<ul style="list-style-type: none"> <li>The execution macro job is not set.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>The interrupt macro job is not set.</li> </ul>	
		3	<ul style="list-style-type: none"> <li>An attempt was made to start the job that could not be started by the macro instruction.</li> </ul>	Correct the macro job.
		5	<ul style="list-style-type: none"> <li>An error occurred in the operation process of job call stack when the execution of macro instruction was cancelled.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> <li>Turn the power OFF then back ON.</li> </ul> If the error occurs again, contact your Yaskawa representative.
		6	<ul style="list-style-type: none"> <li>Incorrect macro number</li> </ul>	
4608	JOB ARGUMENT GET ERROR	An error occurred when executing a GETARG instruction.		Correct the job.
		1	<ul style="list-style-type: none"> <li>The job argument is not set.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>No number of the specified job argument</li> </ul>	
		3	<ul style="list-style-type: none"> <li>The data types of job argument disagreed.</li> </ul>	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4609	MEMORY PLAY FILE ERROR		An error occurred when executing the memo play operation.	Correct the job.
		2	• The memory play file was being used in another system.	
		5	• The control group in the memory play file did not agree with the control group of execution job.	
		6	• An attempt was made to clear the memory play file by a CLEAR instruction before having executed a MEMOF instruction.	
4610	MEMORY PLAY SAMPLING ERROR		An internal control error occurred at memory play sampling.	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		1	• Failed to read the memory play sampling data.	
		2	• Failed to write the memory play sampling data.	
		3	• Failed to seek the memory play sampling data.	Correctly set the memory play mode.
		4	• Incorrect mode setting at memory play sampling	
		5	• Incorrect designation of the control group at memory play sampling	
4610	MEMORY PLAY SAMPLING ERROR		An internal control error occurred at memory play sampling.	• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
		6	• $K/N < 0$ in the memory play sampling section	
		7	• The memory play sampling data back-play mode could not be detected.	
		8	• The memory play sampling data could not be initialized.	
4611	OPTON INSTRUCTION EXECUTION NUMBER OVER	---	An error occurred when executing a OPTON instruction. • The number of times that the OPTON instruction was executed exceeded the limit value.	Correct the OPTON instruction.
4612	TSYNC ERROR	---	An error occurred at the execution of the TSYNC instruction. • The number of synchronizations (SNUM) specified by the TSYNC instruction disagreed. (Sub code: the number of synchronizations of the first executed TSYNC)	Set the same number of synchronizations of the TSYNC instruction.



## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4613	SERVO SEALER GUN CONTROL ERROR	An internal control error occurred in the servo sealer gun motion.		<ul style="list-style-type: none"> <li>Set the function designation parameter. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	<ul style="list-style-type: none"> <li>The function designation parameter is not set.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>No sealer gun axis exists at the job for which the sealer gun control was attempted to be executed.</li> </ul>	<ul style="list-style-type: none"> <li>Correct the job. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		3	<ul style="list-style-type: none"> <li>No robot axis exists at the job at which an attempt was made to execute sealer gun control.</li> </ul>	
		4	<ul style="list-style-type: none"> <li>Incorrect designation of the control method for sealer gun control</li> </ul>	Set either "1" or "2" for PRM1 control method designation of the OPTON instruction.
		5	<ul style="list-style-type: none"> <li>Incorrect designation of the needle position for sealer gun control</li> </ul>	If "1" is set for PRM1 of the OPTON instruction, set the PRM2 needle position designation to a value between 0 and 100.
		6	<ul style="list-style-type: none"> <li>Incorrect designation of the sealing width for sealer gun control</li> </ul>	If "2" is set for PRM1 of the OPTON instruction, set PRM2 sealing width designation to a value between 0 and 30.
4614	SEALER GUN CHARACTERISTIC FILE UNSET	0	The servo sealer gun condition file is not set.	Set the servo sealer gun condition file.
4615	I/O AXIS MOTION IMPOSSIBILITY (during playback)	0	I/O axis motion could not be performed. (in playback) <ul style="list-style-type: none"> <li>An attempt was made to command a job whose control group was in I/O axis motion.</li> </ul>	<ul style="list-style-type: none"> <li>Stop the I/O axis motion.</li> <li>Correct the job.</li> </ul>
4616	AXIS SHIFT ERROR	An internal control error occurred when shifting the axis.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	<ul style="list-style-type: none"> <li>The file could not be switched because of incorrect start point designation.</li> </ul>	
4616	AXIS SHIFT ERROR	An internal control error occurred when shifting the axis.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		2	<ul style="list-style-type: none"> <li>The control group with which the axis shifting is performed disagrees with the control group set for the axis shifting function in the calibration file.</li> </ul>	
		3	<ul style="list-style-type: none"> <li>The calibration file number for axis shifting function is out of the applicable range.</li> </ul>	
		4	<ul style="list-style-type: none"> <li>There is no "selected" file corresponding to the calibration file number for the axis shift function.</li> </ul>	
4617	SU AXIS MOTION DISABLED (LR AXIS POSITION ERROR)	SU-axes cannot move with the current L- and R-axes position.		<ul style="list-style-type: none"> <li>Reduce the speed of S- and U-axes.</li> <li>Teach the positions of L- and R-axes again so that S- and U-axes can move.</li> </ul>
		1	<ul style="list-style-type: none"> <li>For the CSL15D manipulator, the motion speed of S- and U-axes exceeded the upper limit.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>For the CSL15D manipulator, S- and U-axes were going to move regardless of the limit speed "0" when the positions of L- and R-axes exceeded the upper limit.</li> </ul>	

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4618	SHIFT INSTRUCTION EXECUTION ERROR	1	An internal control error occurred at execution of the SHIFT instruction. • For the tool shift with Euler angle $\pm 90$ degrees, the shift value for axes other than Y-axis is set.	Set the shift value for Y-axis only.
4619	UNDEFINED JOB ENTRY TABLE	---	An error occurred in job registration table. • The job registration table is not set. (Subcode: Designated registration number)	Set the job registration table.
4620	ARM (TOOL) INTERFERENCE	0	Arms or tools interfere between manipulators. • The arm interference check between manipulators detected that manipulator's arms or tools are interfered.	Perform the teaching again to correct positions for manipulators.
4621	WELD COMPLETE SIGNAL ERROR	---	An error occurred in welding completion signal. • The welding completion signal was ON when starting the spot welding instruction execution. (Subcode: Welder number)	Check the settings for welding completion signal.
4622	SELF INTERFERENCE	0	The manipulator's arm interferes with a tool. • The manipulator's self interference check detected that the manipulator's arm interferes with a tool.	Perform the teaching again to correct positions for manipulators.
4623	GETPOS COMMAND ERROR		An error occurred when executing a GETPOS instruction.	Correct the GETPOS instruction.
		1	• An attempt was made to obtain the step that used a local position type variable. (The step with local position type variable cannot be fetched. Example: MOVJ LP000 VJ=25.00)	
4623	GETPOS COMMAND ERROR		An error occurred when executing a GETPOS instruction.	Correct the GETPOS instruction.
		2	• An attempt was made to obtain the step that used an array position type variable. (The step with array position type variable cannot be fetched. Example: MOVJ P[0] VJ=25.00)	
		3	• The specified step did not exist.	
4624	PLUG VOLUME SETTING ERROR	---	Incorrect setting of amount of fillings	Review the setting for the amount of fillings.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4625	WRONG EXECUTION OF LOADDB INST	An error occurred when executing a LOADDB instruction.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	• No file	
		2	• No directory	
		4	• There was no directory entry after this point.	
		-1	• No file name	
		-2	• File presence error	
		-3	• Incorrect file name	
		-4	• The disk is full.	
		-5	• The directory is full.	
		-6	• I/O error	
		-7	• Invalid handle	
		-8	• Handle overflow	
		-9	• File has already been opened.	
		-10	• File attribute error	
		-11	• Open mode error	
		-12	• The hardware disk with large capacity is used.	
		-14	• The door is open.	
		-15	• The disk is write-protected.	
		-30	• Card controller access error	
		-31	• No card	
		-32	• Card drive information readout error	
		-33	• Partition table error	
		-34	• No drive number	
		-35	• No specified partition number	
		-36	• Cluster size error	
		-37	• Incorrect number of sectors	
		-38	• Sector/byte error	
		-40	• Card not applicable for I/O	
		-41	• Nonsupported version	
		-42	• The setting register did not exist.	
		-43	• Card not applicable for ATA	
		-44	• Double chain error	
		-45	• Media error (not fixed disk)	
		-50	• Media error (not fixed disk)	
4625	WRONG EXECUTION OF LOADDB INST	An error occurred when executing a LOADDB instruction.		<ul style="list-style-type: none"> <li>• Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.</li> </ul>
		-51	• Sector read command error	
		-52	• Sector write command error	
4626	IMPOSSIBLE S-AXIS MOV (IN SPHERE)	---	An error occurred at S-axis high-speed rotation. <ul style="list-style-type: none"> <li>• The S-axis rotation radius was below the lower limit.</li> </ul>	Correct the limit distance for S-axis rotation center motion (S1CG067).
4627	GUN RECOGNITION SINGLE OFF	---	The gun identification signal was not received. (Subcode: Gun number)	Check the gun identification signal.

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4628	WRITE VARIABLE NO. MULTI SETTING	---	An error in the variable number setting. • Duplicated usage of the written destination variable numbers. (Subcode: Duplicated variable number)	Correct the written destination variable numbers.
4629	GROUP CHANGE ERROR	An error occurred when executing the group change function.		Validate the group change parameter.
		1	• The group change parameter was invalid.	
		2	• The GRPCHG instruction was executed while the external axis motor was servo ON.	Execute the GRPCHG instruction when the external axis motor was servo OFF.
		3	• The GRPCHG instruction was executed in unchuck status.	Execute the GRPCHG instruction in chuck status.
		4	• The group identification signal was not received.	Check the group identification signal.
		5	• The specified control group number and the group identification number were unmatched.	Check the specified control group number.
		6	• The encoder PG power supply was OFF when the GRPCHG was ON.	Turn ON the encoder PG power supply when GRPCHG is ON.
		7	• The encoder PG power supply was ON when the GRPCHG was OFF.	Turn OFF the encoder PG power supply when GRPCHG is OFF.
		8	• The control group that corresponded to the received group identification signal did not exist.	Check the group identification signal.
4630	DUPLICATED GUN NUMBER	---	The gun numbers were overlapped when executing a SVSPOT instruction. (Subcode: The overlapped gun number)	Check the gun numbers.
4632	UNDEFINED LNR SCALE FILE	---	The linear scale characteristic file is not set. (Subcode: Linear scale characteristic file number)	Set the linear scale characteristic file.
4633	FOLLOWING ERROR	1	An error occurred when executing a FOLLOW instruction. • An attempt was made to re-execute the FOLLOW instruction after interrupting it.	Re-execute the move instruction executed before the FOLLOW instruction, and then re-execute the FOLLOW instruction.
4634	FOLLOWING SPEED OVER	0	The manipulator motion speed exceeded the limit during the Following motion. • With the specified bending speed, the manipulator motion speed exceeds the maximum speed.	<ul style="list-style-type: none"> <li>• Reduce the bending speed.</li> <li>• Perform the teaching again so that the manipulator moving distance becomes shorter.</li> </ul>
4635	CANNOT EXECUTE COMMON JOB	---	The called job could not be executed because the specified control group was shared with the called job. (Subcode: The related control-group)	Correct the control group specified by the CALL instruction.
4636	THICKNESS ERROR	---	Incorrect workpiece thickness (Sub code: Gun number)	
4637	TRACK CHG WORK IN/NOT NOT FOUND	---	No workpiece presence/absence data at switching the synchronization section. (Subcode: Conveyor characteristic file number)	Check the workpiece presence/absence data for the synchronization section.

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4638	TRACKING CHG WORK ID NOT FOUND	---	No workpiece type data at switching the synchronization section. (Subcode: Conveyor characteristic file number)	Check the workpiece type data for the synchronization section.
4639	SYMOVJ INST EXECUTE ERROR	An internal control error occurred during the SYMOVJ motion.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> <li>If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	<ul style="list-style-type: none"> <li>The moving amount in the orientation at the SYMOVJ motion position could not correctly be calculated.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>The conveyor moving amount is not specified for the SYMOVJ motion.</li> </ul>	Set the conveyor moving amount for the SYMOVJ motion.
		3	<ul style="list-style-type: none"> <li>An error occurred in the preparation process of the manipulator motion start position for the SYMOVJ motion.</li> </ul>	<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> <li>If the error occurs again, contact your Yaskawa representative.</li> </ul>
		4	<ul style="list-style-type: none"> <li>An error occurred in the preparation process of the manipulator motion end position for the SYMOVJ motion.</li> </ul>	Reset the alarm, and then try again. If the error occurs again, contact your Yaskawa representative.
4640	WRONG EXECUTION OF PSTART INST	An error occurred when executing a PSTART instruction.		Correct the PSTART instruction.
		1	<ul style="list-style-type: none"> <li>No axis data of control group to be disconnected</li> </ul>	
		2	<ul style="list-style-type: none"> <li>An attempt was made to disconnect a control group other than the occupation control group during prereading processing.</li> </ul>	
		3	<ul style="list-style-type: none"> <li>An attempt was made to disconnect a control group other than the occupation control group when executing a PSTART instruction.</li> </ul>	
4641	CANNOT EXECUTE JOB (SEPARATE GROUP)	---	<ul style="list-style-type: none"> <li>The disconnected control group could not be moved.</li> <li>The control group disconnected by itself was used for its own move instruction. (Subcode: The disconnected control group used by a move instruction)</li> </ul>	Do not use the control group disconnected by itself for its own move instruction.
4644	SPOT WELDER I/F ERROR (ASW)	An error occurred between the controller and spot welder.		<ul style="list-style-type: none"> <li>Reset the alarm, and then try again.</li> <li>Turn the power OFF then back ON.</li> <li>If the error occurs again, contact your Yaskawa representative.</li> </ul>
		1	<ul style="list-style-type: none"> <li>The controller could not access the welder.</li> </ul>	
		2	<ul style="list-style-type: none"> <li>The controller could not send an instruction to the welder because the welder was busy in processing.</li> </ul>	
		3	<ul style="list-style-type: none"> <li>The welder could not receive the instruction sent from the controller.</li> </ul>	
		102	<ul style="list-style-type: none"> <li>The specified welder number (system) could not be found.</li> </ul>	Check the specified welder number (system), and specify the correct welder number.
4645	NOT PERMIT FIXED-WEAV ON SWVON	---	<ul style="list-style-type: none"> <li>Hover weaving could not be executed.</li> <li>The hover weaving is disabled in coordinated motion.</li> </ul>	<ul style="list-style-type: none"> <li>Correct the job.</li> <li>Reset the alarm, and then try again.</li> <li>Turn the power OFF then back ON.</li> <li>If the error occurs again, contact your Yaskawa representative.</li> </ul>

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4651	PALLETIZING EXECUTE ERROR	1	The setting of the palletizing condition configuration file is incomplete.	<ul style="list-style-type: none"> <li>Set the palletizing condition setting file to "Completed."</li> </ul>
		4	Palletize completion universal output number range exceeds the limit.	<ul style="list-style-type: none"> <li>Change the palletize completion universal output signal number of the palletizing condition setting file in the user output signal point of contact number.</li> </ul>
		5	During the palletize start instruction execution, the palletize start instruction is executed again (double execution).	<ul style="list-style-type: none"> <li>Delete the palletize start instruction in the palletize section.</li> </ul>
		6	The value of the palletizing number present value output register (or I variable) is more than the total number output register (or I variable).	<ul style="list-style-type: none"> <li>Check if the palletizing number of current position output register (or I variable) and total number of output register (or I variable) is not changed by another function.</li> </ul>
		7	Palletize completion universal output signal is turned ON at palletize start instruction execution.	<ul style="list-style-type: none"> <li>Reset the palletize completion universal output signal.</li> </ul>
		8	Palletize end instruction is not registered.	<ul style="list-style-type: none"> <li>Register the palletizing end instruction.</li> </ul>
4800	WDT ERROR (CONVERTER)	---	Watchdog timer error in the converter. No response from the converter.	<ul style="list-style-type: none"> <li>Turn the power OFF then back ON after cooling the power supply unit.</li> <li>If the error occurs again, contact your Yaskawa representative.</li> </ul>
4850	REGENERATIVE TROUBLE (SERVO2)	---	Disconnection of SERVOPACK regenerative resistor or failure of regenerative transistor is suspected.	<ul style="list-style-type: none"> <li>Turn the power OFF and back ON.</li> <li>Check the connection of regenerative resistor cable.</li> <li>Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>Replace the SERVOPACK.</li> </ul>
4851	REGENERATIVE OVERLOAD (SERVO2)	---	Regeneration energy exceeds the tolerance when the motor decelerates.	<ul style="list-style-type: none"> <li>Turn the power OFF and back ON.</li> <li>Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>Check the regenerative resistor capacity.</li> <li>Replace the SERVOPACK.</li> </ul>
4852	OVERVOLTAGE (SERVO2)	---	The main circuit DC voltage of SERVOPACK is incorrect.	<ul style="list-style-type: none"> <li>Turn the power OFF and back ON.</li> <li>Check the SERVOPACK Primary supply voltage.</li> <li>Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>Replace the SERVOPACK.</li> </ul>
4853	VOLTAGE DROP (SERVO2)	---	The main circuit DC voltage of SERVOPACK is incorrect.	<ul style="list-style-type: none"> <li>Turn the power OFF and back ON.</li> <li>Check the SERVOPACK Primary supply voltage.</li> <li>Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>Replace the SERVOPACK.</li> </ul>
4854	OVER SPEED (SERVO2)	---	The rotation speed of the servo motor is incorrect.	<ul style="list-style-type: none"> <li>Turn the power OFF and back ON.</li> <li>Check the connections of a motor power line and an encoder line.</li> <li>Check a circumference noise.</li> <li>Replace the SERVOPACK.</li> </ul>

## Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4855	OVERLOAD (MOMENT) (SERVO2)	---	The motor is overloaded. The motor torque has significantly exceeded the rated torque.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Check the connections of a motor power line and an encoder line.</li> <li>• Replace the SERVOPACK.</li> </ul>
4856	OVERLOAD (CONTINUE) (SERVO2)	---	<p>The motor has continued to be overloaded for a certain time. The motor has exceeded the rated torque for a long period of time.</p> <p>*In the case of a large capacity amplifier (The servo pack in use when the alarm is emitted is SGDM-□□AC-NX1.) The temperature of SERVOPACK heatsink has exceeded 100°C. Frequent ON/OFF switching of the servo was detected. Because there is a capacitor in the power supply section of the large capacity amplifier, a large charging current flows when the servo is switched ON. Consequently, if the servo is switched ON/OFF frequently, the main circuit devices in the servo pack will deteriorate.</p>	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Check the connections of a motor power line and an encoder line.</li> <li>• Replace the SERVOPACK.</li> </ul> <p>*In the case of a large capacity amplifier (The servo pack in use when the alarm is emitted is SGDM-□□AC-NX1.)</p> <ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Set the servo ON/OFF switching frequency to no more than 5 switching operations per minute.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Review the ambient operating temperature.</li> <li>• Replace the SERVOPACK.</li> </ul>
4857	DB OVERLOAD (SEVO2)	---	Energy exceeds the capacity of dynamic brake (DB) resistor when it stops.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Replace the SERVOPACK.</li> </ul>
4858	RESIST OVERLOAD (SERVO2)	---	The main circuit could have been repeatedly turned on and off.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Reduce the frequency of the main circuit power supply ON/OFF.</li> <li>• Replace the SERVOPACK.</li> </ul>
4859	HEAT SINK OVERHEAT (SERVO2)	---	The temperature of SERVOPACK heatsink has exceeded 100°C.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Replace the SERVOPACK.</li> </ul>
4860	ENCODER BATTERY ERROR (SERVO2)	---	The voltage drop of encoder backup battery is suspected.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the connection of encoder backup battery and the voltage.</li> <li>• Replace the MOTOR and SERVOPACK.</li> </ul>
4861	ENCODER OVERHEAT (SERVO2)	---	The temperature in the encoder is abnormal.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Replace the MOTOR and SERVOPACK.</li> </ul>
4862	SPEED A/D ERROR (SERVO2)	---	The A/D converter for the speed command input or converted data is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
4863	TORQUE A/D ERROR (SERVO2)	---	The A/D converter for the torque command input is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Replace the SERVOPACK.</li> </ul>
4864	WRONG MOTOR ROTATION (SERVO2)	---	The detected direction of torque is opposite to that of speed.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the connections of a motor power line and an encoder line.</li> <li>• Replace the MOTOR and SERVOPACK.</li> </ul>

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4865	POSITION ERROR (SERVO2)	---	The position deviation pulse has exceeded the threshold.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Check the connections of a motor power line and an encoder line.</li> <li>• Replace the SERVOPACK.</li> </ul>
4866	OPEN PHASE (SERVO2)	---	The voltage of one of three-phase input power supplies to SERVOPACK has dropped.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the connection of a three-phase power supply to SERVOPACK.</li> <li>• Replace the SERVOPACK.</li> </ul>
4867	OVERLOAD WARNING (SERVO2)	---	The motor is overloaded.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Check the connections of a motor power line and an encoder line.</li> <li>• Replace the SERVOPACK.</li> </ul>
4868	REGENERATIVE OVERLOAD WARN(SV2)	---	Regeneration energy exceeds the tolerance when the motor decelerates.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Check the regenerative resistor capacity.</li> </ul>
4869	MECHATROLINK DATA SET WARNING(SV2)	---	The MECHATROLINK communication data setting error.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Contact your Yaskawa representative.</li> </ul>
4870	MECHATROLINK COMMAND WARNING(SV2)	---	The MECHATROLINK communication command is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Contact your Yaskawa representative.</li> </ul>
4871	MECHATROLINK 2 COMMAND WARNING(SV2)	---	The MECHATROLINK communication is incorrect.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the wiring around the MECHATROLINK communication cable.</li> <li>• Take some action against noises from the MECHATROLINK communication cable.</li> <li>• Replace the SERVOPACK.</li> </ul>
4873	BATTERY WARNING (SERVO2)	---	Warning display indicating the voltage drop of the absolute encoder battery.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the battery connection.</li> <li>• Replace the battery.</li> <li>• Replace the SERVOPACK.</li> </ul>
4876	POSITION ERROR WARNING (SERVO2)	---	The position deviation pulse has exceeded the tolerance.	<ul style="list-style-type: none"> <li>• Turn the power OFF and back ON.</li> <li>• Check the settings for manipulator motion condition (influence by external force, load condition).</li> <li>• Check the connections of a motor power line .</li> <li>• Replace the SERVOPACK.</li> </ul>
4901	CUBE/AXIS INTERFERENCE 1	---	The manipulator has moved into the specified cube area 1 or the maximum or minimum value of the axis interference 1 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4902	CUBE/AXIS INTERFERENCE 2	---	The manipulator has moved into the specified cube area 2 or the maximum or minimum value of the axis interference 2 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>



### Alarm Message List

[illegible]

### 8.3 Alarm Message List

Alarm Message List

Alarm Number	Message	Sub Code	Cause	Remedy
4915	CUBE/AXIS INTERFERENCE 15	---	The manipulator has moved into the specified cube area 15 or the maximum or minimum value of the axis interference 15 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4916	CUBE/AXIS INTERFERENCE 16	---	The manipulator has moved into the specified cube area 16 or the maximum or minimum value of the axis interference 16 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4917	CUBE/AXIS INTERFERENCE 17	---	The manipulator has moved into the specified cube area 17 or the maximum or minimum value of the axis interference 17 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4918	CUBE/AXIS INTERFERENCE 18	---	The manipulator has moved into the specified cube area 18 or the maximum or minimum value of the axis interference 18 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4919	CUBE/AXIS INTERFERENCE 19	---	The manipulator has moved into the specified cube area 19 or the maximum or minimum value of the axis interference 19 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4920	CUBE/AXIS INTERFERENCE 20	---	The manipulator has moved into the specified cube area 20 or the maximum or minimum value of the axis interference 20 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4921	CUBE/AXIS INTERFERENCE 21	---	The manipulator has moved into the specified cube area 21 or the maximum or minimum value of the axis interference 21 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4922	CUBE/AXIS INTERFERENCE 22	---	The manipulator has moved into the specified cube area 22 or the maximum or minimum value of the axis interference 22 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4923	CUBE/AXIS INTERFERENCE 23	---	The manipulator has moved into the specified cube area 23 or the maximum or minimum value of the axis interference 23 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>
4924	CUBE/AXIS INTERFERENCE 24	---	The manipulator has moved into the specified cube area 24 or the maximum or minimum value of the axis interference 24 was exceeded.	<ul style="list-style-type: none"> <li>• Check the position in the step (move instruction) where the alarm occurred.</li> <li>• Change the position in the step (move instruction) where the alarm occurred.</li> <li>• Check the interference region.</li> </ul>

## 9 Error

### 9.1 Error Message List

Error warns the operator not to advance to the next operation caused by a wrong operation or the access method when using the programming pendant or an external equipment (computer, PLC, etc.).


When an error occurs, confirm the content of the error then release the error.


To release the error, perform either of the following operations:

- Press [CANCEL] on programming pendant.
- Input alarm/error reset signal (system input).

**NOTE** An error is different from an alarm because it does not stop the robot even if it occurred while the robot was operated (during playback).



When two or more errors occur,  appears in the message display area. Activate the message display area and press [SELECT] to view the list of current errors.



To view details of the selected error contents, select "HELP." To close the error list, select "CLOSE." To release all the errors, press [CANCEL].

### 9.1.1 System and General Operation

Error No.	Data	Error Message	Contents
10	-	Turn off servo power and perform corrective action	It cannot be operated while servo power supply is ON.
20	-	Depress TEACH	Out of specified operation mode
30	-	Illegal setting for number of variables	Parameter setting error
40	-	Undefined robot position variables	Position variable cannot be used.
60	-	Undefined points (ORG, XX, XY)	Not registered user coordinates basic 3 points (ORG, XX, XY)
70	-	Program and current tool different	The tool number registered with teaching position data does not match the tool number selected at the programming pendant.
80	-	Same position in the 3 points	
100	-	On overrun recovery status	
110	-	Turn ON servo power	
120	-	Set to PLAY mode	
130	-	No start using external signal	
140	-	No start using P.P.	
180	-	TEACH mode select signal ON	
190	-	Set variable number	
200	-	Defined group axis	
210	-	Undefined coordinated robots	
212		Cannot register group combination	
230	-	While releasing soft limit	
240	-	Undefined robot	
270	-	Undefined gun condition file	
280	-	Lack of number of I/O points	
290	-	Cannot set same No.	
300	-	Undefined user frame	
310	-	Cannot register Master JOB	
320	-	Cannot operate CHECK-RUN	
330	-	Cannot operate MACHINE LOCK	

Error No.	Data	Error Message	Contents
340	-	Cannot operate Master JOB	
350	-	Cannot initialize	
380	-	Position not checked	Second home position was not checked.
390	-	Can specify servo off by safety relay	
410	-	Time could not be measured	Time could not be measured for TRT function.
420	-	Incorrect number of taught points	The number of the taught points for tool calibration is incorrect.
430	-	Register start reserved JOB	
460	-	Excess time for measuring	
500	-	Undefined robot calibration data	
510	-	Undefined axis	
520	-	Cannot select two coordinated combination	
530	-	Start reservation mode	
550	-	Start reserved JOB change prohibit is set	
560	-	Cannot teach position while soft limit released	
590	-	Register group axis combination	[SYNCHRO] was pressed for coordinated job which was not registered as group.
600	-	Out of setting data range	
610	-	Cannot use the user coordinate	
620	-	Select JOB (robot)	
650	-	Incorrect measured data	
660	-	Wrong data type of position variable	
680	-	Defined data	
	XXX		File No.
700	-	Wrong CMOS memory board type	
760	-	Error in start condition set	
770	-	During robot operation	
800	-	The gun of designation is not connected	

---

## 9.1 Error Message List

---

Error No.	Data	Error Message	Contents
801	-	The group axis of designation is not connection	
810	-	Servo power supply is limited	
820	-	Modification range over	
930	-	Undefined conveyor calibration data	
940	-	Forced pressure signal ON	
950	-	Negative correction distance	
960	-	I/O axis mode requesting	
970	-	ERRSVCPU signal error	
971	-	ERRCPU signal error	

### 9.1.2 Editing

Error No.	Data	Error Message	Contents
1010	-	EDIT LOCK mode	
1020	-	Enter correct value	
1030	-	Unauthorized ID No.	
1050	-	Enter correct date	
1060	-	Enter correct clock	
1070	-	Enter an ID number in 4-8 figures	
1080	-	Negative value can't be set	

### 9.1.3 Job Defined Data

Error No.	Data	Error Message	Contents
2010	-	Incorrect character	
2020	-	Name not entered	
2030	-	Undefined JOB name	
2040	-	Defined JOB name	
2050	-	Address not found	
2070	-	Set robot exactly to taught position	
2080	-	Press INSERT or MODIFY	
2090	-	Only modifying move instruction possible	
2100	-	JOB cannot be edited.	
2110	-	Over soft limit	
2120	-	Cannot insert/alter/delete with servo off	
2150	-	Inserting is not possible from this point	
2160	-	Cannot modify or delete this position	
2170	-	Press INSERT to record same step as previous step	
2180	-	Cannot insert data	
2210	-	Illegal data setting	
2220	-	Display edit instruction	
2240	-	Excessive instruction equation	

## 9.1 Error Message List

Error No.	Data	Error Message	Contents
2250	-	Unmatched number of parentheses in equation	
2260	-	Wrong group axis selection	
2270	-	Cannot insert any more instruction in JOB	
2280	*	JOB memory is full	
	1		Lack of position file memories
	2		Lack of JOB registering memories
	3		Lack of instruction file memories
	4		Lack of memory pool
	5		Lack of pass condition file for multi-layer
2290	-	Undefined master JOB	
2291	*	Undefined SUB Master JOB	
	1		Sub-master 1
	2		Sub-master 2
	3		Sub-master 3
	4		Sub-master 4
	5		Sub-master 5
	6		Sub-master 6
	7		Sub-master 7
	8		Sub-master 8
2292	-	Undefined MASTER START JOB	
2293	*	Undefined SUB START JOB	
	1		Sub-master 1
	2		Sub-master 2
	3		Sub-master 3
	4		Sub-master 4
	5		Sub-master 5
	6		Sub-master 6
	7		Sub-master 7
	8		Sub-master 8



Error No.	Data	Error Message	Contents
2300	-	Cannot teach JOB without group-axis specification	
2310	*	Same label exists	
	XXX		Line No.
2340	-	Pasted data not found	
2360	-	Cannot create editing area	
2370	-	Cannot cut/copy NOP and END instructions	
2390	-	Wrong group axis selection	
2400	-	Cannot move in cut & paste editing	
2430	-	Reverse data not found	
2440	-	Move C-and W-axis to basic position	Lazer cutting
2450	-	Relative JOB not permitted	
2470	-	Wrong JOB type	
2480	-	Wrong JOB coordinates setting	
2500	-	Cannot convert the JOB	
2510	-	Cannot correct position in the JOB	
2520	-	Enter JOB name	
2530	-	Illegal step number	
2540	-	Enter step number	
2550	-	Duplicated step number	
2551	-	Duplicated line number	
2560	-	Cannot correct steps of position variables and REFP	
2570	-	The step does not contain speed	
2580	-	The step dose not contain PL/CONT	
2590	-	Soft limit range over	
2600	-	Cannot teach position in concurrent JOB	
2610	-	Wrong JOB kind	
2620	-	Cannot correct play speed in the JOB	
2630	-	Conveyor position not reset	

---

## 9.1 Error Message List

---

Error No.	Data	Error Message	Contents
2640	-	Incorrect JOB name	
2670	-	Undefined target JOB	
2710	-	Relative job can't be shifted with pulse type	
2730	-	Cannot use robot macro JOB	
2740	-	Cannot use concurrent macro JOB	
2750	-	Cannot use JOB with group-axis specification	
2760	-	Cannot insert/modify/delete for group axis detachment	
2761	-	Axis is separated. Cannot add, modify, or delete.	
2770	-	Cannot reverse data of SVSPOTMOV instruction	
2780	-	Arithmetic error	

### 9.1.4 External Memory Equipment

Error No.	Data	Error Message	Contents
3010	-	Floppy disk drive cable not connected	
3020	-	Floppy disk not inserted into floppy disk drive	
3030	-	Floppy disk protection is ON	
3040	-	File not saved on floppy disk or Compact Flash	
3050	-	File saved on floppy disk or Compact Flash	
3060	-	Out of memory on floppy disk or Compact Flash	
3070	-	Number of files on floppy disk or Compact Flash is full	
3080	-	I/O error on floppy disk or Compact Flash	
3090	*	Transmission error with floppy disk or Compact Flash	
	1		Framing error
	2		Overrun error
	3		Parity error
	4		Data code error
	5		Data read error
	6		Data write error
	7		Data time out
	8		Serial I/O error
	9		Error other than described above
3110	-	Syntax error	
3120	*	HEX code error	
	1		Specification error of data decode
	2		Specification error of EOF record
	3		Record type error
	4		Total check error of record
3130	-	Verify error	

---

## 9.1 Error Message List

---

Error No.	Data	Error Message	Contents
3140	-	Wrong pseudo instruction	
3150	*	Concurrent I/O record error	
	1		Format error
	2		Ladder program is too long.
	3		Exceed the range of the data
	4		Specification error of channel No.
	5		Specification error of relay No.
	6		Timer value error
	7		Specification error of timer No.
3160	-	Cannot load illegal system data	
3170	*	Condition file data error	
	1		Format error
	2		Specified file No. is omitted.
	3		Specified tool No. is omitted.
	4		User file is not registered.

Error No.	Data	Error Message	Contents
3190	*	Error in JOB data record	
	1		Record on the number of position data (NPOS) is wrong for the format.
	2		Record on the user coordinate No. (USER) is wrong for the format.
	3		Record on the tool No. (TOOL) is wrong for the format.
	4		Record on the position data section is wrong for the format.
	5		Record on the robot type of XYZ data (RCONF) is wrong for the format.
	6		Date (DATE) record is wrong for the format.
	7		Comment (COMM) record is wrong for the format.
	8		Record on the JOB attribute data (ATTR) is wrong for the format.
	9		Control group (GROUP) record is wrong for the format.
	10		Local variable (LVARs) record is wrong for the format.
	11		JOB argument (JARGS) record is wrong for the format.
	12		Record on the teaching coordinates for relative job (FRAME) is wrong for the format.
	13		Position data coordinates do not match relative job coordinates.
3200	-	NOP or END instruction not found	
3210	-	Position No. storage area not found	
3220	*	Syntax error in instruction data	
	2		Interior control error
	3		Undefined instruction/tag
	4		Instruction/tag shortage
	5		Disuse instruction/tag
	6		Sub instruction

## 9.1 Error Message List

Error No.	Data	Error Message	Contents
3220	7		No instruction
	8		Invalid instruction
	9		Invalid tag
	10		Invalid character
	11		Undefined intermediate code
	12		Intermediate code shortage
	13		Syntax stack overflow
	14		Syntax stack underflow
	15		Array type tag uncompleted Tag [ARRAY]
	16		Element type tag uncompleted Tag [ELEMENT]
	17		Macro JOB unregistered
	18		Input format error
	19		Data size over
	20		MIN value over
	21		MAX value over
	22		Operation expression error
	23		Job call argument setting error
	24		Macro job call argument setting error
	25		Position vector setting error
	26		System error
	27		Soft key designate error
	28		Numerical input buffer overflow
	29		Real type data precision error
	30		Element format error
	35		BOOL TYPE data error
	36		CHAR data error
	37		BYTETYPE, BINARY / HEXADECI- MAL BYTE TYPE data error
	38		INTEGER TYPE, DECIMAL WORD TYPE data error

Error No.	Data	Error Message	Contents
3220	39		BINARY/HEXADECIMAL WORD TYPE data error
	40		DOUBLE PRECISION INTEGER TYPE, DECIMAL DWORD TYPE data error
	41		BINARY/HEXADECIMAL WORD TYPE data error
	42		REAL TYPE data error
	43		LADDER SPECIAL TYPE data error
	44		JCL text
	45		Invalid text
	46		LABEL NAME data error
	47		JOB NAME data error
	48		STRING data error
	49		COMMENT data error
	58		Invalid instruction/tag detection
3230	-	Syntax not matched	
3240	-	Undefined application	
3250	-	Cannot load this file	
3260	-	Excess input data	
3270	-	Cannot verify this file	
3280	-	Wrong welding condition (STANDARD/ ENHANCED)	
3290	-	Serial port not defined	
3300	-	Serial port being used	
3310	-	Protocol being used	
3350	-	Not enough memory	
3360	-	Invalid folder	
3370	-	Incorrect folder name	
3450	-	Cannot load macro JOB at current security mode	Load in management mode.

---

## 9.1 Error Message List

---

Error No.	Data	Error Message	Contents
3460	*	Cannot backup Compact Flash	
	1		Insufficient Compact Flash memory.
	2		Not accessible to Compact Flash.
3470	-	Database not found	
3480	-	Database access error	
3490	-	Same database exists	
3500	-	Check Compact Flash insertion	
3510	-	Cannot delete folder. Check attribute and inside file	
3520	-	Same folder exists	
3530	-	Cannot load at current security mode	



## 9.1.5 Concurrent I/O

Error No.	Data	Error Message	Contents
4010	*	Illegal relay No.	
	XXX		Line No.
4030	*	Illegal instruction	
	XXX		Line No.
4040	*	Relay/register No. duplicated in OUT/GOUT or arithmetic instruction	Multiple outputs are instructed to the relay or register.
	XXX		Line No.
4050	*	The relay is not used	
	XXX		Line No.
4060	*	Excess STR [-NOT] instructions	
	XXX		Line No.
4070	*	Excess AND [OR] STR instructions	
	XXX		Line No.
4080	*	Syntax error in CNT instructions	
	XXX		Line No.
4090	*	Enter STR [-NOT] at head of block	Need STR [-NOT]
	XXX		Line No.
4120	-	Concurrent I/O memory is full	Exceeds memory capacity (10000 steps)
4130	-	END instruction not found	END instruction not found
4140	-	Wrong ladder program	Position and number of PART instruction are wrong.
4150	*	Wrong use of GSTR, GOUT commands	GSTR and GOUT is not used together.
	XXX		Line No.
4220	-	Excess TMR/CNT or arithmetic instructions	More than 100 TMR, CNT or arithmetic instruction used
4230	-	Syntax error in TMR/CNT instructions	

### 9.1.6 Maintenance Mode


Error No.	Data	Error Message	Contents
8010	-	Too many axes	
8020	-	Too many I/O points	
8030	-	Too many boards (XFB01B (MASTER))	
8031	-	Too many boards (MSC01B)	
8040	-	Memory error (ControlNet output condition)	
8041	-	Memory error (UNIWIRED CONNECT DAT	
8050	-	Robot model is not registered	
8060	-	Cannot get UNIWIRED connection data	

# 10 LED Indicator on Circuit Board

## 10.1 LED Indicator on NCP 01 Circuit Board

The LED indicators: LED0/LED1 on the NCP01 circuit board show the statuses as in the following table. The LED indicators show the operating statuses for the single NCP01 circuit board.

LED0	KED1	Status
OFF	OFF	The power is not turned ON.
ON	OFF	Before the BIOS starts
OFF	ON	The BIOS starts.
ON	ON	The BIOS initialization has been completed./ OS boot starts.




## 10.2 LED Indicator on Robot I/F Unit

The 7-segment LED indicator and battery alarm LED lamp are located on the robot I/F unit (JZNC-NIF01□).

See " 10.3 7 SEG-LED Indicator " for details displayed by the 7-segment LED indicator.

The battery alarm LED lamp is lit when the battery runs out. See " 5.1.1 Replacing Parts of the CPU Unit " to replace the battery.



## 10.3 7 SEG-LED Indicator

The following tables show the operating statuses for JANCD-NIF01/SGDR-AXA01/SGDR-AXA02/JANCD-NCP02. The operating statuses are indicated by 7 SEG-LED.

### [Normal Indication]

Status	NX100		
	NIF Circuit Board	AXA Circuit Board	NCP02 Circuit Board
Right after applying the power	All 7-SEG indicators light up. (‘8’, ‘+’, ‘.’ light up.)		
During the start-up process	Counts up from ‘O’ toward ‘d’.		
After starting up normally	‘d’, ‘+’, ‘.’ blink every one second.		

### [Error Indication]

Status	NX100		
	NIF Circuit Board	AXA Circuit Board	NCP02 Circuit Board
Alarms occurrence in the Main CPU and servo CPU communication system	‘d’, ‘+’, ‘.’ blink every one second.	The error cause is indicated by 7 SEG-LED. (See the indication spec ①.)	‘d’, ‘+’, ‘.’ blink every one second.
Normal alarms other than alarms described above		‘d’, ‘+’, ‘.’ blink every one second.	
Fatal alarms occurrence	The error cause and the address where the error has occurred are indicated by 7 SEG-LED. (See the indication spec ②.)		



#### Indication Spec ①

E.g.)

The cycle: [F] → [0] → [0] → [3] → [.] is repeated. : Error cause

#### Indication Spec ②

E.g.)

[-] → [0] → [2] → [0] → [0] → : Error cause

The cycle: [.] → [-] → [0] → [0] → [0] → [0] → [F] → : Address where the error occurred  
[F] → [0] → [4] is repeated.

## ■ 7 SEG-LED Indicator Status (1-digit indication) of Each Unit at Error Occurrence

NIF01	
All Lit	The power has been turned ON.
0	The booting program has started.
1	The system program has started. (Starts up initializations of various kinds.)
2	Starts verifying the existence of other circuit boards. (Verifies the start-up of the booting program.)
3	Starts the system program transmission.
4	Sends the request of the system program start-up.
5	Starts verifying the existence of other circuit boards. (Verifies the start-up of the system program.)
6	Acquires hardware information, etc. of other circuit boards. (Verifies the IO board status, servo IF, and so on.)
7	Starts the CMOS data transmission.
8	Sends the pre-online request.
9	Waits for CERF communication synchronization.
A	
B	Sends the start-up request of on-line system.
C	The on-line system has started. (Starts up the initialization task.)
D	Processes the NX100 setup completion. (Servo ON enabled)
E	Alarm occurs at the NX100 setup.
F	The maintenance system is starting up.
P	Communications interrupted between NCP01 and the programming pendant.
U	Updating system software through network.

AXA01/AXA02	
All Lit	The power has been turned ON.
0	The booting program has started. (ROM/RAM/FP register check)
1	Starts the booting system. (Completes initializations of various kinds.)
2	Completes the preparation for receiving the system program.
3	The system program has been received. (Waits for the request of system change.)
4	The system program has started. (Starts up hardware initializations of various kinds.)
5	Starts the system. (Completes initializations of various kinds.)
6	Starts the CMOS data transmission.
7	Receives the CERF mapping. (Waits for pre-online)
8	Starts the servo system. (Starts the process of various initializations.)
9	Waits for CERF communication synchronization. (Completes the process of various initializations.)
A	
B	Waits for the start-up of on-line system.
C	
D	Completes the NX setup process. (Servo ON enabled)

NCP02	
All Lit	The power has been turned ON.
0	The booting program has started. (ROM/RAM/FP register check)
1	Starts the booting system. (Completes initializations of various kinds.)
2	Completes the preparation for receiving the system program.
3	The system program has been received. (Waits for the request of system change.)
4	The system program has started. (Starts up hardware initializations of various kinds.)
5	Starts the system. (Completes initializations of various kinds.)
6	Starts the CMOS data transmission.
7	Receives the CERF mapping. (Waits for pre-online)
8	Starts the optional system. (Starts the process of various initializations.)
9	
A	
B	
C	
D	Completes the NX setup process.

## ■ 7 SEG-LED Indicator Status (4 digit-indication) of Each Unit at Error Occurrence

NIF01	
0000	Arithmetic error
0001	Debug
0002	NMI
0003	Breakpoint
0004	Overflow
0005	Out of BOUND
0006	Invalid operation code
0007	Device disabled
0008	Double fault
0009	Coprocessor segment overrun
000A	Invalid TSS
000B	Segment absence
000C	Stack segment fault
000D	General protection exception
000E	Page fault
000F	
0010	Floating point error
0011	Alignment check
0012	Machine check
0013	SIMD floating point exception
0014	
0015	
0016	
0017	
0018	
0019	
001A	
001B	
001C	
001D	
001E	
001F	
0900	WDT error



AXA01/AXA02	
0010	ROM error in the boot section
0020	RAM error
0030	FP register error
0040	On-line communications command error
0100	Reset exception
0200	Machine check exception
0210	WDT error
0300	Data access error
0400	Instruction access exception
0500	
0600	Alignment exception
0700	Program exception
0800	Unavailable floating point exception
0900	
0A00	Undefined exception
0B00	Undefined exception
0C00	System call exception
0D00	Trace exception
0E00	Undefined exception
0F00	Undefined exception
1000	Instruction conversion error exception
1100	Data load conversion error exception
1200	Data store conversion error exception
1300	Instruction breakpoint exception
1400	System management interruption
1500	Undefined exception
1600	Undefined exception
1700	Undefined exception
1800	Undefined exception
1900	Undefined exception
1A00	Undefined exception
1B00	Undefined exception
1C00	Undefined exception
1D00	Undefined exception
1E00	Undefined exception
1F00	Undefined exception
2000	Undefined exception
2100	Undefined exception
2200	Undefined exception
2300	Undefined exception
2400	Undefined exception
2500	Undefined exception
2600	Undefined exception
2700	Undefined exception

AXA01/AXA02	
2800	Undefined exception
2900	Undefined exception
2A00	Undefined exception
2B00	Undefined exception
2C00	Undefined exception
2D00	Undefined exception
2E00	Undefined exception
2F00	Undefined exception
3010	Receiving data size error
3020	Receiving data sum error
3030	Receiving data write address error
3040	All receiving data sum error
F001	Communication error with NIF01 (Send incompleteness)
F002	Communication error with NIF01 (Receive incompleteness)
F003	Communication error with NIF01 (Receive WDT)
F004	Communication error with NIF01 (Receive WDT inconsistency)
F010	Communication error with NIF01 (CERF status)

NCP02	
0010	ROM error in the boot section
0020	RAM error
0030	FP register error
0040	On-line communications command error
0100	Reset exception
0200	Machine check exception
0210	WDT error
0300	Data access error
0400	Instruction access exception
0500	
0600	Alignment exception
0700	Program exception
0800	Unavailable floating point exception
0900	
0A00	Undefined exception
0B00	Undefined exception
0C00	System call exception
0D00	Trace exception
0E00	Undefined exception
0F00	Undefined exception
1000	Instruction conversion error exception
1100	Data load conversion error exception
1200	Data store conversion error exception
1300	Instruction breakpoint exception
1400	System management interruption

NCP02	
1500	Undefined exception
1600	Undefined exception
1700	Undefined exception
1800	Undefined exception
1900	Undefined exception
1A00	Undefined exception
1B00	Undefined exception
1C00	Undefined exception
1D00	Undefined exception
1E00	Undefined exception
1F00	Undefined exception
2000	Undefined exception
2100	Undefined exception
2200	Undefined exception
2300	Undefined exception
2400	Undefined exception
2500	Undefined exception
2600	Undefined exception
2700	Undefined exception
2800	Undefined exception
2900	Undefined exception
2A00	Undefined exception
2B00	Undefined exception
2C00	Undefined exception
2D00	Undefined exception
2E00	Undefined exception
2F00	Undefined exception
3010	Receiving data size error
3020	Receiving data sum error
3030	Receiving data write address error
3040	All receiving data sum error

---

## Numerics

---

10A ceramic fuse .....	5-18
200VAC input connector .....	5-2
24V fuse for I/O .....	5-2
24VDC fuse for I/O .....	5-14
24VDC output connector .....	5-2
3A glass-tube fuse .....	5-18
5A alarm fuse .....	5-18

## A

---

absolute data allowable range alarm occurs...	6-14
AC control power supply connector .....	5-10, 5-11
alarm .....	8-1
alarm history .....	7-20
alarm history window .....	7-20
alarm level .....	8-1
amplifier .....	5-16
axis data .....	8-3

## B

---

backboard .....	5-15
backside duct fan .....	3-1, 3-3, 5-15
battery .....	3-1, 5-15
battery inspections .....	3-6
binary data .....	8-3
brake fuse .....	5-13

## C

---

changing the absolute data .....	6-7
changing the monitor items .....	7-27
checking and replacing fuses .....	5-13
circuit breaker (QF1) check .....	3-7
clearing absolute data .....	6-8
clearing the alarm history .....	7-21
Clearing the I/O message history .....	7-23
Clearing the System Monitoring Time Display .....	7-19
Compact Flash .....	5-2
connector for encoder signal .....	5-2
connector for external power supply .....	5-2
control circuit board (JANCD-NCP01) .....	5-2, 5-15
control group data .....	8-3
control power supply (CPS-420F) ....	3-3, 5-2, 5-15
control power supply fuse .....	5-13
converter .....	5-16
converter control signal connector .....	5-10, 5-11
converter signal connector .....	5-2
cooling fan (JZNC-NZU01) .....	3-3
cooling fan construction (medium- or large-capacity NX100) .....	3-4

cooling fan construction (small-capacity NX100) .....	3-3
correlate voltage .....	3-6
CPU unit (JZNC-NRK01) .....	5-2, 5-15
creating a check program .....	4-3
current position .....	7-25
current position window .....	7-25

## D

---

DC control power supply connector .....	5-10, 5-11
decimal data .....	8-3
displaying and releasing alarm .....	8-2
door lock .....	3-2
drive I/F(1) connector .....	5-2
drive I/F(2) connector .....	5-2

## E

---

editing mode .....	2-1
emergency stop button .....	3-1
emergency stop button inspections .....	3-5
emergency stop connector .....	5-2
Enable switch .....	3-1
Enable switch inspections .....	3-5
ENCODER ROTATE SUM .....	7-26
error message list .....	9-1
ERROR PULSE .....	7-26

## F

---

FEEDBACK PULSE .....	7-26
FEEDBACK SPEED .....	7-26

## G

---

ground wiring .....	5-10
---------------------	------

## H

---

home position .....	6-3
home position calibration .....	6-2
hotline connector for programming pendant .....	5-2
how to replace converter .....	5-11

---

## I

---

I/F connector between robots .....	5-2
I/O circuit board .....	5-15
I/O communications connector .....	5-2
I/O I/F connector .....	5-2
I/O message history .....	7-22
I/O message history window .....	7-22
IN 1 TURN POSITION .....	7-26
independent control function (optional) .....	8-4
individual window of the system monitoring time display .....	7-18
in-panel fan .....	3-1, 5-13
in-panel ventilation fan .....	3-3
input power supply check .....	3-7
input/output status .....	7-3
Interior circulation fan .....	5-15

---

## L

---

lead cable check .....	3-7
------------------------	-----

---

## M

---

main power switch .....	3-2
major alarm .....	8-1
management mode .....	2-1
manipulator home position .....	6-9
manipulator model .....	7-2
MAX. TORQUE .....	7-26
minor alarm .....	8-1
mode switch .....	3-5
modification of the signal name .....	7-15
modifying the output status .....	7-5
MOTOR ABSOLUTE .....	7-26
motor power connector .....	5-10, 5-12
multiple SERVOPACK system .....	8-3

---

## N

---

NX100 controller .....	3-1
NX100 parts list .....	5-13

---

## O

---

open phase check .....	3-7
operation mode .....	2-1
outline of alarm .....	8-1

---

## P

---

PN power supply connector .....	5-11, 5-12
position data when power is turned ON/OFF ..	7-24
position deviation check using the check program .....	6-10
power flow .....	1-3
power ON/OFF position window .....	7-24
power supply contactor unit .....	5-11, 5-15
power supply contactor unit fuse .....	5-15
power supply voltage confirmation .....	3-6
PWM amplifier control power supply connector .....	5-11, 5-12
PWM signal connector .....	5-10, 5-11, 5-12

---

## R

---

rack for the various circuit boards .....	5-2
recommended spare parts .....	5-18
regenerative resistor connector .....	5-10, 5-11
regular inspections .....	3-1
remote control connector .....	5-2
replacing parts .....	5-1
replacing parts of the CPU unit .....	5-2
replacing the base-axis control circuit board (SGDR-AXA01A) .....	5-5
replacing the control circuit board (JANCD-NCP01) .....	5-3
replacing the control power supply (CPS-420F) .....	5-4
replacing the I/O circuit board (JANCD-NIO01□) .....	5-9
replacing the robot I/F circuit board (JANCD-NIF01) .....	5-8
replacing the robot I/F unit (JZNC-NIF01□) .....	5-6
replacing the SERVOPACK .....	5-10
RIF communications connector .....	5-2
RIN input .....	7-8
RIN input window .....	7-8
robot I/F circuit board .....	5-15
robot I/F unit (JZNC-NIF01□) .....	5-2, 5-15
robot I/F unit fuse .....	5-15

---

## S

---

security mode .....	2-1
security system .....	2-1
servo control circuit board (SGDR-AXA01A) .....	5-2, 5-13
servo monitor window .....	7-26
servo monitoring .....	7-26
SERVO ON .....	3-5
SERVO ON READY .....	3-5
SERVOPACK .....	5-10, 5-15, 5-16
SERVOPACK list .....	5-14
signal flow .....	1-4
SPECIFIC OUTPUT simple window .....	7-7

---

SPECIFIC OUTPUT window .....	7-7
Specific Input .....	7-6
SPECIFIC INPUT simple window .....	7-6
SPECIFIC INPUT window .....	7-6
Specific Output.....	7-7
SPECIFIC OUTPUT simple window .....	7-7
SPECIFIC OUTPUT window .....	7-7
SPEED DEVIATION .....	7-26
SPEED INST .....	7-26
supplied parts list .....	5-18
System.....	7-17
system diagnosis.....	7-1
system input connector for robot .....	5-2
system monitoring time display .....	7-17
System Monitoring Time Display Window .....	7-17
system version.....	7-1

## T

---

three-phase AC power supply	
connector .....	5-10, 5-11
TORQUE SPEC .....	7-26
TU hotline I/O connector .....	5-2

## U

---

universal input.....	7-3
UNIVERSAL INPUT simple window .....	7-3
UNIVERSAL INPUT window.....	7-3
UNIVERSAL OUTPUT simple window.....	7-4
UNIVERSAL OUTPUT window .....	7-4
user I/O connector .....	5-2
user ID .....	2-7
universal output.....	7-4

## V

---

voltage between earth (phase-S ground) .....	3-6
--	-----

## W

---

WAGO connector wiring tool .....	5-18
WAGO terminal block wiring tool.....	5-18

## X

---

XYZ coordinate data .....	8-3
---------------------------	-----

# NX100

# MAINTENANCE MANUAL

---

## HEAD OFFICE

2-1 Kurosaki-Shiroishi, Yahatanishi-ku, Kitakyusyu, Fukuoka, 806-0004, Japan  
Phone +81-93-645-7745 Fax +81-93-645-7746

YASKAWA America Inc. MOTOMAN Robotics Division  
805 Liberty Lane, West Carrollton, OH 45449, U.S.A.  
Phone +1-937-847-6200 Fax +1-937-847-6277

YASKAWA Nordic AB  
Franska vagen 10, Box 4004, 390 04 Kalmar, Sweden  
Phone +46-480-417800 Fax +46-480-417999

YASKAWA Europe GmbH Robotics Division  
Kammerfeld strasse 1, 85391 Allershausen, Germany  
Phone +49-8166-90-100 Fax +49-8166-90-103

YASKAWA Electric Korea Co., Ltd.  
7F, Doore Bldg.; 24, Yeoido-Dong Youngdungpo-ku, Seoul, KOREA  
Phone +82-2-784-7844 Fax +82-2-784-8495

YASKAWA Electric (Singapore) PTE Ltd.  
151 Lorong Chuan, #04-02A, New Tech Park, Singapore 556741  
Phone +65-6282-3003 Fax +65-6289-3003

YASKAWA Electric (Thailand) Co., Ltd.  
252/246, 4th Floor. Muang Thai-Phatra Office Tower II Rachadaphisek Road, Huaykwang Bangkok, 10320 Thailand  
Phone +66-2-693-2200 Fax +66-2-693-4200

Shougang MOTOMAN Robot Co. Ltd.  
No.7, Yongchang-North Road, Beijing E&T Development Area, China 100176  
Phone +86-10-6788-2858 Fax +86-10-6788-2878

MOTOMAN Motherson Robotics Ltd.  
Plot No.195-196, 1st Floor, Sec.4 IMT Manesar, Gurgaon 122050, Haryana  
Phone +91-124-475-8500 Fax +91-124-414-8016

---

Specifications are subject to change without notice  
for ongoing product modifications and improvements.